# OMRON

Machine Automation Controller NX-series EtherNet/IP™ Unit

**User's Manual** 

NX-EIP201

EtherNet/IP Unit





W627-E1-02

#### NOTE -

- 1. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.
- No patent liability is assumed with respect to the use of the information contained herein.
   Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice.
- Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions.
   Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

#### Trademarks -

- Sysmac and SYSMAC are trademarks or registered trademarks of OMRON Corporation in Japan and other countries for OMRON factory automation products.
- Microsoft, Windows, Excel, Visual Basic, and Microsoft Edge are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- EtherCAT<sup>®</sup> is registered trademark and patented technology, licensed by Beckhoff Automation GmbH. Germany.
- ODVA, CIP, CompoNet, DeviceNet, and EtherNet/IP are trademarks of ODVA.
- The SD and SDHC logos are trademarks of SD-3C, LLC.

Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

#### Copyrights

- · Microsoft product screen shots used with permission from Microsoft.
- This product incorporates certain third party software. The license and copyright information associated with this software is available at http://www.fa.omron.co.jp/nj info e/.

# Introduction

Thank you for purchasing an NX-series EtherNet/IP Unit.

This manual contains information that is necessary to use the NX-series EtherNet/IP Unit. Please read this manual and make sure you understand the functionality and performance of the NX-series EtherNet/IP Unit before you attempt to use it in a control system.

Keep this manual in a safe place where it will be available for reference during operation.

#### **Intended Audience**

This manual is intended for the following personnel, who must also have knowledge of electrical systems (electrical engineers or the equivalent).

- · Personnel in charge of introducing FA systems.
- · Personnel in charge of designing FA systems.
- · Personnel in charge of installing and maintaining FA systems.
- · Personnel in charge of managing FA systems and facilities.

For programming, this manual is intended for personnel who understand the programming language specifications in international standard IEC 61131-3 or Japanese standard JIS B 3503.

## **Applicable Products**

This manual covers the following products.

 NX-series EtherNet/IP Unit NX-EIP201

# **Relevant Manuals**

The following table provides the relevant manuals for the NX-series CPU Units. Read all of the manuals that are relevant to your system configuration and application before you use the NX-series CPU Unit.

Most operations are performed from the Sysmac Studio Automation Software. Refer to the *Sysmac Studio Version 1 Operation Manual (Cat. No. W504)* for information on the Sysmac Studio.

												I	Vlar	nua	ı											_
	В	asi			rma	3-																				
	_	tion																								
Purpose of use		NX-series NX502 CPU Unit	Software User's Manual	NJ/NX-series CPU Unit	Instructions Reference Manual	NJ/NX-series	Motion Control User's Manual	NJ/NX-series CPU Unit	Motion Control Instructions Reference Manual	NJ/NX-series	Built-in EtherCAT Port User's Manual	NJ/NX-series CPU Unit	Built-in EtherNet/IP Port User's Manual	NJ/NX-series CPU Unit	EtherNet/IP Unit User's Manual	NX-series	OPC UA User's Manual	NJ/NX-series CPU Unit	FINS Function User's Manual	NX-series CPU Unit	User's Manual	NJ/NX-series Database Connection CPU Units	Automation Playback User's Manual	NX-series CPU Unit	Troubleshooting Manual	NJ/NX-series
Introduction to NX502 CPU Units	•																									_
Setting devices and hardware																										
Using motion control							•																			
Using EtherCAT																										
Using EtherNet/IP															•											
Software settings																										
Using motion control																										
Using EtherCAT											•															
Using EtherNet/IP													•		•											
Using OPC UA																										
Using FINS																										
Using the database connection service																					•	•				
Using automation playback																										


			_ :									ı	Vlar	nua	I											
	B	ası	c II		rma	3-																				
	Ξ	z	_		<u></u>	Z	3	Z	3	Z	Œ	Z	Œ	Z	Щ	Z	0	z	Ξ	Z	C	Z	>	Z	=	z
	Hardware User's Manual	NX-series NX502 CPU Unit	Software User's Manual	NJ/NX-series	Instructions Reference Manual	NJ/NX-series	Motion Control User's Manual	NJ/NX-series CPU Unit	<b>Motion Control Instructions Reference Manual</b>	NJ/NX-series	Built-in EtherCAT Port User's Manual	NJ/NX-series CPU Unit	Built-in EtherNet/IP Port User's	NJ/NX-series CPU Unit	EtherNet/IP Unit User's Manual	<b>NX-series</b>	OPC UA User's Manual	NJ/NX-series CPU Unit	FINS Function User's Manual	<b>NX-series CPU Unit</b>	User's Manual	NJ/NX-series Database Connection CPU Units	Automation Playback User's Manua	NX-series CPU Unit	Troubleshooting Manual	N
	var	erie	/are	X-SE	ıcti	X-se	ň	X-se	n C	X-se	E E	X-SE	j.	X-se	Net	erie	Z	X-SE	Fur	erie	s N	X-se	mat	erie	oles	NJ/NX-series
		S	SU	erie	ons	erie	ont	erie	ont	erie	the	erie	the	erie	₽	S	<b>Use</b>	erie	nctic	s C	anu	erie	ion	s C	hoc	erie
		X50	er's	SC	Re	S	<u>o</u>	s CI	<u>o</u>	G	Ĉ	SC	r Ne	SC	Uni		S,JK	SC	on (	2	<u>a</u>	s Da	Pla	2	ting	G
Purpose of use	S S	2 C	Ma	Š	fere		Use	) De	Inst		TP	Š	Ž P	č	sN 1		Maı	č	Jsei	Unit		atab	yba	Unit	<u>≥</u>	
	anu	2	nua	<b>CPU Unit</b>	nce		S	Jnit	ruc		ont	Jnit	Po	Jnit	er's		nual	Jnit	''s N			ase	ck		anu	
	<u>a</u>	Unit	=		Ma		Mar		tion		Use		<b>∓</b>		Ma		_		/an			Co	Jse		<u>a</u>	
		_			nua		nual		S R		S, J.		ser		ınu				ual			nne	r's I			
					_				efei		Mai		s N		=							ctic	<b>lan</b>			
									one,		านล		Manual									on C	ual			
									ë z				<u>a</u>									ΡU				
									anu													Uni				
Writing the user program									<u>a</u>													ls				_
Using motion control	1						_																			
Using EtherCAT												•														
Using EtherNet/IP														•		•										
Using OPC UA																		•								
Using FINS			•		•																					
Using the database connection serv-																										
ice																					•					
Using automation playback																							•			
Programming error processing																										
Testing operation and debugging																										
Using motion control																										
Using EtherCAT											•															
Using EtherNet/IP													•		•											
Using OPC UA			•																							
Using FINS																			•							
Using the database connection serv-																										
ice																					L.					
Using automation playback																							•			
Learning about error management and																	_	7		7	_	7	_	_		
corrections*1	-		_																							
Maintenance	-		_																							
Using motion control	-																									
Using EtherCAT	-										•		_													
Using EtherNet/IP													•													

<sup>\*1.</sup> Refer to the *NJ/NX-series Troubleshooting Manual (Cat. No. W503)* for the error management concepts and the error items. However, refer to the manuals that are indicated with triangles ( $\triangle$ ) for details on errors corresponding to the products with the manuals that are indicated with triangles ( $\triangle$ ).

# **Manual Structure**

# Page Structure

The following page structure is used in this manual.



This illustration is provided only as a sample. It may not literally appear in this manual.

## **Special Information**

Special information in this manual is classified as follows:



#### Precautions for Safe Use

Precautions on what to do and what not to do to ensure safe usage of the product.



# Precautions for Correct Use

Precautions on what to do and what not to do to ensure proper operation and performance.



# Additional Information

Additional information to read as required.

This information is provided to increase understanding or make operation easier.



#### Version Information


Information on differences in specifications and functionality for Controller with different unit versions and for different versions of the Sysmac Studio is given.

## **Precaution on Terminology**

In this manual, "download" refers to transferring data from the Sysmac Studio to the physical Controller and "upload" refers to transferring data from the physical Controller to the Sysmac Studio. For the Sysmac Studio, "synchronization" is used to both "upload" and "download" data. Here, "synchronize" means to automatically compare the data for the Sysmac Studio on the computer with the data in the physical Controller and transfer the data in the direction that is specified by the user.

Manual Structure

# **Sections in this Manual**



# **CONTENTS**

	Introduction	
	Intended Audience	
	Applicable Products	
	Relevant Manuals	2
	Manual Structure	4
	Page Structure	
	Special Information	
	Precaution on Terminology	
	Sections in this Manual	7
	Terms and Conditions Agreement	14
	Warranty, Limitations of Liability	
	Application Considerations	
	Disclaimers	
	Statement of security responsibilities for assumed use cases and against threats	10
	Safety Precautions	17
	Definition of Precautionary Information	
	Symbols	
	Warnings	10
	Precautions for Safe Use	20
	Precautions for Correct Use	23
	Regulations and Standards	25
	Unit Versions	26
	Unit Versions	
	Dalata d Managala	07
	Related Manuals	27
	Revision History	29
	•	
Secti	on 1 Features and System Configuration	
	1-1 Features	1-2
	1-1-1 EtherNet/IP Features	1-2
	1-1-2 Features of NX-series EtherNet/IP Units	1-2
	1-2 System Configuration	1-6
	1-3 Introduction to Communications Services	1-8
	1-3-1 CIP (Common Industrial Protocol) Communications Services	
	1-3-2 IP Routing 1-3-3 Packet Filter	
	1-3-4 BOOTP Client	
	1-3-5 Specifying Host Names	1-11
	1-3-6 SNMP Agent	
	1-3-7 LLDP	
	1-4 Support Software	1-14

Section 2	<b>Specifications and Application Procedures</b>	
•	ecifications	
2-1-1 2-1-2	General Specifications Performance Specifications	
2-1-3	Function Specifications	
2-2 Eth	erNet/IP Communications Procedures	2-
Section 3	Part Names and Functions	
3-1 Par	t Names	3-2
3-2 Par	t Functions	3-
3-2-1	Operation Status Indicators	
3-2-2	DIP Switch	3-4
Section 4	Mounting	
4-1 Mo	unting and Removing NX-series EtherNet/IP Units	4-2
Section 5	Installing Ethernet Networks	
	ecting the Network Devices	
5-1-1	Recommended Network Devices	
5-1-2 5-1-3	Ethernet Switch Types Ethernet Switch Functions	
5-1-4	Precautions for Ethernet Switch Selection	
5-2 Net	work Installation	5-7
5-2-1	Basic Installation Precautions	
5-2-2	Recommended Network Devices	
5-2-3 5-2-4	Precautions When Laying Twisted-pair Cable	
	Precautions When Installing and Connecting Ethernet Switches	
	nnecting to the Network	
5-3-1 5-3-2	Ethernet Connectors	
Section 6	Device Variables Related to the NX-series E Unit	therNet/IP
<b>6-1 Wh</b> 6-1-1 6-1-2	at You Can Check with Device Variables	6-2
	vice Variables	
6-3 Spe	ecifications for Individual Device Variables	6-10
Section 7	Sysmac Studio Settings for the EtherNet/IP	Port

TCP/IP Settings Display ......7-2

LINK Settings Display.....7-10

SNMP Settings Display......7-11

7-1

7-2 7-3

	7-4	SNI	MP Trap Settings Display	7-13
	7-5	CIP	Settings Display	7-15
Section	n	8	TCP/IP Functions	
	8-1	Det	ermining IP Addresses	8-2
		8-1-1	IP Addresses	
		8-1-2	EtherNet/IP Port IP Address Settings	8-4
		8-1-3	Private and Global Addresses	8-9
	8-2	Defa	ault States of TCP/UDP Ports and the Changing Procedure	8-12
	8-3	Tes	ting Communications	8-13
		8-3-1	PING Command	
		8-3-2	Using the PING Command	8-13
		8-3-3	Host Computer Operation	8-13
	8-4	Pac	ket Filter	8-15
		8-4-1	Introduction to Packet Filter	
		8-4-2	Packet Filter Specifications	
		8-4-3	Packet Filter Settings	
		8-4-4	Settings for Devices That Access the Controller	8-17
	8-5	Por	t Forward via NX-series EtherNet/IP Units	8-20
	00	8-5-1	Port Forward on Which a CPU Unit Is a Client	
		8-5-2	Port Forward on Which an External Device Is a Client	
		8-5-3	Port Forward Between CPU Unit and NX-series EtherNet/IP Unit or Between Ether-	
			Net/IP Ports on NX-series EtherNet/IP Units	8-24
	9-1		oduction to Tag Data Links	
		9-1-1 9-1-2	Tag Data Links	
		9-1-2	Tag Data Link Functions and Specifications	
		9-1-4	Overview of Operation	
		9-1-5	Starting and Stopping Tag Data Links	
		9-1-6	Controller Status	
		9-1-7	Concurrency of Tag Data Link Data	9-12
	9-2	Sett	ting Tag Data Links	9-15
	<b>-</b>	9-2-1	Starting the Network Configurator	
		9-2-2	Tag Data Link Setting Procedure	
		9-2-3	Registering Devices	
		9-2-4	Creating Tags and Tag Sets	
		9-2-5	Connection Settings	
		9-2-6	Creating Connections Using the Wizard	
		9-2-7	Creating Connections by Dragging and Dropping Devices	
		9-2-8 9-2-9	Connecting the Network Configurator to the Network  Downloading Tag Data Link Parameters	
		9-2-9		
		9-2-10	Verifying Tag Data Link Parameters	
		9-2-12		
		9-2-13	3 11 3 3	
		9-2-14	- 5	
		9-2-15	Reading a Network Configuration File	9-67
		9-2-16	•	
		9-2-17	- 3 3	
		9-2-18	Displaying Device Status	9-72
	9-3	Lad	der Programming for Tag Data Links	9-73
		9-3-1	Ladder Programming for Tag Data Links	9-73
		9-3-2	Status Flags Related to Tag Data Links	9-76

9-4 Tag	Data Links with Other Models	9-78
9-5 Qui	ckConnect	9-82
9-5-1	Method of Use	
9-5-2	Managed Switches	9-83
Section 10	CIP Message Communications	
10-1 Ove	erview of the CIP Message Communications Service	10-2
10-1-1	Overview of the CIP Message Communications Service	
10-1-2	Message Communications Service Specifications	10-2
10-2 Clie	ent Function of CIP Message Communications	10-3
10-2-1	Overview	10-3
10-2-2		
10-2-3	<b></b>	
10-2-4		
10-2-5	1 ( - /	
10-2-6 10-2-7	· · · · · · · · · · · · · · · · · · ·	
10-2-8	1 0	
	·	
	ver Function of CIP Message Communications	
10-3-1	CIP Message Structure for Accessing CIP Objects	
10-4 Spe	cifying Request Path	
10-4-1	Examples of CIP Object Specifications	
10-4-2	Logical Segment	10-27
10-5 CIP	Object Services	10-28
10-5-1		
10-5-2		
10-5-3 10-5-4	- , (- ,	
Section 11	SNMP Agent	
11-1 SNN	MP Agent	11-2
	Overview	11-2
11-1-2	Specifications	
11-1-3	3	
11-1-4	MIB Specifications	11-4
11-2 Pro	cedure to Use the SNMP Agent	11-25
11-2-1	Procedures	
11-2-2	Settings Required for the SNMP Agent	11-25
Section 12	Communications Performance and Commu	unications
	Load	
12-1 Con	nmunications System	12-2
12-1-1		
12-1-2		
12-1-3	Packet Interval (RPI) Accuracy	12-6
12-2 Adii	usting the Communications Load	12-7
12-2-1	=	
12-2-2		
12-2-3	o o	
12-2-4	Changing the RPI	12-11
12-2-5	RPI Setting Examples	12-16

	12-3 Tag Data Link I/O Response Time	
	12-3-1 Timing of Data Transmissions	
	12-4 Message Service Transmission Delay	
Secti	on 13 Instructions Specific to NX-series EtherNet/	
	Commonly Used Structure Variables	13-2
	TDLinkStartConnection	13-3
	Variables Related Device Variables	
	Related Device variables	
	Function	13-5
	Precautions for Correct Use	
	Sample Programming	
	TDLinkStopConnection  Variables	
	Related Device Variables	
	Related Error Codes	13-9
	Function	
	Precautions for Correct Use	
Secti	on 14 Troubleshooting	
	<ul> <li>14-2 Checking with the Unit Status Indicators on the NX-series EtherNet/IP</li> <li>14-3 Checking with the EtherNet/IP Status Indicators on the NX-series Ethe</li> <li>14-4 Checking with the Sysmac Studio, an HMI, and Instructions That Read</li> <li>14-4-1 Types of Communications Errors</li> <li>14-4-2 Source and Level of Communications Errors</li> <li>14-4-3 Error Tables</li> <li>14-4-4 Error Details</li> </ul>	rNet/IP Unit14-5 Error Status .14-6 14-6 14-7 14-8
	14-5 Checking with Device Variables	14-46
	14-6 Checking with the Network Configurator	14-47
	14-6-1 The Network Configurator's Device Monitor Function	14-47
Secti	14-6-2 Connection Status Codes and Troubleshooting  ion 15 Maintenance and Inspection	14-55
	15-1 Maintenance and Inspection	15-2
Appe	ndices	
	A-1 Dimensions	A-2
	A-2 Functional Comparison of EtherNet/IP Ports on NJ/NX-series CPU L Other Series	
	A-3 Use the Sysmac Studio to Set the Tag Data Links (EtherNet/IP Connect	
	A-3-1 Overview of the Tag Data Links (EtherNet/IP Connections) Settings with the	
	A-3-2 Procedure to Make the EtherNet/IP Connection Settings with the Sysmac S	tudio A-7
	A-3-3 EtherNet/IP Connection Settings	
	A-5-4 IVIAKING THE EMEMBERIA CONNECTION SETTINGS WITH THE SYSTIAC STUDIO	A-12

A-3-5	Checking Communications Status with the Sysmac Studio and Troubleshooting	A-32
A-3-6	Troubleshooting	
A-4 EDS	File Management	A-43
A-4-1	Installing EDS Files	
A-4-2	Creating EDS Files	
A-4-3	Deleting EDS Files	A-44
A-4-4	Saving EDS Files	
A-4-5	Searching EDS Files	A-45
A-4-6	Displaying EDS File Properties	A-46
A-4-7	Creating EDS Index Files	A-46
A-5 Prec	autions for Using the Network Configurator on Windows XP, Windows Vis-	_
	r Windows 7 or Higher	
A-5-1	Changing Windows Firewall Settings	
A-6 Tag I	Data Link Settings with Generic Devices	A-50
A-6-1	Creating Generic Devices	
A-6-2	Creating a Tag or Tag Set for Generic Device	
A-7 TCP/	UDP Port Numbers Used for the NX-series EtherNet/IP Unit	A-55

# Index

# **Terms and Conditions Agreement**

## Warranty, Limitations of Liability

## **Warranties**

#### Exclusive Warranty

Omron's exclusive warranty is that the Products will be free from defects in materials and work-manship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

#### Limitations

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right.

#### Buyer Remedy

Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See http://www.omron.com/global/ or contact your Omron representative for published information.

# Limitation on Liability; Etc

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY

WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

## **Application Considerations**

# **Suitability of Use**

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

# **Programmable Products**

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

#### **Disclaimers**

## **Performance Data**

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

# **Change in Specifications**

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may

be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

## **Errors and Omissions**

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

# Statement of security responsibilities for assumed use cases and against threats

OMRON SHALL NOT BE RESPONSIBLE AND/OR LIABLE FOR ANY LOSS, DAMAGE, OR EXPENSES DIRECTLY OR INDIRECTLY RESULTING FROM THE INFECTION OF OMRON PRODUCTS, ANY SOFTWARE INSTALLED THEREON OR ANY COMPUTER EQUIPMENT, COMPUTER PROGRAMS, NETWORKS, DATABASES OR OTHER PROPRIETARY MATERIAL CONNECTED THERETO BY DISTRIBUTED DENIAL OF SERVICE ATTACK, COMPUTER VIRUSES, OTHER TECHNOLOGICALLY HARMFUL MATERIAL AND/OR UNAUTHORIZED ACCESS.

It shall be the users sole responsibility to determine and use adequate measures and checkpoints to satisfy the users particular requirements for (i) antivirus protection, (ii) data input and output, (iii) maintaining a means for reconstruction of lost data, (iv) preventing Omron Products and/or software installed thereon from being infected with computer viruses and (v) protecting Omron Products from unauthorized access.

# **Safety Precautions**

## **Definition of Precautionary Information**

The following notation is used in this manual to provide precautions required to ensure safe usage of the NX-series X Bus Unit.

The safety precautions that are provided are extremely important for safety. Always read and heed the information provided in all safety precautions.

The following notation is used.



Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury. Additionally, there may be severe property damage.



Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury, or property damage.

## **Symbols**



The circle and slash symbol indicates operations that you must not do.

The specific operation is shown in the circle and explained in text.

This example indicates prohibiting disassembly.



The triangle symbol indicates precautions (including warnings).

The specific operation is shown in the triangle and explained in text.

This example indicates a precaution for electric shock.



The triangle symbol indicates precautions (including warnings).

The specific operation is shown in the triangle and explained in text.

This example indicates a general precaution.



The filled circle symbol indicates operations that you must do.

The specific operation is shown in the circle and explained in text.

This example shows a general precaution for something that you must do.



The triangle symbol indicates precautions (including warnings).

The specific operation is shown in the triangle and explained in text.

This example indicates a precaution for high temperatures.

## **Warnings**

# **MARNING MARNING**

## **During Power Supply**

Do not attempt to take any Unit apart.

In particular, high-voltage parts are present in the Power Supply Unit while power is supplied or immediately after power is turned OFF. Touching any of these parts may result in electric shock. There are sharp parts inside the Unit that may cause injury.



#### **Fail-safe Measures**

The NX-series EtherNet/IP Unit will not start operation if an error is detected by the self-diagnosis at startup. External safety measures must be provided to ensure safe operation of the system in such case.



If there is interference in remote I/O communications, output status will depend on the products that are used.



Confirm the operation that will occur when there is interference in communications, and implement safety measures.

Correctly set all of the settings in the remote I/O and Units.



Unintended outputs may occur when an error occurs in variable memory. As a countermeasure for such problems, external safety measures must be provided to ensure safe operation of the system.



Provide measures in the communications system and user program to ensure safety in the overall system even if errors or malfunctions occur in data link communications.



You must take fail-safe measures to ensure safety in the event of incorrect, missing, or abnormal signals caused by broken signal lines, momentary power interruptions, or other causes.



Not doing so may result in serious accidents due to incorrect operation.

# **Security Measures**

#### **Anti-virus protection**

Install the latest commercial-quality antivirus software on the computer connected to the control system and maintain to keep the software up-to-date.



#### Security measures to prevent unauthorized access

Take the following measures to prevent unauthorized access to our products.

- Install physical controls so that only authorized personnel can access control systems and equipment.
- Reduce connections to control systems and equipment via networks to prevent access from untrusted devices.
- Install firewalls to shut down unused communications ports and limit communications hosts and isolate control systems and equipment from the IT network.
- Use a virtual private network (VPN) for remote access to control systems and equipment.
- Adopt multifactor authentication to devices with remote access to control systems and equipment.
- Set strong passwords and change them frequently.
- Scan virus to ensure safety of USB drives or other external storages before connecting them to control systems and equipment.

#### Data input and output protection

Validate backups and ranges to cope with unintentional modification of input/output data to control systems and equipment.

- · Checking the scope of data
- Checking validity of backups and preparing data for restore in case of falsification and abnormalities
- Safety design, such as emergency shutdown and fail-soft operation in case of data tampering and abnormalities



Backup data and keep the data up-to-date periodically to prepare for data loss.



When using an intranet environment through a global address, connecting to a SCADA or an unauthorized terminal such as an HMI or to an unauthorized server may result in network security issues such as spoofing and tampering. You must take sufficient measures such as restricting access to the terminal, using a terminal equipped with a secure function, and locking the installation area by yourself.



When constructing an intranet, communication failure may occur due to cable disconnection or the influence of unauthorized network equipment. Take adequate measures, such as restricting physical access to network devices, by means such as locking the installation area.



When using a device equipped with the SD Memory Card function, there is a security risk that a third party may acquire, alter, or replace the files and data in the removable media by removing the removable media or unmounting the removable media. Please take sufficient measures, such as restricting physical access to the Controller or taking appropriate management measures for removable media, by means of locking the installation area, entrance management, etc., by yourself.





# **Precautions for Safe Use**

# **Transporting and Disassembly**

- Do not attempt to disassemble, repair, or modify any Units. Doing so may result in malfunction or fire.
- Do not drop any Unit or subject it to abnormal vibration or shock. Doing so may result in Unit malfunction or burning.
- When transporting any Unit, use the special packing box for it. Also, do not subject the Unit to excessive vibration or shock during transportation.

# **Mounting**

- Always turn OFF the power supply before mounting the Units. If the power supply is not OFF, the Unit may result in malfunction or may be damaged.
- Do not exceed the maximum number of mountable X Bus Units in the specifications. Doing so may result in Unit malfunction or burning.

# Wiring

- Do not pull on the cables or bend the cables beyond their natural limit.
   Do not place heavy objects on top of the cables or other wiring lines.
   Doing so may break the cables.
- · Mount connectors only after checking the mounting location carefully.
- · Be sure that the communications cables are locked.

# Operation

After you change any Unit settings, carefully check the safety of the controlled system before you
restart the Unit.

# **Turning OFF the Power Supply**

- Always turn OFF the power supply to the Controller before you attempt any of the following.
  - a) Mounting or removing the NX Units, X Bus Units or CPU Units
  - b) Assembling the Units
  - c) Setting DIP switches or rotary switches
  - d) Connecting cables or wiring the system
  - e) Connecting or disconnecting the terminal blocks or connectors

The power supply circuit in the CPU Unit may continue to supply power to the Controller for a few seconds after the power supply turns OFF. The POWER indicator is lit during this time. Confirm that the POWER indicator is not lit before you perform any of the above actions.

 Never turn OFF the power supply to the Controller when the BUSY indicator of the NX-series Ether-Net/IP Unit is flashing. While the BUSY indicator is flashing, the settings in the NX-series

- EtherNet/IP Unit are being backed up in the built-in non-volatile memory. This data will not be backed up correctly if the power supply is turned OFF. Also, a minor fault level Controller error will occur the next time you start operation, and the NX-series EtherNet/IP Unit will stop the operation.
- Do not disconnect the cable or turn OFF the power supply to the Controller while transferring the settings of the NX-series EtherNet/IP Unit from the Support Software.

## **General Communications**

- In the data link communications, create a user program that uses receive data only when there is no current error in the data link originator device with reference to the EIP\_Comm1Status.TargetNodeErr[255] (CIP Communications1 Target Node Error Information) or EIP\_Comm2Status.TargetNodeErr[255](CIP Communications2 Target Node Error Information). If there is an error in the source device, the data for the data link may contain incorrect values.
- Before you start the communications of data that is required to operate the equipment, confirm that the data reached the proper destination after you set the IP Address.
- Unexpected operation may result if inappropriate data link tables are set. Even if appropriate data link tables have been set, confirm that the controlled system will not be adversely affected before you transfer the data link tables. The data links start automatically after the data link tables are transferred.

## **EtherNet/IP Communications**

- Make sure that the communications distance, number of nodes connected, and method of connection for EtherNet/IP are within specifications. Do not connect EtherNet/IP communications to EtherCAT or other networks. An overload may cause the network to fail or malfunction.
- All related EtherNet/IP nodes are reset when you transfer settings for the NX-series EtherNet/IP Unit (including IP addresses and tag data links settings). The settings can only be enabled after the reset. Confirm that the system will not be adversely affected by resetting nodes before you transfer the settings.
- Confirm that the system will not be adversely affected before you start the tag data link communica-
- Confirm that the system will not be adversely affected before you stop the tag data link communications.
- Confirm that the system will not be adversely affected by resetting nodes before you transfer the tag
  data link settings and routing tables.
- To ensure tag set concurrency, match the settings of the *task that updates a tag set on the X Bus* with the refreshing task for variables.
- If EtherNet/IP tag data links (cyclic communications) are used with a repeating hub, the communications load on the network will increase. This will increase collisions and may prevent stable communications. Do not use repeating hubs on networks where tag data links are used. Use an Ethernet switch instead.

# **Restoring Data**

• You cannot back up, restore, or compare data for disabled Units. After you restore data, sufficiently confirm that operation is correct before you start actual operation.

# Unit Replacement

• Make sure to transfer the tag data link settings and routing tables before restarting operation after you replaced the NX-series EtherNet/IP Unit.

# **Precautions for Correct Use**

# Storage and Installation

- Follow the instructions in this manual to correctly perform installation.
- Do not operate or store the Controller in the following locations. Doing so may result in burning, in operation stopping, or in malfunction.
  - a) Locations subject to direct sunlight
  - b) Locations subject to temperatures or humidity outside the range specified in the specifications
  - c) Locations subject to condensation as the result of severe changes in temperature
  - d) Locations subject to corrosive or flammable gases
  - e) Locations subject to dust (especially iron dust) or salts
  - f) Locations subject to exposure to water, oil, or chemicals
  - g) Locations subject to shock or vibration
- Take appropriate and sufficient countermeasures when installing the Controller in the following locations.
  - a) Locations subject to strong, high-frequency noise
  - b) Locations subject to static electricity or other forms of noise
  - c) Locations subject to strong electromagnetic fields
  - d) Locations subject to possible exposure to radioactivity
  - e) Locations close to power lines
- Before touching a Unit, be sure to first touch a grounded metallic object in order to discharge any static build-up.
- Install the Controller away from sources of heat and ensure proper ventilation. Not doing so may result in malfunction, in operation stopping, or in burning.

# **Mounting**

- When you install the Unit, be careful not to touch or bump the pins in the X Bus connector.
- When you handle the Unit, be careful not to apply stress to the pins in the X Bus connector. If the Unit is installed and the power supply is turned ON when the pins in the X Bus connector are deformed, contact failure may cause malfunctions.
- Attach a cover to the left end of the X Bus Unit to prevent entry of foreign objects. Signal short-circuit or contact failure may cause malfunctions.
- If you use DIN Track Insulation Spacers to install a CPU Rack, the height will be increased by approximately 10 mm. Make sure that the CPU Rack and connecting cables do not come into contact with other devices.

# Wiring

 Do not allow wire clippings, shavings, or other foreign material to enter any Unit. Otherwise, Unit burning, failure, or malfunction may occur. Cover the Units or take other suitable countermeasures, especially during wiring work.

# **Security Measures**

- If you forget your user name or password, go online with administrator privileges and check your user authentication settings.
  - If you forget the user name or password for administrator privileges, start the CPU Unit in Safe Mode and connect the Sysmac Studio online to perform the Clear All Memory operation following **If you cannot log in** in the Authentication in Safe Mode Dialog Box.
  - Refer to the *NX-series NX502 CPU Unit Hardware User's Manual (Cat. No. W629)* for how to start the CPU Unit in Safe Mode.
- If you cannot go online with the Sysmac Studio because of forgetting the registered IP Address for Packet Filter settings, connect from the built-in EtherNet/IP port of the CPU Unit. Refer to Troubleshooting When You Cannot Go Online from the Sysmac Studio in the NJ/NX-series Troubleshooting Manual (Cat. No. W503) for details.

# **Disposal**

- When disposing of or transferring our products, information such as user data stored in the device
  may be seen by third parties, resulting in information leakage. It is recommended that you erase the
  data on your responsibility before disposing of or transferring the device. Omron shall not be liable
  for any loss, damage, or other expenses incurred directly or indirectly in the event of any information
  leakage due to disposal or transfer.
  - For details on *complete data erasure function* for completely erasing user data, refer to the *NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501)*.

# **Regulations and Standards**

Refer to the following manuals for regulations and standards.

• NX-series NX502 CPU Unit Hardware User's Manual (Cat. No. W629)

# **Unit Versions**


This section describes the notations of unit version and how to check them.

## **Unit Versions**

The unit version is the modification number of the Unit. Even when two Units have the same model number, they will have some functional differences if they have different unit versions.

# **Checking Unit Versions on ID Information Indications**

The unit version is given on the ID information indications on the side of the product. The ID information on an NX-series EtherNet/IP Unit is shown in the following figure.



The meanings of the ID information are shown in the following table.

Name	Function
Unit version	Shows the unit version of the Unit.
Lot number and serial	Shows the lot number and the serial number of the Unit.
number	DDMYY: Lot number, □: For use by OMRON, SSSS: Serial number
	M is 1 to 9 for January to September, X for October, Y for November, and Z for De-
	cember.
Hardware revision	Shows the hardware revision of the Unit.
MAC addresses	Shows the MAC addresses of the port 1 and port 2 on the Unit.

# **Checking with the Support Software**

Refer to the user's manual of the connected CPU Unit for how to check the unit version of the X Bus Unit.

# **Related Manuals**


The following manuals are related. Use these manuals for reference.

Manual name	Cat.No.	Model numbers	Application	Description
NX-series	W627	NX-EIP201	Learning how to use	Information on the NX-series Ether-
EtherNet/IP <sup>™</sup> Unit User's			the NX-series Ether-	Net/IP Unit is provided.
Manual			Net/IP Unit.	Information is provided on the basic
				setup, tag data links, and other fea-
				tures.
NX-series	W629	NX502-□□□□	Learning the basic	An introduction to the entire NX502
NX502 CPU Unit			specifications of the	system is provided along with the fol-
Hardware			NX502 CPU Units,	lowing information on the CPU Unit.
User's Manual			including introductory	Features and system configura-
			information, design-	tion
			ing, installation, and	Introduction
			maintenance.	Part names and functions
			Mainly hardware in-	General specifications
			formation is provid-	Installation and wiring
			ed.	Maintenance and inspection
NJ/NX-series CPU Unit	W501	NX701-□□□□	Learning how to pro-	The following information is provided
Software User's Manual		NX502-□□□□	gram and set up an	on a Controller built with an NJ/NX-
		NX102-□□□	NJ/NX-series CPU	series CPU Unit.
		NX1P2-□□□	Unit.	CPU Unit operation
		NJ501-□□□□	Mainly software in-	CPU Unit features
		NJ301-□□□□	formation is provid-	Initial settings
		NJ101-□□□□	ed.	Programming based on IEC
				61131-3 language specifications
NJ/NX-series Instructions	W502	NX701-□□□□	Learning detailed	The instructions in the instruction set
Reference Manual		NX502-□□□□	specifications on the	(IEC 61131-3 specifications) are de-
		NX102-□□□□	basic instructions of	scribed.
		NX1P2-□□□□	an NJ/NX-series	
		NJ501-□□□□ NJ301-□□□□	CPU Unit.	
		NJ101-□□□□		
NJ/NX-series CPU Unit	W507	NX701-□□□□	Learning about mo-	The settings and operation of the
Motion Control User's	VV307	NX502-□□□□	tion control settings	CPU Unit and programming con-
Manual		NX102-□□□□	and programming	cepts for motion control are descri-
Manual		NX1P2-	concepts.	bed.
		NJ501-□□□□	обпосры.	Bod.
		NJ301-□□□□		
		NJ101-□□□□		
NJ/NX-series	W508	NX701-□□□□	Learning about the	The motion control instructions are
Motion Control Instructions		NX502-□□□□	specifications of the	described.
Reference Manual		NX102-□□□□	motion control in-	
		NX1P2-□□□□	structions.	
		NJ501-□□□□		
		NJ301-□□□□		
		NJ101-□□□□		
NJ/NX-series	W505	NX701-□□□□	Using the built-in	Information on the built-in EtherCAT
CPU Unit		NX502-□□□□	EtherCAT port on an	port is provided.
Built-in EtherCAT® Port		NX102-□□□□	NJ/NX-series CPU	This manual provides an introduction
User's Manual		NX1P2-□□□□	Unit.	and provides information on the con-
		NJ501-□□□□		figuration, features, and setup.
		NJ301-□□□□		
		NJ101-□□□□		

Manual name	Cat.No.	Model numbers	Application	Description
NJ/NX-series	W506	NX701-□□□□	Using the built-in	Information on the built-in
CPU Unit		NX502-□□□□	EtherNet/IP port on	EtherNet/IP port is provided.
Built-in EtherNet/IP <sup>™</sup> Port		NX102-□□□□	an NJ/NX-series	Information is provided on the basic
User's Manual		NX1P2-□□□□	CPU Unit.	setup, tag data links, and other fea-
		NJ501-□□□□		tures.
		NJ301-□□□□		
		NJ101-□□□□		
NJ/NX-series	W588	NX701-□□□□	Using the OPC UA.	Describes the OPC UA.
CPU Unit		NX502-□□□□		
OPC UA		NX102-□□□□		
User's Manual		NJ501-1□00		
NX-series	W596	NX701-□□20	Using the FINS func-	Describes the FINS function of an
CPU Unit		NX502-□□□□	tion of an NX-series	NX-series CPU Unit.
FINS Function		NX102-□□□□	CPU Unit.	
User's Manual				
NJ/NX-series	W503	NX701-□□□□	Learning about the	Concepts on managing errors that
Troubleshooting Manual		NX502-□□□□	errors that may be	may be detected in an NJ/NX-series
		NX102-□□□□	detected in an	Controller and information on individ-
		NX1P2-□□□□	NJ/NX-series Con-	ual errors are described.
		NJ501-□□□□	troller.	
		NJ301-□□□□		
		NJ101-□□□□		
Sysmac Studio Version 1	W504	SYSMAC	Learning about the	Describes the operating procedures
Operation Manual		-SE2□□□	operating procedures	of the Sysmac Studio.
			and functions of the	
			Sysmac Studio.	
NXR-series	W619	NXR-ILM08C-EIT	Learning how to use	The hardware, setup methods, and
IO-Link Master Unit for			an NXR-series IO-	functions of the NXR-series IO-Link
EtherNet/IP <sup>™</sup>			Link Master Unit for	Master Unit for EtherNet/IP are de-
User's Manual			EtherNet/IP.	scribed.

# **Revision History**

A manual revision code appears as a suffix to the catalog number on the front and back covers of the manual.



Revision code	Date	Revised content
01	April 2023	Original production
02	June 2023	Corrected mistakes.

**Revision History** 



# **Features and System Configuration**

This section describes the features, system configuration, introduction to communications services, and Support Software of the NX-series EtherNet/IP Unit.

1-1	Features		1-2
		EtherNet/IP Features	
	1-1-2	Features of NX-series EtherNet/IP Units	1-2
1-2	Syste	em Configuration	1-6
1-3	Introduction to Communications Services		1-8
	1-3-1	CIP (Common Industrial Protocol) Communications Services	
	1-3-2	IP Routing	
	1-3-3	Packet Filter	
	1-3-4	BOOTP Client	1-11
	1-3-5	Specifying Host Names	1-11
	1-3-6	SNMP Agent	1-12
	1-3-7	LLDP	
1_4	Support Software		1-14

# 1-1 Features

The NX-series EtherNet/IP Unit has the EtherNet/IP function when mounted on the X Bus.


The EtherNet/IP and NX-series EtherNet/IP Unit have the following features.

#### 1-1-1 EtherNet/IP Features

EtherNet/IP is an industrial multi-vendor network that uses Ethernet.

The EtherNet/IP specifications are open standards managed by the ODVA (Open DeviceNet Vendor Association), just like DeviceNet.

EtherNet/IP is not just a network between Controllers. It is also used as a field network. Because EtherNet/IP uses standard Ethernet technology, various general-purpose Ethernet devices can be used in the network.



EtherNet/IP System Configuration Example

#### High-speed, High-capacity Data Exchange through Tag Data Links

The EtherNet/IP protocol supports implicit communications, which allows cyclic communications (called tag data links in this manual) with EtherNet/IP devices.

#### Tag Data Link (Cyclic Communications) Cycle Time

Tag data links (cyclic communications) operate at the cyclic period specified for each application, regardless of the number of nodes. Data is exchanged over the network at the refresh cycle set for each connection, so the communications refresh cycle will not increase even if the number of nodes is increased, i.e., the concurrency of the connection's data is maintained.

Because the refresh cycle can be set for each connection, each application can communicate at its ideal refresh cycle. For example, interprocess interlocks can be transferred at high speed, while the production commands and the status monitor information are transferred at low speed.

#### 1-1-2 Features of NX-series EtherNet/IP Units

The features of the NX-series EtherNet/IP Units are described below.

#### X Bus Connection which Enable High-speed and Large Capacity Data Transfer

The NX502 CPU Unit has a built-in X Bus, which is an internal bus capable of transferring data at higher speed and larger capacity than the NX bus. The NX-series EtherNet/IP Unit is one of the X Bus Units that are connected to the X Bus.

The X Bus connector is located on the left side of the NX502 CPU Unit. You can connect the NX-series EtherNet/IP Unit on the left side of the NX502 CPU Unit.

#### Up to Ten EtherNet/IP Networks can be Built

The NX-series EtherNet/IP Unit is equipped with two EtherNet/IP ports for EtherNet/IP communications as standard. Also, you can mount up to four Units to an NX502 CPU Unit. Therefore, including the two ports of the built-in EtherNet/IP ports on the NX502 CPU Unit, you can build up to ten EtherNet/IP networks.

The maximum of ten network segmentation enables large capacity data communications of production information, quality information, and equipment information to improve yield rates in production lines

Furthermore, flexible and safe line configurations on large-scale assembly lines are possible.



#### **Precautions for Correct Use**

The NX-series EtherNet/IP Unit uses IO refresh time to exchange data between the CPU Unit and the X Bus Unit. Calculate the approximate task execution time to check the effect on the task execution time.

#### Tag Data Links

Cyclic communications between Controllers or between a Controller and other devices are possible on an EtherNet/IP network.

High-speed data exchange can be performed through tag data links.



#### **Precautions for Correct Use**

The I/O refresh time varies depending on the number of connections for tag data link communications. Check the effect of the number of connections for tag data link communications on the task execution time.

#### CIP Message Communications

You can send CIP commands to devices on the EtherNet/IP network when required by executing CIP communications instructions in a program.

As a result, it is possible to send and receive data with the devices on the EtherNet/IP network.



#### **Additional Information**

#### **CIP (Common Industrial Protocol)**

CIP is a shared industrial protocol for the OSI application layer. The CIP is used in networks such as EtherNet/IP, CompoNet, and DeviceNet.

Data can be routed easily between networks that are based on the CIP. You can therefore easily configure a transparent network from the field device level to the host level. The CIP has the following advantages.

- Destination nodes are specified by a relative path, without fixed routing tables.
- The CIP uses the producer/consumer model. Nodes in the network are arranged on the same level and it is possible to communicate with required devices whenever it is necessary. The consumer node will receive data sent from a producer node when the connection ID in the packet indicates that the node requires the data. Because the producer can send the same data with the same characteristics in a multicast format, the time required for the transfer is fixed and not dependent on the number of consumer nodes. (Either multicast or unicast can be selected.)

#### BOOTP Client

If the built-in EtherNet/IP port is set in the BOOTP settings, the BOOTP client operates when the Controller power is turned ON, and the IP address is obtained from the BOOTP server. It is possible to set all of the IP addresses of multiple EtherNet/IP ports at the same time.

#### DNS Client for Specifying Host Names

You can directly specify IP addresses, but you can also use the host names instead of the IP addresses for SNMP managers (DNS client or hosts settings).

This will help identify the IP address automatically even after the IP addresses of relevant servers are changed due to system revisions.

- \*1. A separate DNS server is necessary when you use host names with the DNS client.
- \*2. The DNS server is specified directly using its IP address.

#### Network Management with an SNMP Manager

The SNMP agent passes internal status information from the EtherNet/IP port to network management software that uses an SNMP manager.

\*1. A separate SNMP manager is necessary for network management.

#### Complete Troubleshooting Functions

A variety of functions are provided to quickly identify and handle errors.

- · Self-diagnosis at startup
- · Event log that records the time of occurrence and other error details

#### IP Routing Function

The NX-series EtherNet/IP Unit is equipped with two EtherNet/IP ports for EtherNet/IP communications as standard, and this allows to separate the information network from the control network. In addition, the EtherNet/IP ports support the IP routing function to send IP packets to devices on other IP network segments.

\*1. In order to use the function, you must appropriately set the IP router table and default gateway settings for each device on the network according to your network configuration. For details on the settings, refer to 7-1 TCP/IP Settings Display on page 7-2.

#### CIP Safety on EtherNet/IP Compatible

Combined with the NX-SL5□□□ Safety Control Unit, you can build a system which uses CIP Safety on EtherNet/IP communications in networks between Controllers and field networks. Safety communications by CIP Safety is enabled with devices that support CIP Safety on EtherNet/IP and other Safety CPU Units.



#### **Precautions for Correct Use**


- An NX-series EtherNet/IP Unit is required to perform CIP Safety communications. The built-in EtherNet/IP port on an NX502 CPU Unit does not support the CIP Safety communications.
- CIP Safety communications and tag data links cannot be used together in one NX-series EtherNet/IP Unit.
- The I/O refresh time varies depending on the number of connections for CIP Safety communications. Check the effect of the number of connections for CIP Safety communications on the task execution time.

#### LLDP

The LLDP (Link Layer Discovery Protocol) enables to exchange information with other network devices that are connected to a physically communicable range.

## 1-2 System Configuration

The following figure shows a configuration example for a system that uses the NX-series EtherNet/IP Unit.



The following table shows the description, NX502 CPU Unit connection method, and quantity for each configuration element in the figure above.

Configura- tion element	Description	NX502 CPU Unit connection meth- od	Qty
NX502 CPU Unit	A CPU Unit to which the NX-series EtherNet/IP Unit is connected. This Unit performs machine control and process control of the system.		One Unit for machine control, and one Unit for overall process control
NX-series EtherNet/IP Unit	One of X Bus Units which performs EtherNet/IP communications.	X Bus	Up to four Units per an NX502 CPU Unit
NX I/O Unit	An interface Unit to connect an NX-series CPU Unit to control devices such as sensors and actuators. This Unit can also be connected to an NX-series Communications Coupler Unit.	NX bus of CPU Unit and Slave Terminal	Zero to multiple Units (depends on applica- tion)
Safety CPU Unit	A CPU Unit which controls the safety circuit of manufacturing equipment. This Unit controls both of the safety control within equipment by FSoE and the line safety control by CIP Safety.	NX bus of CPU Unit	One Unit per an NX502 CPU Unit

Configura- tion element	Description	NX502 CPU Unit connection method	Qty
FSoE I/O Unit	This Unit inputs safety input signals and outputs safety output signals in combination with a Safety CPU Unit.	NX bus of CPU Unit and Slave Terminal	Zero to multiple Units (depends on application)
Servo Drive	A control device for an electric motor assembled in a control equipment. It is controlled by the Motion Control Function Module within the CPU Unit.	Built-in EtherCAT port	Zero to multiple Units (depends on applica- tion)
EtherCAT general-pur- pose slave	A general-purpose slave connected to the EtherCAT.	Built-in EtherCAT port	Zero to multiple Units (depends on application)
Ethernet switch	An Ethernet switch connects devices on the network by packet switching and transfers the received data to the target device.	EtherNet/IP port on CPU Unit and NX- series EtherNet/IP Unit	Zero to multiple Units (depends on applica- tion)
НМІ	An HMI performs operation input to the manufacturing equipment and displays status of the manufacturing equipment.	EtherNet/IP port on CPU Unit and NX- series EtherNet/IP Unit	Zero to multiple Units (depends on applica- tion)
Sysmac Studio Network Configurator	Support Software for NX502 CPU Unit.	EtherNet/IP port on CPU Unit and NX- series EtherNet/IP Unit	One to multiple Units (depends on application)
HOST PC	This computer performs EtherNet/IP communications.	EtherNet/IP port on CPU Unit and NX- series EtherNet/IP Unit	One to multiple Units (depends on application)
RFID system	This system uses electromagnetic fields and radio waves to exchange product identification information. Communications is performed with a Modbus/TCP client.	EtherNet/IP port on CPU Unit and NX- series EtherNet/IP Unit	Zero to multiple Units (depends on applica- tion)
CIP Safety I/O	A connection interface for sensors and actuators of safety I/O devices. CIP Safety on Ether-Net/IP compatible.	EtherNet/IP port on NX-series EtherNet/IP Unit	Zero to multiple Units (depends on application)

## 1-3 Introduction to Communications Services

This section provides an introduction to the communications services of the NX-series EtherNet/IP

#### 1-3-1 CIP (Common Industrial Protocol) Communications Services

The services using CIP include tag data link and CIP message communications.

#### **Tag Data Links (Cyclic Communications)**

A program is not required to perform cyclic data exchanges with other devices on the EtherNet/IP network.

Normally, a connection is started with the target device for each tag set that was created with the Network Configurator to start communications for tag data links for an EtherNet/IP port. One connection is used per tag set.

The maximum number of connections that can be registered is 256, or a total of 512 with two ports.




#### **Additional Information**

The NX502 CPU Unit can be used with the NX-EIP201 (EherNet/IP Unit) for tag data link communications.

However, check the effect on task execution time because it increases I/O refreshing time.

Refer to 2-1 Specifications on page 2-2 for the EtherNet/IP port tag and tag set specifications.




**Note** In this example, a connection is established with the originator's tag list with tags a to g (inputs), which are in a tag set called *SP1\_IN*, and the target's tag list with tags i and ii (outputs), which are in a tag set called *SP1\_OUT*.

#### **CIP Message Communications**

User-specified CIP commands can be sent to devices on the EtherNet/IP network.


CIP commands can be sent and their responses received by executing the CIP communications instructions from the user program in the CPU Unit.



By specifying a route path, you can send CIP messages (CIP commands and responses) to a device on another CIP-based network segment (CIP routing function for message communications). However, since the starting point of route path is the CPU Unit, it is necessary to set the route path from the CPU Unit through the NX-series EtherNet/IP Unit.

The maximum number of levels of CIP routing via the ports is eight for any combination of CS, CJ, NJ, and NX-series CPU Units. Note that the number of levels of IP routing using an L3 Ethernet switch is not counted in the number of levels of CIP routing via the ports.

 Because there are two EtherNet/IP ports, CIP routing is possible by the NX-series EtherNet/IP Unit alone.





#### **Additional Information**

In CIP routing, a node (Unit) that routes information subtracts the equivalent of one hop from the timeout, deletes its own address from the route information, and relays the information to the next node (Unit).

When a timeout is specified, the timeout for the actual request service processing is set in the last hop.

In the case of relay hops, the timeout for the relay route must be added to the timeout for the request.

OMRON products that support CIP subtract 5 seconds per hop.

#### 1-3-2 IP Routing


The IP routing function sends IP packets to other network segments based on the routing information set in the IP router table.

To communicate with devices on other network segments, you must set the IP router table and default gateway settings for the CPU Unit and each device on the network appropriately for your network configuration.



#### **Precautions for Correct Use**

You cannot create tag data links between multiple CPU Units using IP routing.



#### Port Forward - IP Forward

This function transfers the communications data between the network for the EtherNet/IP port 1 and the network for the EtherNet/IP port 2. Select the *Use* Option for **IP Forward** to transfer the communications data. If you select the *Do not use* Option for **IP Forward**, any other IP packets than those addressed to the NX-series EtherNet/IP Unit are discarded. Refer to 7-1 **TCP/IP Settings** Display on page 7-2 for details on the settings.




CIP routing is not affected by the IP Forward setting.

#### 1-3-3 **Packet Filter**

IP packets are filtered in the receive processing at the EtherNet/IP ports. Specify packets allowed to be received by IP address or TCP/UDP port number.

#### 1-3-4 **BOOTP Client**

You set the EtherNet/IP port to the BOOTP setting to use the BOOTP client to obtain settings, such as the EtherNet/IP port IP address, from the BOOTP server.




The EtherNet/IP port IP address is obtained from the BOOTP server when the power is turned ON.

#### 1-3-5 **Specifying Host Names**

You can directly specify IP addresses, but you can also use the host names instead of the IP addresses for SNMP managers (DNS client or hosts settings).

#### **Example: Setting Host Names on the DNS Server**





#### **Precautions for Correct Use**


A DNS server is required to use the server host names for the DNS client.

#### 1-3-6 SNMP Agent

The SNMP agent has the following functions.

#### **SNMP Agent**

EtherNet/IP port internal status information is provided to network management software that uses an SNMP manager.




#### **SNMP Trap**

When specific conditions occur, the EtherNet/IP port that is set as the SNMP agent sends status notification reports to the SNMP manager.

The SNMP manager can learn about changes in status even without periodically monitoring the Ether-Net/IP port.

Status notification reports are sent under the following conditions.

- · When the Controller is turned ON
- · When links are established
- · When an SNMP agent fails to be authorized



#### 1-3-7 LLDP

LLDP (Link Layer Discovery Protocol) is a protocol used to exchange information with other network devices that are connected to a physically communicable range. The NX-series EtherNet/IP Unit obtains information of other network devices using the SNMP function. The information to be exchanged includes chassis types and system names of the both. Refer to *Lldp Group* on page 11-19 for details on the information to be exchanged.

## 1-4 Support Software

The followings are the Support Software for using the NX-series EtherNet/IP Unit.

#### Sysmac Studio

This software is used to configure all functions of the NX-series EtherNet/IP Unit.

The NX-series EtherNet/IP Unit is supported by version 1.54 or higher.

Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for details on the Sysmac Studio.

#### Network Configurator

This software is used to configure tag data links.

The NX-series EtherNet/IP Unit is supported by version 3.74 or higher.

For the details on the settings, refer to Section 9 Tag Data Link Functions on page 9-1.



# **Specifications and Application Procedures**

This section describes the specifications and application procedures of the NX-series EtherNet/IP Unit.

2-1	Spec	ifications	2-2
	2-1-1	General Specifications	2-2
	2-1-2	Performance Specifications	2-3
	2-1-3	Function Specifications	2-6
2-2	Ether	Net/IP Communications Procedures	2-7

## 2-1 Specifications

This section provides general specifications, performance specifications, and function specifications of the NX-series EtherNet/IP Unit.

#### 2-1-1 General Specifications

The general specifications of the NX-series EtherNet/IP Unit are given below.

It	em	Specification
Enclosure		Mounted in a panel
Grounding method		Ground to less than 100 $\Omega$ .
Dimensions: Height × Depth × Width		100 × 120 × 39 (mm)
Weight		350 g max.
Power consumption		8.1 W max.
Operating environment Ambient operating te perature		0 to 55°C
	Ambient operating humidity	10% to 95% (with no icing or condensation)
	Atmosphere	Must be free from corrosive gases.
	Ambient storage temperature	-25 to 70°C (with no icing or condensation)
	Altitude	2,000 m max.
	Pollution degree	2 or less: Meets IEC 61010-2-201.
	Noise immunity	2 kV on power supply line (Conforms to IEC 61000-4-4.)
	Overvoltage category	Category II: Meets IEC 61010-2-201.
	EMC immunity level	Zone B
	Vibration resistance	Conforms to IEC 60068-2-6.
		5 to 8.4 Hz with 3.5-mm amplitude,
		8.4 to 150 Hz, acceleration of 9.8 m/s <sup>2</sup>
		100 min each in X, Y, and Z directions (10 sweeps of 10 min each = 100 min total)
		Gravity acceleration is assumed to be G=9.8m/s <sup>2</sup> .
	Shock resistance	Conforms to IEC 60068-2-27, 147 m/s <sup>2</sup> , 3 times in X, Y, and Z directions.
		Gravity acceleration is assumed to be G=9.8m/s <sup>2</sup> .
	Mounting method	Mount to DIN Track
	Mounting direction	One direction (upright)
Applicable standards		Refer to the OMRON website (http://
		www.ia.omron.com/) or consult your OMRON represen-
		tative for the applicable standards.

### 2-1-2 Performance Specifications

The specifications of the NX-series EtherNet/IP Unit are given below.

	1	tem	NX-EIP201
EtherNet/IP	Number of po	rts	2
port	Physical layer		10BASE-T, 100BASE-TX, or 1000BASE-T
	Frame length		1,514 bytes max.
	Media access	method	CSMA/CD
	Modulation		Baseband
	Topology		Star
	Baud rate		1 Gbps (1000BASE-T) max.
	Transmission	media	STP (shielded, twisted-pair) cable of Ethernet
			category 5, 5e or higher
	Maximum tran	smission distance between	100 m
	Ethernet switch	ch and node	
	Maximum nun	nber of cascade connections	There are no restrictions if an Ethernet switch
			is used.
	LLDP		Supported.
	BOOTP client		Supported.
	DHCP client		Not supported.
	DNS client		Supported.
	SNMP agent, t	traps	Supported.
	CIP service: Tag data links (cyclic communica- tions)	Maximum number of con-	256 per port
		nections	512 total
		Packet interval*1*2	Can be set for each connection.
			1.0 to 10,000 ms in 1.0-ms increments
		Allowed communications	*2*4
		Allowed communications bandwidth per Unit	40,000 pps <sup>*3*4</sup> (including heartbeat)
		Maximum number of tag	256 per port
		sets	512 total
		Tag types	Network variables
			CIO, Work, Holding, DM, or EM Areas can be
			used.
		Number of tags per connec-	64 (63 tags if Controller status is included in
		tion (i.e., per tag set)	the tag set.)
		Maximum number of tags	1,024 per port
			2,048 total
		Maximum link data size per	369,664 bytes per port (total of 739,328 bytes
		node (total size for all tags)	with two ports)
		Maximum data size per con-	1,444 bytes
		nection	
		Maximum number of regis-	256 per port
		trable tag sets	512 total (1 connection = 1 tag set)
		Maximum tag set size	1,444 bytes (Two bytes are used if Controller
		Maximum tag set size	status is included in the tag set.)
		Changing tag data link pa-	<u> </u>
		rameters when Controller is	Supported*5
		in RUN mode	

Item			NX-EIP201
	Multicast pack	et filter*6	Supported.
CIP message service: Ex- plicit mes-	Class 3 (numb tions)	er of connec-	128 per port 256 total (clients plus server)
sages	UCMM (non- connection type)	Maximum number of clients that can commu- nicate at one time	32 per port 64 total
		Maximum number of servers that can commu- nicate at one time	32 per port 64 total
	CIP routing		Supported CIP routing is supported for the following remote Units: NX-EIP201 NX701-□□□, NX502-□□□, NX102-□□ □, NX1P2-□□□ NJ501-□□□, NJ301-□□□, NJ101-□□□ □, CS1W-EIP21, CJ1W-EIP21, CJ2H-CPU□□-EIP, CJ2M-CPU3□ Using a combination of any Units above, communication can be extended up to a maximum of 8 levels.
Maximum routable safety da-		84 total (originator: 80, target: 4) 32 bytes	
SNMP	ta length per c Agents MIB	onnection	SNMPv1 or SNMPv2C MIB-II
EtherNet/IP co	nformance test		Conforms to CT18.
Ethernet interf			10BASE-T, 100BASE-TX, or 1000BASE-T Auto negotiation

- \*1. Data will be refreshed at the set interval, regardless of the number of nodes.
- \*2. The approximate I/O response time of the tag data link is determined by the relationship between the packet interval and the number of connections. Refer to 12-3 Tag Data Link I/O Response Time on page 12-23 for details.
- \*3. "pps" means packets per second, i.e., the number of communications packets that can be sent or received in one second.
- \*4. When the Unit is performing tag data link communications where the allowable communications bandwidth per Unit is close to or greater than 30,000 pps, the following functions may not be used properly. In that case, use the built-in EtherNet/IP port on the CPU Unit or an EtherNet/IP port of a different NX-series EtherNet/IP Unit.
  - Connecting the Sysmac Studio online from the EtherNet/IP port of the NX-series EtherNet/IP Unit
  - · Connecting the Network Configurator online from the EtherNet/IP port of the NX-series EtherNet/IP Unit
  - Connecting the NA-series Programmable Terminal online from the EtherNet/IP port of the NX-series EtherNet/IP Unit

- · Port forward via the NX-series EtherNet/IP Unit
- · CIP message communications
- SNMP function

These functions of the NX-series EtherNet/IP Unit can be used via X Bus from the built-in EtherNet/IP port on the CPU Unit or an EtherNet/IP port of a different NX-series EtherNet/IP Unit.

- \*5. If the parameters of the EtherNet/IP port are changed, the port is restarted. When other nodes are in communications with the affected node, the communications will temporarily time out and automatically recover after the restart.
- \*6. As the EtherNet/IP port implements the IGMP client, unnecessary multi-cast packets can be filtered by using an Ethernet switch that supports IGMP Snooping.
- \*7. CIP Safety communications and tag data links cannot be used together in one NX-series EtherNet/IP Unit.

### 2-1-3 Function Specifications

The function specifications of the NX-series EtherNet/IP Unit are given below.

		Item		NX-EIP201
Communica- tions			TCP/IP or UDP/IP	
		CIP communications services	Tag data links	Programless cyclic data exchange is performed with the devices on the EtherNet/IP network.
			Message Com- munications	CIP commands are sent to or received from the devices on the EtherNet/IP network.
		TCP/IP application	SNMP agent	EtherNet/IP port internal status information is provided to network management software that uses an SNMP manager.
System	Event logs	Function		Events are recorded in the logs.
manage- ment		Maximum number of events	System event log	1,024
			Access event log	512
			User-defined event log	None

# 2-2 EtherNet/IP Communications Procedures

#### Basic Operation

1 Wire the Ethernet network with twisted-pair cable.

Section 5 Installing Ethernet Networks on page 5-1

2 Set the EtherNet/IP port IP address with the Sysmac Studio.

8-1 Determining IP Addresses on page 8-2

- 1. Use the Sysmac Studio to create a new project.
- 2. Set the local IP address in one of the following ways:
- · Defaults:

Port	Default IP address The subnet mask is 255.255.255.0 for all ports.	
Port 1	192.168.250.1	
Port 2	192.168.251.1	

- Set any IP address.
- · Obtain from the BOOTP server.

**3** Perform a communications test with a PING command from a computer.

8-3 Testing Communications on page 8-13

**4** Use the Sysmac Studio to set the initial settings of the Ether-Net/IP Function Module.

Section 7 Sysmac Studio Settings for the EtherNet/IP Port on page 7-1

• Set the TCP/IP settings and Ethernet settings as required.

#### Using Tag Data Links

1 Import the variable settings for the tags that were created on the Sysmac Studio to the Network Configurator.

9-2-4 Creating Tags and Tag Sets on page 9-19

2 Use the Network Configurator to create the tag data link table.

Section 9 Tag Data Link Functions on page 9-1

- · Create the network configuration.
- · Set the tags, tag sets, and connections.

3 Connect the Network Configurator online.

4 Download the tag data link setting.

5 Start the tag data links (the links starts automatically when power is turned ON).

6 Check operation.

Section 3 Part Names and Functions on page 3-1 Section 14 Troubleshooting on page 14-1

- Check the EtherNet/IP port indicators.
- Use the Sysmac Studio to check the communications status with the All Tag Data Link Communications Status device variable
- Use the monitor function of the Network Configurator to confirm that the tag data links are in normal operation.

#### Using the Message Communications Service

· CIP Communications Instructions

1 Execute CIP communications instructions in the user program.

 $\downarrow$ 

Section 10 CIP Message Communications on page 10-1

2 Check operation.

Section 3 Part Names and Functions on page 3-1 Section 14 Troubleshooting on page 14-1

 Use the Sysmac Studio to check the communications status with the end codes of the instructions (Done, Err, and ErrID).

#### Using the SNMP Agent

1 Use the Sysmac Studio to set the initial settings of the Ether-Net/IP Function Module. Section 11 SNMP Agent on page 11-1

- · Set the SNMP settings.
- · Set the SNMP trap settings.

2 Check operation.

· Check the event log to see if the SNMP agent started.

#### Using the BOOTP

1 Use the Sysmac Studio to set the initial settings of the Ether-Net/IP Function Module.

Section 7 Sysmac Studio Settings for the EtherNet/IP Port on page 7-1

· Set the BOOTP settings.

2 Check operation.

- Check the event log to see if the BOOTP started.
- · Check the Online device variable.




## **Part Names and Functions**

This section describes part names and functions of the NX-series EtherNet/IP Unit.

3-1	Part I	Names	3-2
		Functions	
		Operation Status Indicators	
	3-2-2	DIP Switch	3-4

## 3-1 Part Names

The following table gives the name of each part of the NX-series EtherNet/IP Unit.




Symbol	Name	Function
Α	X Bus connectors	These connectors are used to connect another Unit.
В	DIN Track mounting hook	This hook is used to mount the Unit to a DIN Track.
С	Unit hookup guides	These guides are used to connect two Units.
D	Operation status indica-	The indicators show the current operating status of the Unit.
	tors	
Е	EtherNet/IP ports	The communications ports for EtherNet/IP connection. There are two
		ports.
F	DIP switch	This switch is for configuring internal settings of the Unit, but not used
		normally. Always keep all pins from SW1 to SW4 in OFF state.
G	Unit specifications	The specifications of the Unit are given here.

### 3-2 Part Functions

#### 3-2-1 Operation Status Indicators

The operation status indicators include the Unit status indicators which display the operating status of the NX-series EtherNet/IP Unit and the EtherNet/IP (Port 1/Port 2) status indicators which display the status of EtherNet/IP ports.

The specifications of both instructions are given in the following table.



#### **Unit Status Indicators**

Indicator	Color	Indicator sta- tus	Status of NX-series EtherNet/IP Unit	
RUN	Green	Lit	Power is ON.	
		Flashing	A System Initialization Error occurred.	
		Not lit	Power is OFF, or a Power Supply Error, a Hardware Initialization Error, an X Bus Unit Hardware Error, or an error for which the user cannot recover operation occurred in the Unit.	
ERR	Red	Lit	An error for which the user cannot recover operation occurred in the Unit.	
		Flashing	An error for which the user can recover operation occurred in the Unit.	
		Not lit	An error not occurred in the Unit.	
BUSY	Yellow	Flashing	Built-in non-volatile memory access in progress.	
		Not lit	Other than the above.	

#### EtherNet/IP (Port 1/Port 2) Status Indicators

Indicator	Color	Indicator status	Status of EtherNet/IP port
NET RUN	Green	Lit	Normal
		Flashing	Ethernet communications are in progress.
		Not lit	Ethernet communications are not possible.

Indicator	Color	Indicator status	Status of EtherNet/IP port	
NET ERR	Red	Lit	An error for which the user cannot recover operation occurred.	
		Flashing	An error for which the user can recover operation occurred.	
		Not lit	There are no Ethernet communications errors.	
			The power supply is OFF or the Unit was reset.	
LINK/ACT	Yellow	Lit	The link was established.	
		Flashing	The link is established, and data communications are in progress.	
		Not lit	A link was not established.	
			The cable is not connected.	
			The power supply is OFF or the Unit was reset.	

#### 3-2-2 DIP Switch

Do not use the DIP switch. Always keep all pins from SW1 to SW4 in OFF state.



## Mounting

This section describes how to mount the NX-series EtherNet/IP Unit.

4-1 Mounting and Removing NX-series EtherNet/IP Units ......4-2

# 4-1 Mounting and Removing NX-series EtherNet/IP Units

Refer to *Mounting and Removing Units* in the *NX-series NX502 CPU Unit Hardware User's Manual (Cat. No. W629)* for how to mount and remove the NX-series EtherNet/IP Unit.

## **Installing Ethernet Networks**

5-1	Selec	ting the Network Devices	5-2
	5-1-1	Recommended Network Devices	
	5-1-2	Ethernet Switch Types	
	5-1-3	Ethernet Switch Functions	
	5-1-4	Precautions for Ethernet Switch Selection	5-4
5-2	Netw	ork Installation	5-7
	5-2-1	Basic Installation Precautions	5-7
	5-2-2	Recommended Network Devices	5-7
	5-2-3	Precautions When Laying Twisted-pair Cable	5-7
	5-2-4	Precautions When Installing and Connecting Ethernet Switches	
5-3	Conn	ecting to the Network	5-13
	5-3-1	Ethernet Connectors	
	5-3-2	Connecting the Cable	

## 5-1 Selecting the Network Devices

#### 5-1-1 Recommended Network Devices

The following table shows the devices recommended for use with the EtherNet/IP.

#### Ethernet Switches

Manufacturer	Model	Description		
OMRON	W4S1-05D	Packet priority control (QoS): EtherNet/IP control data priority		
		Ethernet standard: IEEE 802.3 10Base-T, 100Base-TX		
		Auto-negotiation: Supported		
		Broadcast storm control: Supported		
		Number of ports: 5		
Cisco Systems,	Consult the manufacturer.			
Inc.	http://www.cisco.com/			
Contec USA,	Consult the manufacturer.			
Inc.	http://www.contec.com/			
Phoenix Con-	Consult the manufacturer.			
tact USA	https://www.phoenixcontact.com			

#### Twisted-pair Cables and Connectors

Applicable EtherNet/IP communications cables and connectors vary depending on the used baud rate.

For 100Base-TX and 10Base-T, use an STP (shielded twisted-pair) cable of category 5 or higher. You can use either straight or cross cable.

For 1000Base-T, use an STP (shielded twisted-pair) cable (double shielding with aluminum tape and braiding) of category 5e or higher. You can use either straight or cross cable.

Cabling materials used for EtherNet/IP communication cables are shown in the table below. "100Base-TX" in the "Product" column of the table below indicates that either 100Base-TX or 10Base-T can be used.

Product			Manufacturer	Model
For 1000Base-T	Size and con-	Cable	Hitachi Metals, Ltd.	NETSTAR-C5E
and 100Base-	ductor pairs:			SAB 0.5 × 4P CP
TX	AWG24 × 4 pairs		Kuramo Electric Co.	KETH-SB
			JMACS Japan Co., Ltd.	IETP-SB
	*1	RJ45 Connec-	Panduit Corporation	MPS588
		tors		
For 100Base-	Size and con-	Cable	Kuramo Electric Co., Ltd.	KETH-PSB-OMR
TX	ductor pairs: AWG22 × 2 pairs*1		JMACS Japan Co., Ltd.	PNET/B
		RJ45 Assembly	OMRON	XS6G-T421-1
		Connectors		

<sup>\*1.</sup> We recommend that you use cables and connectors in above combinations.

#### 5-1-2 Ethernet Switch Types

#### Unmanaged Layer 2 (L2) Ethernet Switches

These Ethernet switches use the Ethernet MAC address to switch ports. Ordinary Ethernet switches have this function. Ethernet switch functions and settings cannot be changed.

#### Managed Layer 2 (L2) Ethernet Switches

These Ethernet switches use the Ethernet MAC address to switch ports. Ethernet switch functions and settings can be changed with special software tools for Ethernet switches running on a network node. You can also collect analytical data. These Ethernet switches provide more-advanced functions than unmanaged layer 2 Ethernet switches.

#### 5-1-3 Ethernet Switch Functions

This section describes the Ethernet switch functions that are important for an EtherNet/IP network. For an EtherNet/IP port, consider whether the Ethernet switch supports the following two functions when you select the Ethernet switch.

- · Multicast filtering
- QoS (Quality of Service) for TCP/UDP port numbers (L4)

#### Multicast Filtering

Multicast filtering transfers multicast packets to the specific nodes only. This function is implemented in the Ethernet switch as IGMP snooping or GMRP.

"Specific nodes" are nodes equipped with an IGMP client, and have made transfer requests to the Ethernet switch. (OMRON EtherNet/IP ports are equipped with an IGMP client.) When the Ethernet switch does not use multicast filtering, multicast packets are sent to all nodes, just like broadcast packets, which increases the traffic in the network.

Settings must be made in the Ethernet switch to enable this function. There must be enough multicast filters for the network.

#### QoS (Quality of Service) Function for TCP/UDP Port Numbers (L4)

This function controls the priority of packet transmissions so that packets can be sent with higher priority to a specific IP address or TCP (UDP) port. The TCP and UDP protocols are called transport layer protocols, leading to the name L4 (layer 4) QoS function.

When tag data links and message communications are executed on the same network, tag data links can be sent at higher priority to prevent problems such as transmission delays due to message communications traffic and packet losses due to buffer overflow.

Also, when tag data links and CIP Safety communications are executed on the same network, it is possible to reduce the impact of tag data link traffic by increasing the priority of CIP Safety communications with QoS settings.

Refer to 7-5 CIP Settings Display on page 7-15 for details on the QoS settings.

Settings must be made in the Ethernet switch to enable QoS function and give higher priority to tag data link packets.

These functions are supported by Ethernet switches as described in the table below.

Ethernet switch type	Multicast filtering	L4 QoS	Remarks
Unmanaged L2 Ethernet switch	Not supported	Not sup- ported	
Managed L2 Ethernet switch	Supported	Supported	Both functions must be set with a special software tool.
OMRON Ethernet switch (W4S1-series Ethernet switches)	Not supported	Supported	L4 QoS is set with a switch. No software tool is necessary. *1

Even QoS settings are made, tag data links and CIP Safety communications are processed with the same priority.



#### **Additional Information**

 If you select Multi-cast Connection for the connection type in the connection settings on the Network Configurator, multicast packets are used. If the connection type is set to a Point to Point Connection, multicast packets are not used.

#### 5-1-4 Precautions for Ethernet Switch Selection

The functions supported by the Ethernet switch may affect tag data link transmission delays and the settings in the Controller configurations and setup.

In addition, if the Ethernet switch supports advanced functions, special settings are required for the functions.

When you select an Ethernet switch, it is necessary to consider what kind of data transmission and how much traffic you use over the the network.

Refer to the following precautions when you select an Ethernet switch.

Refer to 12-2 Adjusting the Communications Load on page 12-7 to estimate the communications load for tag data links.

#### Selecting the Ethernet Switch Based on the Type of Network Communications

#### Executing Tag Data Links Only

We recommend that you use an L2 Ethernet switch without multicast filtering or an L2 Ethernet switch with multicast filtering.

An L2 Ethernet switch with multicast filtering prevents increased traffic due to unnecessary multicast packets, so the tag data links can operate at higher speed.

If either of the following conditions exists, there is no difference in the traffic condition whether multicast filtering is supported or not.

- The tag data links are set to share the same data with all nodes in the network. (Multicast packets are transferred to all nodes in the network, just like broadcast transmission.)
- The tag data link settings are all one-to-one (unicast) and multicast packets are not used. When multicast filtering is used, settings must be made accordingly on the Ethernet switch. There must be enough multicast filters for the network.

#### Executing Tag Data Links and Message Communications

We recommend an L2 Ethernet switch with multicast filtering and L4 QoS.

If you set tag data links for higher-priority transmission, it is possible to prevent problems such as transmission delays due to message communications traffic and packet losses due to buffer overflow.

Refer to 7-5 CIP Settings Display on page 7-15 for details on the QoS settings.

When multicast filtering and L4 QoS are used, settings must be made accordingly on the Ethernet switch.

#### Executing Tag Data Links and CIP Safety Communications

We recommend an L2 Ethernet switch with multicast filtering and L4 QoS.

If you set CIP Safety packets for higher-priority transmission, it is possible to reduce the impact from problems such as transmission delays due to tag data link communications traffic and packet losses due to buffer overflow.

When L4 QoS is used, settings must be made accordingly in the QoS configuration on the Sysmac Studio and on the Ethernet switch. Refer to 7-5 *CIP Settings Display* on page 7-15 for details on configuring QoS on the Sysmac Studio.

## Selecting the Ethernet Switch Based on the Ethernet Switch's Supported Functions

#### L2 Ethernet Switch without Multicast Filtering

We recommend this kind of Ethernet switch when only tag data links are executed and any of the following conditions is met.

- The tag data links are set to share the same data with all nodes in the network. (Multicast packets are transferred to all nodes in the network, just like broadcast transmission.)
- The tag data link settings are all one-to-one (unicast) and multicast packets are not used.
- · There is little traffic in the tag data links.

No special settings are required for an L2 Ethernet switch without multicast filtering.

#### L2 Ethernet Switch with Multicast Filtering

We recommend this kind of Ethernet switch when only tag data links are executed and the following condition is met.

There are many 1:N links (where N represents some number of nodes in the network) in the tag
data link settings, i.e., there are many multicast packets used, or there is heavy traffic in the tag
data links

Specific settings are required for an L2 Ethernet switch with multicast filtering. There must be enough multicast filters for the network.

#### L3 Ethernet Switch with Multicast Filtering and L4 QoS Functions

We recommend this kind of Ethernet switch when both tag data links and message communications are executed.

If you set tag data links for higher-priority transmission, you can prevent problems such as transmission delays due to message communications traffic and packet losses due to buffer overflow. When multicast filtering and L4 QoS are used, settings must be made accordingly on the Ethernet switch. There must be enough multicast filters for the network.

## Selecting the Ethernet Switch Based on the Network Communication Speed

#### Executing Tag Data Links at a Baud Rate Over 100 Mbps

If you use data tag links with the following conditions, use an Ethernet switch with multicast filtering or an Ethernet switch that supports a baud rate of 1,000 Mbps.

- Multicast
- · Baud rate over 100 Mbps

If there is an Ethernet device on the same network that communicates at a speed of 100 Mbps or less, the device may affect tag data link communications and cause tag data links to be broken, even if the device is not related to tag data link communications.



#### **Precautions for Correct Use**

- · Ask the Ethernet switch manufacturer for setting procedures for the Ethernet switch.
- Install the Ethernet switch based on its environmental resistance specifications so that the
  environmental resistance specifications are fully met. Ask the Ethernet switch manufacturer
  for information on the environmental resistance of the Ethernet switch.

### 5-2 Network Installation

#### 5-2-1 Basic Installation Precautions

- Take the greatest care when you install the Ethernet System. Be sure to follow ISO 8802-3 specifications. Be sure you understand them before attempting to install an Ethernet System.
- Unless you are already experienced in installation of communications systems, we strongly recommend that you employ a professional to install your system.
- Do not install Ethernet equipment near sources of noise.
   If a noisy environment is unavoidable, take adequate measures against noise interference, such as installation of network components in metal cases or the use of optical cable in the system.
- When using a shielded cable with the shields on both ends of the cable connected to connector hoods, ground loops induced by improper grounding methods may decrease noise immunity and cause device damage. To prevent ground loops caused by differences in potential between device grounding points, the reference potential between the devices must be stabilized. Design grounding appropriately so that noise current does not flow to ground lines between the devices. For grounding methods, refer to the NX-series NX502 CPU Unit Hardware User's Manual (Cat. No. W629).
- To obtain information on installing EtherNet/IP cable, contact ODVA.
   ODVA web site: http://www.odva.org
- When you install an EtherNet/IP network that combines an information network with the control system, and the communications load may be heavy due to tag data links, we recommend that you set up a network where the load does not affect communications. For example, install the tag data links in a segment that is separate from the information network.

#### 5-2-2 Recommended Network Devices

Refer to 5-1 Selecting the Network Devices on page 5-2 for the devices recommended for use with the EtherNet/IP port.

#### 5-2-3 Precautions When Laying Twisted-pair Cable

#### **Connecting the Shield to Connector Hoods**

#### • Between an EtherNet/IP Port and an Ethernet Switch


Connect the shield to connector hoods as described below.

Communications standard	Connection
10Base-T	Connect the shield at both ends
100Base-TX	or
	Connect the shield only at the Ethernet switch side. A clamp core must be attach-
	ed to the EtherNet/IP port side of the cable.
1000Base-T	Connect the shield at both ends

10Base-T or 100Base-TX

Connect the cable shields to the connector hoods as described in either (1) or (2) below.


Connecting the shields at both ends of the cable
 Connect the shields to the connector hoods at both ends of the cables.



Connecting the shields only at the Ethernet switch sideConnect the shields to the connector hoods only at the Ethernet switch side.

A clamp core must be attached to the end of the cable at the EtherNet/IP port side. For a recommended clamp core and attachment methods, refer to *Recommended Clamp Core and Attachment Method* on page 5-10.

To comply with EMC standards, it is mandatory that a clamp core be attached when connecting the shield to the connector hood only at the Ethernet switch side.






#### **Additional Information**

Noise immunity may be reduced and device damage may occur due to ground loops, which may be caused by improper shield connections and grounding methods. When using a baud rate of 100 Mbps or less, it may be possible to alleviate this problem by connecting the shield only at the Ethernet switch side as described in (2), rather than connecting both ends as described in (1).

#### • 1000Base-T

Connect the shields to respective connector hoods at both ends of the cables.

This connection is required for 1000Base-T to ensure compliance with EMC standards.



#### Between Two Ethernet Switches

Regardless of which baud rate is used, check with the Ethernet switch manufacturers for information about installing the network between Ethernet switches, and in particular whether or not it is necessary to connect the cable shields to the connector hoods.

#### Other Precautions When Laying the Twisted-pair Cable

- Firmly insert the connector until it locks into place when you connect the cable to the Ethernet switch and the EtherNet/IP port.
- Do not install the twisted-pair cable together with high-voltage lines.
- Do not install the twisted-pair cable near devices that generate noise.
- · Do not install the twisted-pair cable in locations subject to high temperatures or high humidity.
- Do not install the twisted-pair cable in locations subject to excessive dirt, dust, oil mist or other contaminants.

#### Recommended Clamp Core and Attachment Method


When you connect the cable shield only with the connector hood of the Ethernet switch, you need to attach a clamp core to the EtherNet/IP port.


The recommended clamp core and attachment method are given below.

#### Recommended Clamp Core

Manufacturer	Product	Model
NEC TOKIN	Clamp core	ESD-SR-250


**ESD-SR-250** dimensions






#### Recommended Attachment Method

· Attach a clamp core to the communications cable as shown below.



Make two loops with the cable as shown.

· Connect the communications cable as shown below.



Attach close to the cable connection as shown.


#### 5-2-4 Precautions When Installing and Connecting Ethernet Switches

#### **Precautions When Installing Ethernet Switches**

- Do not ground the Ethernet switch in the same location as a drive-system component, such as an inverter.
- Always use a dedicated power supply for the Ethernet switch. Do not use the same power supply for other equipment, such as an I/O power supply, motor power supply, or control power supply.
- Before installation, check the Ethernet switch's environmental resistance specifications, and use an
  Ethernet switch that is appropriate for the ambient conditions. Contact the Ethernet switch manufacturer for details on Ethernet switch's environmental resistance specifications.

#### **Ethernet Switch Connection Methods**

Connect Ethernet switches with twisted-pair cables, as follows: Connect an MDI port to an MDI-X port with a straight cable. Connect two MDI ports or two MDI-X ports with a cross cable.
 Note It is very difficult to distinguish cross cables and straight cables by appearance. Incorrect cables will cause communications to fail. We recommend cascade connections with straight cables wherever possible.



• Some Ethernet switches can automatically distinguish between MDI and MDI-X. When this kind of Ethernet switch is used, straight cable can be used between Ethernet switches.



#### **Precautions for Correct Use**

EtherNet/IP port link settings is fixed as the auto negotiation. The following table shows the connection for communications mode of the Ethernet switch.

(Auto-Nego: Auto negotiation, Full: Full duplex, Half: Half duplex)

Communications mode of the	Connection	
Auto-Nego	Best	
10 Mbps (fixed)	Full	
	Half	OK
100 Mbps (fixed)	Full	
	Half	OK
1,000 Mbps (fixed)	Full	

Best = Recommended; OK = Allowed; --- = Not allowed.

## 5-3 Connecting to the Network

### 5-3-1 Ethernet Connectors

The following standards and specifications apply to the connectors for the Ethernet twisted-pair cable.

- · Electrical specifications: Conforming to IEEE 802.3 standards.
- Connector structure: RJ45 8-pin Modular Connector (conforming to ISO 8877)
- For information on connecting shield wire to connector hoods, refer to 5-1-2 Ethernet Switch Types on page 5-3.

## 10Base-T and 100Base-TX



Connector pin	Signal name	Abbr.	Signal direction
1	Transmission data +	TD+	Output
2	Transmission data -	TD-	Output
3	Reception data +	RD+	Input
4	Not used		
5	Not used		
6	Reception data -	RD-	Input
7	Not used		
8	Not used		

## 1000Base-T



Connector pin	Signal name	Abbr.	Signal direction
1	Communication data DA+	BI_DA+	Input/output
2	Communication data DA-	BI_DA-	Input/output
3	Communication data DB+	BI_DB+	Input/output
4	Communication data DC+	BI_DC+	Input/output
5	Communication data DC-	BI_DC-	Input/output
6	Communication data DB-	BI_DB-	Input/output
7	Communication data DD+	BI_DD+	Input/output
8	Communication data DD-	BI_DD-	Input/output

## 5-3-2 Connecting the Cable



#### **Precautions for Correct Use**

- Turn OFF the Controller's power supply before connecting or disconnecting Ethernet communications cable.
- Allow extra space for the bending radius of the communications cable.
   For the dimensions when the communications cable is connected to the Unit, refer to *Installation Height* on page A-3. The required space depends on the communications cable and connector that are used. Consult the manufacturer or sales agent.
- **1** Install the twisted-pair cable.

- **2** Connect the cable to the Ethernet switch.
- Connect the twisted-pair cable to the connector on the EtherNet/IP port.

  Be sure to press the connectors (both the Ethernet switch side and Ethernet side) until they lock into place.



# Device Variables Related to the NX-series EtherNet/IP Unit

6-1	What	You Can Check with Device Variables	6-2
		Checking for Errors in the NX-series EtherNet/IP Unit	
		Checking for Status of the NX-series EtherNet/IP Unit	
6-2	Devic	e Variables	6-5
6-3	Speci	fications for Individual Device Variables	6-16

## 6-1 What You Can Check with Device Variables

You can use the device variables that are provided for the NX-series EtherNet/IP Unit in the user program to check errors that occur in the NX-series EtherNet/IP Unit and the status of the NX-series EtherNet/IP Unit.



#### **Additional Information**

This section describes only the device variables that are used to check the errors and status which are unique to the NX-series EtherNet/IP Unit. Refer to *Specifications for Individual Device Variables* in the *NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501)* for information on the device variables that are used to check the errors and status of the X Bus Unit Common Function Module.

## 6-1-1 Checking for Errors in the NX-series EtherNet/IP Unit

You can check for a Communications Port Error and a CIP Communications Error that occur in the NX-series EtherNet/IP Unit.

The device variables related to errors have a hierarchical structure combined with the system-defined variables as shown in the following table. The system gives the error status at each level by logically ORing the error status information in the lower level. For example, the value of *ETN\_ErrSta* in Level 5 changes to TRUE when the value of any of the following five device variables in the lower level is TRUE.

- ETN Port1Status.PortErr
- ETN Port2Status.PortErr
- ETN\_TcpAppCfgErr
- ETN IPRTbIErr
- ETN\_DNSCfgErr

From Level 1 to Level 4 are the system-defined variables. Refer to the *NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501)* for details on the specifications of these system-defined variables.

System-defined variables from Level 1 to Level 4

Level 1		Lev	Level 2		rel 3	Lev	el 4
Variable	Name	Variable	Name	Variable	Name	Variable	Name
_ErrSta	Controller Er- ror Status	_PLC_ErrSta	PLC Func- tion Module Error Status	The rest of levels are omitted.			
		_EIP_ErrSta	EtherNet/IP Error	The rest of level ted.	The rest of levels are omitted.		
		_NXB_ErrSta	NX Bus Function Module Error Status	The rest of levels are omitted.			
		_XBU_ErrSta	X Bus Function Module Error Status	_XBU_MstrE		The rest of levels are omitted.	
				_XBU_Uni- tErr	X Bus Function Module Unit Error Status	_XBU_Uni- tErrTbl	X Bus Function Module Unit Error Status Table

## Device variables in levels lower than Level 4\_XBU\_UnitErrTbI

Lev	/el 5	Lev	rel 6		Level 7
Variable	Name	Variable	Name	Variable	Name
ETN_Err- Sta	Communi- cations	ETN_Port1 Status.Por-	Communi- cations	ETN_Port1Status.MacA-drErr	Port1 MAC Address Error
	Port Error	tErr	Port1 Error	ETN_Port1Status.LanH- wErr	Port1 Communications Controller Error
				ETN_Port1Status.EtnCf-gErr	Port1 Basic Ethernet Setting Error
				ETN_Port1Sta- tus.IPAdrCfgErr	Port1 IP Address Setting Error
				ETN_Port1Status.IPAdr- DupErr	Port1 IP Address Duplication Error
				ETN_Port1Status.Boot- pErr	Port1 BOOTP Server Error
		ETN_Port2 Status.Por-	Communi- cations	ETN_Port2Status.MacA-drErr	Port2 MAC Address Error
		tErr	Port2 Error	ETN_Port2Status.LanH- wErr	Port2 Communications Controller Error
				ETN_Port2Status.EtnCf-gErr	Port2 Basic Ethernet Setting Error
				ETN_Port2Sta- tus.IPAdrCfgErr	Port2 IP Address Setting Error
				ETN_Port2Status.IPAdr- DupErr	Port2 IP Address Duplication Error
				ETN_Port2Status.Boot- pErr	Port2 BOOTP Server Error
				ETN_TcpAppCfgErr	TCP Application Setting Error
				ETN_IPRTblErr	IP Router Table Setting Error
				ETN_DNSCfgErr	DNS Setting Error

Lev	rel 5	Lev	el 6	Level 7			
Variable	Name	Variable	Name	Variable	Name		
EIP_ErrSta	CIP Com- munica-	EIP_Comm 1Status.Ci-	CIP Com- munica-	EIP_Comm1Status.Iden- tityErr	CIP Communications1 Identity Error		
	tions Error	pErr	tions1 Error	EIP_Comm1Sta- tus.TDLinkCfgErr	CIP Communications1 Tag Data Link Setting Error		
				EIP_Comm1Sta- tus.TDLinkOpnErr	CIP Communications1 Tag Data Link Connection Failed		
				EIP_Comm1Sta- tus.TDLinkErr	CIP Communications1 Tag Data Link Communications Error		
				EIP_Comm1Status.TagA-drErr	CIP Communications1 Tag Name Resolution Error		
		EIP_Comm 2Status.Ci-	CIP Com- munica-	EIP_Comm2Status.Iden- tityErr	CIP Communications2 Identity Error		
		pErr	tions2 Error	EIP_Comm2Sta- tus.TDLinkCfgErr	CIP Communications2 Tag Data Link Setting Error		
				EIP_Comm2Sta- tus.TDLinkOpnErr	CIP Communications2 Tag Data Link Connection Failed		
				EIP_Comm2Sta- tus.TDLinkErr	CIP Communications2 Tag Data Link Communications Error		
				EIP_Comm2Status.TagA-drErr	CIP Communications2 Tag Name Resolution Error		
XBU_Err- Sta*1	X Bus Unit Common Function Module Er- ror Status	The rest of le	evels are				

<sup>\*1.</sup> Refer to Specifications for Individual Device Variables in the NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501) for details of specifications.

## 6-1-2 Checking for Status of the NX-series EtherNet/IP Unit

You can check the status of the NX-series EtherNet/IP Unit such as if the EtherNet/IP port is available for use, or CIP communications are operating properly.

## 6-2 Device Variables

The variables are described in the tables as shown below.

Variable name	Meaning	Function	Data type	Range of values	Reference
This is the device variable name. The prefix gives the category name.	This is the meaning of the variable.	The function of the variable is described.	The data type of the variable is given.	The range of values that the variable can take is given.	The page of the individ- ual device variable specifica- tions table is given.

## • Functional Classification: NX-series EtherNet/IP Unit Errors

Variable name	Meaning	Function	Data type	Range of values	Reference
ETN_ErrSta	Communications Port Error	This is the error status variable for the communications port.  Represents the collective status of the following error flags. *1  • ETN_Port1Status.PortErr (Communications Port1 Error)  • ETN_Port2Status.PortErr (Communications Port2 Error)  • ETN_TcpAppCfgErr (TCP Application Setting Error)  • ETN_DNSCfgErr (DNS Setting Error)  • ETN_IPRTblErr (IP Router Table Setting Error)	WORD	16#0000 to 16#00F0	page 6-16
ETN_Port1Sta- tus.PortErr	Communications Port1 Error	This is the error status variable for the communications port 1. Represents the collective status of the following error flags. *1  • ETN_Port1Status.MacAdrErr (Port1 MAC Address Error)  • ETN_Port1Status.LanHwErr (Port1 Communications Controller Error)  • ETN_Port1Status.EtnCfgErr (Port1 Basic Ethernet Setting Error)  • ETN_Port1Status.IPAdrCfgErr (Port1 IP Address Setting Error)  • ETN_Port1Status.IPAdrDupErr (Port1 IP Address Duplication Error)  • ETN_Port1Status.BootpErr (Port1 BOOTP Server Error)  Note If a Link OFF Detected occurs, it is recorded in the event log and then the corresponding bit turns ON.	WORD	16#0000 to 16#00F0	page 6-17

Variable name	Meaning	Function	Data type	Range of values	Reference
ETN_Port2Sta- tus.PortErr	Communications Port2 Error	This is the error status variable for the communications port 2. Represents the collective status of the following error flags. *1  ETN_Port2Status.MacAdrErr (Port2 MAC Address Error)  ETN_Port2Status.LanHwErr (Port2 Communications Controller Error)  ETN_Port2Status.EtnCfgErr (Port2 Basic Ethernet Setting Error)  ETN_Port2Status.IPAdrCfgErr (Port2 IP Address Setting Error)  ETN_Port2Status.IPAdrDupErr (Port2 IP Address Duplication Error)  ETN_Port2Status.BootpErr (Port2 BOOTP Server Error)  Note If a Link OFF Detected occurs, it is recorded in the event log and then the corresponding bit turns ON.	WORD	16#0000 to 16#00F0	page 6-17
ETN_Port1Sta- tus.MacAdrErr	Port1 MAC Address Error	Indicates that an error occurred when the MAC address was read on the communications port 1 at startup.  TRUE: Error FALSE: Normal	BOOL	TRUE or FALSE	page 6-17
ETN_Port2Sta- tus.MacAdrErr	Port2 MAC Address Error	Indicates that an error occurred when the MAC address was read on the communications port 2 at startup.  TRUE: Error  FALSE: Normal	BOOL	TRUE or FALSE	page 6-18
ETN_Port1Sta- tus.LanHwErr	Port1 Communications Controller Error	Indicates that a Communications Controller failure occurred on the communications port 1.  TRUE: Failure FALSE: Normal	BOOL	TRUE or FALSE	page 6-18
ETN_Port2Sta- tus.LanHwErr	Port2 Communica- tions Controller Error	Indicates that a Communications Controller failure occurred on the communications port 2.  TRUE: Failure FALSE: Normal	BOOL	TRUE or FALSE	page 6-18
ETN_Port1Sta- tus.EtnCfgErr	Port1 Basic Ethernet Setting Error	Indicates that the Ethernet communications speed setting (Speed/Duplex) for the communications port 1 is incorrect. Or, a read operation failed. TRUE: Setting incorrect or read failed. FALSE: Normal	BOOL	TRUE or FALSE	page 6-18
ETN_Port2Sta- tus.EtnCfgErr	Port2 Basic Ethernet Setting Error	Indicates that the Ethernet communications speed setting (Speed/Duplex) for the communications port 2 is incorrect. Or, a read operation failed.  TRUE: Setting incorrect or read failed. FALSE: Normal	BOOL	TRUE or FALSE	page 6-18

Variable name	Meaning	Function	Data type	Range of values	Reference
ETN_Port1Sta- tus.IPAdrCfgErr	Port1 IP Address Setting Error	Indicates the IP address setting errors for the communications port 1. TRUE:  There is an illegal IP address setting.  A read operation failed.  The IP address obtained from the BOOTP server is inconsistent.  FALSE: Normal	BOOL	TRUE or FALSE	page 6-19
ETN_Port2Sta- tus.IPAdrCfgErr	Port2 IP Address Setting Error	Indicates the IP address setting errors for the communications port 2. TRUE:  There is an illegal IP address setting.  A read operation failed.  The IP address obtained from the BOOTP server is inconsistent.  FALSE: Normal	BOOL	TRUE or FALSE	page 6-19
ETN_Port1Sta- tus.IPAdrDupErr	Port1 IP Address Duplication Error	Indicates that the same IP address is assigned to more than one node for the communications port 1.  TRUE: Duplication occurred.  FALSE: Other than the above.	BOOL	TRUE or FALSE	page 6-19
ETN_Port2Sta- tus.IPAdrDupErr	Port2 IP Address Duplication Error	Indicates that the same IP address is assigned to more than one node for the communications port 2.  TRUE: Duplication occurred.  FALSE: Other than the above.	BOOL	TRUE or FALSE	page 6-19
ETN_Port1Sta- tus.BootpErr	Port1 BOOTP Server Error	Indicates that a BOOTP server connection failure occurred on the communications port 1.  TRUE: There was a failure to connect to the BOOTP server (timeout).  FALSE: The BOOTP is not enabled, or BOOTP is enabled and an IP address was normally obtained from the BOOTP server.	BOOL	TRUE or FALSE	page 6-20
ETN_Port2Sta- tus.BootpErr	Port2 BOOTP Server Error	Indicates that a BOOTP server connection failure occurred on the communications port 2.  TRUE: There was a failure to connect to the BOOTP server (timeout).  FALSE: The BOOTP is not enabled, or BOOTP is enabled and an IP address was normally obtained from the BOOTP server.	BOOL	TRUE or FALSE	page 6-20
ETN_TcpAppCfgErr	TCP Application Setting Error	TRUE: At least one of the set values for a TCP application is incorrect. Or, a read operation failed. FALSE: Normal	BOOL	TRUE or FALSE	page 6-20
ETN_IPRTblErr	IP Router Table Setting Error	Indicates that the default gateway settings or IP router table settings are incorrect. Or, a read operation failed.  TRUE: Setting incorrect or read failed.  FALSE: Normal	BOOL	TRUE or FALSE	page 6-20
ETN_DNSCfgErr	DNS Setting Error	Indicates that the DNS or hosts settings are incorrect. Or, a read operation failed. TRUE: Setting incorrect or read failed. FALSE: Normal	BOOL	TRUE or FALSE	page 6-20

Variable name	Meaning	Function	Data type	Range of values	Reference
EIP_ErrSta	CIP Communications Error	This is the error status variable for CIP communications.  Represents the collective status of the following error flags. *1  • EIP_Comm1Status.CipErr (CIP Communications1 Error)  • EIP_Comm2Status.CipErr (CIP Communications2 Error)	WORD	16#0000 to 16#00F0	page 6-21
EIP_Comm1Status.CipErr	CIP Communications1 Error	This is the error status variable for CIP communications on the communications port 1.  Represents the collective status of the following error flags. *1  • EIP_Comm1Status.IdentityErr (CIP Communications1 Identity Error)  • EIP_Comm1Status.TDLinkCfgErr (CIP Communications1 Tag Data Link Setting Error)  • EIP_Comm1Status.TDLinkOpnErr (CIP Communications1 Tag Data Link Connection Failed)  • EIP_Comm1Status.TDLinkErr (CIP Communications1 Tag Data Link Communications1 Tag Data Link Communications Error)  • EIP_Comm1Status.TagAdrErr (CIP Communications1 Tag Name Resolution Error)	WORD	16#0000 to 16#00F0	page 6-21
EIP_Comm2Status.CipErr	CIP Communications2 Error	This is the error status variable for CIP communications on the communications port 2.  Represents the collective status of the following error flags. *1  • EIP_Comm2Status.IdentityErr (CIP Communications2 Identity Error)  • EIP_Comm2Status.TDLinkCfgErr (CIP Communications2 Tag Data Link Setting Error)  • EIP_Comm2Status.TDLinkOpnErr (CIP Communications2 Tag Data Link Connection Failed)  • EIP_Comm2Status.TDLinkErr (CIP Communications2 Tag Data Link Communications2 Tag Data Link Communications Error)  • EIP_Comm2Status.TagAdrErr (CIP Communications2 Tag Name Resolution Error)	WORD	16#0000 to 16#00F0	page 6-21
EIP_Comm1Sta- tus.IdentityErr	CIP Communica- tions1 Identity Error	Indicates that the identity information for CIP communications 1 (which you cannot overwrite) is incorrect. Or, a read operation failed.  TRUE: Setting incorrect or read failed.  FALSE: Normal	BOOL	TRUE or FALSE	page 6-21

Variable name	Meaning	Function	Data type	Range of values	Reference
EIP_Comm2Sta- tus.IdentityErr	CIP Communica- tions2 Identity Error	Indicates that the identity information for CIP communications 2 (which you cannot overwrite) is incorrect. Or, a read operation failed.  TRUE: Setting incorrect or read failed. FALSE: Normal	BOOL	TRUE or FALSE	page 6-22
EIP_Comm1Sta- tus.TDLinkCfgErr	CIP Communica- tions1 Tag Data Link Setting Error	Indicates that the tag data link settings for CIP communications 1 are incorrect. Or, a read operation failed. TRUE: Setting incorrect or read failed. FALSE: Normal	BOOL	TRUE or FALSE	page 6-22
EIP_Comm2Sta- tus.TDLinkCfgErr	CIP Communica- tions2 Tag Data Link Setting Error	Indicates that the tag data link setting for CIP communications 2 are incorrect. Or, a read operation failed.  TRUE: Setting incorrect or read failed.  FALSE: Normal	BOOL	TRUE or FALSE	page 6-22
EIP_Comm1Sta- tus.TDLinkOpnErr	CIP Communications1 Tag Data Link Connection Failed	Indicates that establishing a tag data link connection for CIP communications 1 failed.  TRUE: Establishing a tag data link connection failed due to one of the following causes.  The information registered for a target node in the tag data link parameters is different from the actual node information.  There was no response from the remote node.  FALSE: Other than the above.	BOOL	TRUE or FALSE	page 6-22
EIP_Comm2Sta- tus.TDLinkOpnErr	CIP Communications2 Tag Data Link Connection Failed	Indicates that establishing a tag data link connection for CIP communications 2 failed.  TRUE: Establishing a tag data link connection failed due to one of the following causes.  The information registered for a target node in the tag data link parameters is different from the actual node information.  There was no response from the remote node.  FALSE: Other than the above.	BOOL	TRUE or FALSE	page 6-23
EIP_Comm1Sta- tus.TDLinkErr	CIP Communications1 Tag Data Link Communications Error	Indicates that a timeout occurred in a tag data link connection for CIP communications 1.  TRUE: A timeout occurred.  FALSE: Other than the above.	BOOL	TRUE or FALSE	page 6-23
EIP_Comm2Sta- tus.TDLinkErr	CIP Communications2 Tag Data Link Communications Error	Indicates that a timeout occurred in a tag data link connection for CIP communications 2.  TRUE: A timeout occurred.  FALSE: Other than the above.	BOOL	TRUE or FALSE	page 6-23

Variable name	Meaning	Function	Data type	Range of values	Reference
EIP_Comm1Status.TagAdrErr	CIP Communications1 Tag Name Resolution Error	Indicates that the tag resolution for CIP communications 1 failed (i.e., the address could not be identified from the tag name).  TRUE: Tag resolution failed (i.e., the address could not be identified from the tag name). The following causes are possible.  • The size of the network variable is different from the tag settings.  • The I/O direction that is set in the tag data link settings does not agree with the I/O direction of the variable in the NX-series EtherNet/IP Unit.  • There is no network variable in the NX-series EtherNet/IP Unit that corresponds to the tag setting.  FALSE: Other than the above.	BOOL	TRUE or FALSE	page 6-23
EIP_Comm2Status.TagAdrErr	CIP Communications2 Tag Name Resolution Error	Indicates that the tag resolution for CIP communications 2 failed (i.e., the address could not be identified from the tag name).  TRUE: Tag resolution failed (i.e., the address could not be identified from the tag name). The following causes are possible.  • The size of the network variable is different from the tag settings.  • The I/O direction that is set in the tag data link settings does not agree with the I/O direction of the variable in the NX-series EtherNet/IP Unit.  • There is no network variable in the NX-series EtherNet/IP Unit that corresponds to the tag setting.  FALSE: Other than the above.	BOOL	TRUE or FALSE	page 6-24

<sup>\*1.</sup> Refer to Meanings of Error Status Bits on page 6-10 for the meanings of the error status bits.

## Meanings of Error Status Bits

The meanings of the individual bits in the following error status are the same.

- ETN\_ErrSta (Communications Port Error)
- EIP\_ErrSta (CIP Communications Error)
- ETN\_Port1Status.PortErr (Communications Port1 Error)
- ETN\_Port2Status.PortErr (Communications Port2 Error)
- EIP\_Comm1Status.CipErr (CIP Communications1 Error)
- EIP\_Comm2Status.CipErr (CIP Communications2 Error)

The meanings of the individual bits are shown in the following table.

Bit:	15	14	13	12	11	10	9	8	/	6	5	4	3	2	1	U
WORD	-	-	-	-	-	-	-	-	-	-			-	-	-	-

Bit	Description
15 to 6	Reserved.
5	This bit indicates whether a minor fault level Controller error has occurred.
	TRUE: A minor fault level Controller error has occurred.
	FALSE: A minor fault level Controller error has not occurred.
4	This bit indicates whether an observation level Controller error has occurred.
	TRUE: An observation level Controller error has occurred.
	FALSE: An observation level Controller error has not occurred.
3 to 0	Reserved.

## • Functional Classification: NX-series EtherNet/IP Unit Status

Variable name	Meaning	Function	Data type	Range of values	Reference
ETN_Port1Status.Et- nOnlineSta	Port1 Online	Indicates that the EtherNet/IP port's communications can be used via the communications port 1 (that is, the link is ON, IP address is defined, and there are no errors.)  TRUE: The EtherNet/IP port's communications can be used.  FALSE: The EtherNet/IP port's communications is disabled due to an error in initial processing, restart processing, or link OFF status.	BOOL	TRUE or FALSE	page 6-24
ETN_Port2Status.Et- nOnlineSta	Port2 Online	Indicates that the EtherNet/IP port's communications can be used via the communications port 2 (that is, the link is ON, IP address is defined, and there are no errors.)  TRUE: The EtherNet/IP port's communications can be used.  FALSE: The EtherNet/IP port's communications is disabled due to an error in initial processing, restart processing, or link OFF status.	BOOL	TRUE or FALSE	page 6-24
EIP_Comm1Sta- tus.TDLinkRunSta	CIP Communica- tions1 Tag Data Link Communications Sta- tus	Indicates that at least one connection is in normal operation in CIP communications 1.  TRUE: Normal operation FALSE: Other than the above.	BOOL	TRUE or FALSE	page 6-24
EIP_Comm2Sta- tus.TDLinkRunSta	CIP Communica- tions2 Tag Data Link Communications Sta- tus	Indicates that at least one connection is in normal operation in CIP communications 2.  TRUE: Normal operation FALSE: Other than the above.	BOOL	TRUE or FALSE	page 6-25
EIP_Comm1Sta- tus.TDLinkAllRunSta	CIP Communica- tions1 All Tag Data Link Communications Status	Indicates that all tag data links are communicating in CIP communications 1.  TRUE: Tag data links are communicating in all connections as the originator.  FALSE: An error occurred in at least one connection.	BOOL	TRUE or FALSE	page 6-25
EIP_Comm2Sta- tus.TDLinkAllRunSta	CIP Communications2 All Tag Data Link Communications Status	Indicates that all tag data links are communicating in CIP communications 2. TRUE: Tag data links are communicating in all connections as the originator. FALSE: An error occurred in at least one connection.	BOOL	TRUE or FALSE	page 6-25

Variable name	Meaning	Function	Data type	Range of values	Reference
EIP_Comm1Sta- tus.RegTarget- Sta[255]	CIP Communications1 Registered Target Node Information	Gives a list of nodes for which EtherNet/IP connections are registered for CIP communications 1. This variable is valid only when the EtherNet/IP port is the originator. Array[x] is TRUE: The connection to the node with a target node ID of x is registered. Array[x] is FALSE: The connection to the node with a target node ID of x is not registered.	ARRAY [0255] OF BOOL	TRUE or FALSE	page 6-25
EIP_Comm2Sta- tus.RegTarget- Sta[255]	CIP Communica- tions2 Registered Target Node Informa- tion	Gives a list of nodes for which EtherNet/IP connections are registered for CIP communications 2. This variable is valid only when the EtherNet/IP port is the originator. Array[x] is TRUE: The connection to the node with a target node ID of x is registered. Array[x] is FALSE: The connection to the node with a target node ID of x is not registered.	ARRAY [0255] OF BOOL	TRUE or FALSE	page 6-26
EIP_Comm1Sta- tus.EstbTarget- Sta[255]	CIP Communications1 Normal Target Node Information	Gives a list of nodes that have normally established EtherNet/IP connections for CIP communications 1.  Array[x] is TRUE:  The connection to the node with a target node ID of x was established normally.  Array[x] is FALSE:  The connection to the node with a target node ID of x was not established, or an error occurred.	ARRAY [0255] OF BOOL	TRUE or FALSE	page 6-26
EIP_Comm2Sta- tus.EstbTarget- Sta[255]	CIP Communica- tions2 Normal Target Node Information	Gives a list of nodes that have normally established EtherNet/IP connections for CIP communications 2.  Array[x] is TRUE: The connection to the node with a target node ID of x was established normally.  Array[x] is FALSE: The connection to the node with a target node ID of x was not established, or an error occurred.	ARRAY [0255] OF BOOL	TRUE or FALSE	page 6-26
EIP_Comm1Sta- tus.TargetPLCMo- deSta[255]	CIP Communications1 Target PLC Operating Mode	Shows the operating status of the target node Controllers that are connected for CIP communications 1, with the Ether-Net/IP port as the originator.  The array elements are valid only when the corresponding Normal Target Node Information is TRUE. If the corresponding Normal Target Node Information is FALSE, it indicates the previous operating status.  Array[x] is TRUE: This is the operating state of the target Controller with a node address of x.  Array[x] is FALSE: Other than the above.	ARRAY [0255] OF BOOL	TRUE or FALSE	page 6-26

Variable name	Meaning	Function	Data type	Range of values	Reference
EIP_Comm2Sta- tus.TargetPLCMo- deSta[255]	CIP Communications2 Target PLC Operating Mode	Shows the operating status of the target node Controllers that are connected for CIP communications 2, with the Ether-Net/IP port as the originator. The array elements are valid only when the corresponding Normal Target Node Information is TRUE. If the corresponding Normal Target Node Information is FALSE, it indicates the previous operating status. Array[x] is TRUE: This is the operating state of the target Controller with a node address of x. Array[x] is FALSE: Other than the above.	ARRAY [0255] OF BOOL	TRUE or FALSE	page 6-27
EIP_Comm1Sta- tus.TargetPL- CErr[255]	CIP Communications1 Target PLC Error Information	Shows the error status (logical OR of fatal and non-fatal errors) of the target node Controllers that are connected for CIP communications 1, with the Ether-Net/IP ports as the originator. The array elements are valid only when the corresponding Normal Target Node Information is TRUE. The immediately preceding value is retained if this variable is FALSE. Array[x] is TRUE:  A fatal or non-fatal error occurred in the target Controller with a target node ID of x.  Array[x] is FALSE: Other than the above.	ARRAY [0255] OF BOOL	TRUE or FALSE	page 6-27
EIP_Comm2Sta- tus.TargetPL- CErr[255]	CIP Communications2 Target PLC Error Information	Shows the error status (logical OR of fatal and non-fatal errors) of the target node Controllers that are connected for CIP communications 2, with the Ether-Net/IP ports as the originator. The array elements are valid only when the corresponding Normal Target Node Information is TRUE. The immediately preceding value is retained if this variable is FALSE. Array[x] is TRUE:  A fatal or non-fatal error occurred in the target Controller with a target node ID of x.  Array[x] is FALSE: Other than the above.	ARRAY [0255] OF BOOL	TRUE or FALSE	page 6-27

Variable name	Meaning	Function	Data type	Range of values	Reference
EIP_Comm1Status.TargetNo-deErr[255]	CIP Communications1 Target Node Error Information	Indicates that the connection for the Registered Target Node Information for CIP communications 1 was not established or that an error occurred in the target Controller.  The array elements are valid only when the Registered Target Node Information is TRUE.  Array[x] is TRUE:  A connection was not normally established with the target node for a target node ID of x (the Registered Target Node Information is TRUE and the Normal Target Node Information is FALSE), or a connection was established with the target node but an error occurred in the target Controller.  Array[x] is FALSE: The target node is not registered for a target node ID of x (the Registered Target Node Information is FALSE), or a connection was normally established with the target node (the Registered Target Node Information is TRUE). An error occurred in the target Controller (the Target PLC Error Information is TRUE).	ARRAY [0255] OF BOOL	TRUE or FALSE	page 6-28
EIP_Comm2Status.TargetNo-deErr[255]	CIP Communications2 Target Node Error Information	Indicates that the connection for the Registered Target Node Information for CIP communications 2 was not established or that an error occurred in the target Controller.  The array elements are valid only when the Registered Target Node Information is TRUE.  Array[x] is TRUE:  A connection was not normally established with the target node for a target node ID of x (the Registered Target Node Information is TRUE and the Normal Target Node Information is FALSE), or a connection was established with the target node but an error occurred in the target Controller.  Array[x] is FALSE: The target node is not registered for a target node ID of x (the Registered Target Node Information is FALSE), or a connection was normally established with the target node (the Registered Target Node Information is TRUE). An error occurred in the target Controller (the Target PLC Error Information is TRUE).	ARRAY [0255] OF BOOL	TRUE or FALSE	page 6-28



#### **Precautions for Correct Use**

#### **Communications Status with Target Node**

The communications status of the communications port 1 of the NX-series EtherNet/IP Unit and the target node is shown by the combination of the values of the following four device variables.

- EIP\_Comm1Status.RegTargetSta[255] (CIP Communications1 Registered Target Node Information)
- EIP\_Comm1Status.EstbTargetSta[255] (CIP Communications1 Normal Target Node Information)
- EIP\_Comm1Status.TargetPLCErr[255] (CIP Communications1 Target PLC Error Information)
- EIP\_Comm1Status.TargetNodeErr[255] (CIP Communications1 Target Node Error Information)

Value of EIP_Comm1Sta- tus.RegTarget- Sta[255]	Value of EIP_Comm1Sta- tus.EstbTarget- Sta[255]	Value of EIP_Comm1 Status.Tar- getPL- CErr[255]	Value of EIP_Comm1 Status.Tar- getNo- deErr[255]	Communications status with target node
TRUE	TRUE	FALSE	FALSE	A connection with the target node was established normally and there is no error in the target PLC.
		TRUE	TRUE	A connection with the target node was established but there is an error in the target PLC.
	FALSE		TRUE	A connection with the target node was not established normally.
FALSE				The information is not valid because the target node is not registered.

The same applies for the case of communications port 2.

# 6-3 Specifications for Individual Device Variables

The specifications for each device variable are given as described below.

Variable name	This is the de	vice variable nar	ne. The pre-	Members	The member names are given
	fix gives the category name.				for structure variables.
Meaning	This is the meaning of the variable.			Global/local	Global: Global variable, Local:
					Local variable
Function	The function of	of the variable is	described.		
Data type	The data type	of the variable i	s given.	Range of values	The range of values that the var-
					iable can take is given.
R/W access	R: Read on-	Retained	The Retain	Network Publish	The Network Publish attribute of
	ly,		attribute of		the variable is given.
	RW: Read/		the variable		
	write		is given.		
Usage in user	Whether you	Related in-	The instruction	ons that are related to th	ne variable are given.
program	can use the	structions	If you cannot	use the variable directly	y in the user program, the instruc-
	variable di-		tions that acc	ess the variable are giv	en.
	rectly in the				
	user pro-				
	gram is				
	specified.				

## • Functional Classification: NX-series EtherNet/IP Unit Errors

Variable name	ETN_ErrSta						
Meaning	Communication	Communications Port Error Global/local Global					
Function	It represents the ETN_Port1S ETN_Port2S ETN_TcpApp ETN_DNSCf ETN_IPRTbl	This is the error status variable for the communications port.  It represents the collective status of the following error flags.  • ETN_Port1Status.PortErr (Communications Port1 Error)  • ETN_Port2Status.PortErr (Communications Port2 Error)  • ETN_TcpAppCfgErr (TCP Application Setting Error)  • ETN_DNSCfgErr (DNS Setting Error)  • ETN_IPRTbIErr (IP Router Table Setting Error)  Note Refer to Meanings of Error Status Bits on page 6-10 for the meanings of the error status bits.					
Data type	WORD			Range of values	16#0000 to 16#00F0		
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Usage in user pro-	Possible.	Related in-					
gram		structions					

Variable name	ETN_Port1State	us.PortErr					
Meaning	Communication	Communications Port1 Error Global/local Global					
Function	It represents the	This is the error status variable for the communications port 1. t represents the collective status of the following error flags. • ETN Port1Status.MacAdrErr (Port1 MAC Address Error)					
	• ETN_Port1S • ETN_Port1S • ETN_Port1S • ETN_Port1S Note If a Link	<ul> <li>ETN_Port1Status.MacAdrErr (Port1 MAC Address Error)</li> <li>ETN_Port1Status.LanHwErr (Port1 Communications Controller Error)</li> <li>ETN_Port1Status.EtnCfgErr (Port1 Basic Ethernet Setting Error)</li> <li>ETN_Port1Status.IPAdrCfgErr (Port1 IP Address Setting Error)</li> <li>ETN_Port1Status.IPAdrDupErr (Port1 IP Address Duplication Error)</li> <li>ETN_Port1Status.BootpErr (Port1 BOOTP Server Error)</li> <li>Note If a Link OFF Detected occurs, it is recorded in the event log and then the corresponding bit turns ON. Refer to Meanings of Error Status Bits on page 6-10 for the meanings of the error</li> </ul>					
Data type	WORD			Range of values	16#0000 to 16#00F0		
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Usage in user program	Possible.	Related in- structions					

Variable name	ETN_Port2Stat	us.PortErr						
Meaning	Communication	Communications Port2 Error Global/local Global						
Function	This is the error	This is the error status variable for the communications port 2.						
	It represents the	e collective status	s of the following	error flags.				
	ETN_Port2S	• ETN_Port2Status.MacAdrErr (Port2 MAC Address Error)						
	ETN_Port2S	tatus.LanHwErr (	(Port2 Communic	ations Controller Error)				
	ETN_Port2S	ETN_Port2Status.EtnCfgErr (Port2 Basic Ethernet Setting Error)						
	ETN_Port2S	ETN_Port2Status.IPAdrCfgErr (Port2 IP Address Setting Error)						
	ETN_Port2S	ETN Port2Status.IPAdrDupErr (Port2 IP Address Duplication Error)						
	ETN_Port2S	tatus.BootpErr (F	Port2 BOOTP Sei	rver Error)				
	Note If a Link	OFF Detected	occurs, it is red	corded in the event log	and then the corresponding bit			
	turns Of	N. Refer to <i>Mea</i>	anings of Error	Status Bits on page 6-1	0 for the meanings of the error			
	status b	its.						
Data type	WORD			Range of values	16#0000 to 16#00F0			
R/W access	R	Retained	Not retained. Network Publish Do not publish.					
Usage in user program	Possible.	Related in- structions						

Variable name	ETN_Port1Stat	ETN_Port1Status.MacAdrErr							
Meaning	Port1 MAC Add	lress Error		Global/local	Global				
Function	Indicates that an error occurred when the MAC address was read on the communications port 1 at startup.  TRUE: Error  FALSE: Normal								
Data type	BOOL			Range of values	TRUE or FALSE				
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.				
Usage in user pro- gram	Possible.	Related in- structions							

Variable name	ETN Port2Status.MacAdrErr						
Meaning	Port2 MAC Add			Global/local	Global		
Function			when the MAC a		communications port 2 at startup.		
	TRUE: Error						
	FALSE: Norma	I					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Usage in user pro-	Possible.	Related in-		•	·		
gram		structions					
Variable name	ETN Port1Stat	us LanHwErr					
Meaning		ications Controlle	er Error	Global/local	Global		
Function	-			e occurred on the comr			
i diletion	TRUE: Failure	Communication	3 CONTROLL TAILOR	e occurred on the com	numbations port 1.		
	FALSE: Norma	I					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Usage in user pro-	Possible.	Related in-					
gram		structions					
Variable name	ETN Port2Stat	un Landhu/Err					
		ications Controlle	or Error	Global/local	Global		
Meaning Function	-			e occurred on the comr			
runction	TRUE: Failure	Communications	s Controller fallul	e occurred on the comi	nunications port 2.		
	FALSE: Norma	I					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Usage in user pro-	Possible.	Related in-					
gram		structions					
Variable name	CTN Dort1Stat	us CtoCfaCrr					
	ETN_Port1Stat			Global/local	Global		
Meaning		nernet Setting Err			x) for the communications port 1 is incor		
Function		operation failed.		ed setting (Speed/Duple	x) for the communications port 1 is incor-		
	1	incorrect or read					
	FALSE: Norma						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Usage in user pro-	Possible.	Related in-					
gram		structions					
Variable name	ETN_Port2Stat	us.EtnCfaFrr					
Meaning		nernet Setting Err	or	Global/local	Global		
Function					x) for the communications port 2 is incor		
		operation failed.		Johnny (Opocurbupie	, 110 0011111111111111111111111111		
		incorrect or read					
	FALSE: Norma						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Hoose in Hoose are	Possible.	Poloted in					
Usage in user pro-	Possible.	Related in-					

Variable name	ETN_Port1Stat	ETN_Port1Status.IPAdrCfgErr							
Meaning	Port1 IP Addres	ss Setting Error		Global/local	Global				
Function	Indicates the IP address setting errors for the communications port 1.  TRUE:  There is an illegal IP address setting.  A read operation failed.  The IP address obtained from the BOOTP server is inconsistent.  FALSE: Normal								
Data type	BOOL			Range of values	TRUE or FALSE				
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.				
Usage in user program	Possible.	Related in- structions							

Variable name	ETN_Port2State	ETN_Port2Status.IPAdrCfgErr						
Meaning	Port2 IP Addres	ss Setting Error		Global/local	Global			
Function	Indicates the IP TRUE:	Indicates the IP address setting errors for the communications port 2.  TRUE:						
	There is an ill	There is an illegal IP address setting.						
	A read opera	A read operation failed.						
	The IP addre	ess obtained from	the BOOTP ser	ver is inconsistent.				
	FALSE: Normal							
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained. Network Publish Do not publish.					
Usage in user pro-	Possible.	Related in-						
gram		structions						

Variable name	ETN_Port1Status.IPAdrDupErr							
Meaning	Port1 IP Addres	ss Duplication En	ror	Global/local	Global			
Function	Indicates that the same IP address is assigned to more than one node for the communications port 1.  TRUE: Duplication occurred.  FALSE: Other than the above.							
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.			
Usage in user pro- gram	Possible.	Related in- structions						

Variable name	ETN_Port2Stat	ETN_Port2Status.IPAdrDupErr							
Meaning	Port2 IP Addres	Port2 IP Address Duplication Error Global/local Global							
Function	Indicates that the same IP address is assigned to more than one node for the communications port 2.  TRUE: Duplication occurred.  FALSE: Other than the above.								
Data type	BOOL			Range of values	TRUE or FALSE				
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.				
Usage in user program	Possible.	Related in- structions							

Variable name	ETN_Port1Status.BootpErr								
Meaning	Port1 BOOTP			Global/local	Global				
Function	TRUE: There v	Indicates that a BOOTP server connection failure occurred on the communications port 1.  TRUE: There was a failure to connect to the BOOTP server (timeout).  FALSE: The BOOTP is not enabled, or BOOTP is enabled and an IP address was normally obtained from the BOOTP server.							
Data type	BOOL			Range of values	TRUE or FALSE				
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.				
Usage in user pro- gram	Possible.	Related in- structions							
Variable name	ETN_Port2Sta	tus BootnErr							
Meaning				Global/local	Global				
Function	Port2 BOOTP Server Error  Global/local  Indicates that a BOOTP server connection failure occurred on the communications port 2.  TRUE: There was a failure to connect to the BOOTP server (timeout).  FALSE: The BOOTP is not enabled, or BOOTP is enabled and an IP address was normally obtained from the BOOTP server.								
Data type	BOOL			Range of values	TRUE or FALSE				
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.				
Usage in user pro- gram	Possible.	Related in- structions							
Variable name	ETN_TcpAppC	fgErr							
Meaning	TCP Application	n Setting Error		Global/local	Global				
Function	TRUE: At least		alues for a TCP a	pplication is incorrect. (	Or, a read operation failed.				
Data type	BOOL			Range of values	TRUE or FALSE				
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.				
Usage in user pro-	Possible.	Related in-							
gram		structions							
Variable name	ETN_IPRTblEt	r							
Meaning	IP Router Table			Global/local	Global				
Function	Indicates that t	he default gatewa incorrect or read	, ,		incorrect. Or, a read operation failed.				
Data type	BOOL			Range of values	TRUE or FALSE				
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.				
Usage in user pro- gram	Possible.	Related in- structions							
	ETN DNSCfgErr								
Variable name	ETN_DNSCfg8	Err							
				Global/local	Global				
Meaning	DNS Setting E	rror he DNS or hosts incorrect or read	ŭ	Global/local rrect. Or, a read operati					
Variable name Meaning Function Data type	DNS Setting E Indicates that t TRUE: Setting	rror he DNS or hosts incorrect or read	ŭ						

Variable name	EIP_ErrSta	EIP_ErrSta							
Meaning	CIP Communic	ations Error		Global/local	Global				
Function	This is the error	This is the error status variable for CIP communications.							
	It represents the	It represents the collective status of the following error flags.							
	EIP_Comm1	EIP_Comm1Status.CipErr (CIP Communications1 Error)							
	EIP_Comm2	EIP_Comm2Status.CipErr (CIP Communications2 Error)							
	Note Refer to	Meanings of E	rror Status Bits	on page 6-10 for the	meanings of the error status bits.				
Data type	WORD			Range of values	16#0000 to 16#00F0				
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.				
Usage in user pro-	Possible.	Related in-							
gram		structions	uctions						

Variable name	EIP_Comm1Sta	atus.CipErr					
Meaning	CIP Communications1 Error Global/local Global						
Function	This is the error status variable for CIP communications on the communications port 1.						
	It represents the collective status of the following error flags.						
	EIP_Comm1	EIP_Comm1Status.IdentityErr (CIP Communications1 Identity Error)					
	EIP_Comm1	Status.TDLinkCf	gErr (CIP Comm	unications1 Tag Data Link	Setting Error)		
	EIP_Comm1	Status.TDLinkOp	onErr (CIP Comm	nunications1 Tag Data Lin	k Connection Failed)		
	EIP_Comm1	Status.TDLinkEr	r (CIP Communic	cations1 Tag Data Link Co	mmunications Error)		
	EIP_Comm1	Status.TagAdrEr	r (CIP Communic	ations1 Tag Name Resolu	ution Error)		
	Note Refer to	Meanings of E	rror Status Bits	on page 6-10 for the n	neanings of the error status bits.		
Data type	WORD			Range of values	16#0000 to 16#00F0		
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Usage in user pro-	Possible.	Related in-					
gram		structions					

Variable name	EIP_Comm2Status.CipErr							
Meaning	CIP Communic	CIP Communications2 Error Global/local Global						
Function	This is the error	status variable f	or CIP communic	cations on the communica	tions port 2.			
	It represents the	It represents the collective status of the following error flags.						
	EIP_Comm2	Status.IdentityEr	r (CIP Communic	cations2 Identity Error)				
	EIP_Comm2	Status.TDLinkCf	gErr (CIP Comm	unications2 Tag Data Link	Setting Error)			
	EIP_Comm2	Status.TDLinkOp	onErr (CIP Comm	nunications2 Tag Data Lin	k Connection Failed)			
	EIP_Comm2	Status.TDLinkEr	r (CIP Communic	ations2 Tag Data Link Co	mmunications Error)			
	EIP_Comm2	Status.TagAdrEr	r (CIP Communic	ations2 Tag Name Resolu	ution Error)			
	Note Refer to	Meanings of E	rror Status Bits	on page 6-10 for the r	neanings of the error status bits.			
Data type	WORD			Range of values	16#0000 to 16#00F0			
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.			
Usage in user pro-	Possible.	ossible. Related in						
gram		structions						

Variable name	EIP_Comm1S	EIP_Comm1Status.ldentityErr							
Meaning	CIP Communic	CIP Communications1 Identity Error Global/local Global							
Function	Indicates that the identity information for CIP communications 1 (which you cannot overwrite) is incorrect. Or, a read operation failed.  TRUE: Setting incorrect or read failed.  FALSE: Normal								
Data type	BOOL			Range of values	TRUE or FALSE				
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.				
Usage in user pro- gram	Possible.	Related in- structions							

Variable name	EIP_Comm2St	atus.IdentityErr					
Meaning	CIP Communic	ations2 Identity E	Error	Global/local	Global		
Function	read operation	failed. incorrect or read		nmunications 2 (which y	you cannot overwrite) is incorrect. Or, a		
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Usage in user pro- gram	Possible.	Related in- structions					
Variable name		atus.TDLinkCfgE					
Meaning	CIP Communic	ations1 Tag Data	Link Setting	Global/local	Global		
Function	TRUE: Setting	Indicates that the tag data link settings for CIP communications 1 are incorrect. Or, a read operation failed.  TRUE: Setting incorrect or read failed.  FALSE: Normal					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Usage in user pro- gram	Possible.	Related in- structions			_		
Function	TRUE: Setting	incorrect or read	-	mmunications 2 are inco	orrect. Or, a read operation failed.		
	FALSE: Norma	I					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Usage in user program	Possible.	Related in- structions					
	I						
Variable name		atus.TDLinkOpnl		Olahatii	Clabal		
Meaning	tion Failed	ations1 Tag Data		Global/local	Global		
Function	<ul> <li>Indicates that establishing a tag data link connection for CIP communications 1 failed.</li> <li>TRUE: Establishing a tag data link connection failed due to one of the following causes.</li> <li>The information registered for a target node in the tag data link parameters is different from the actual node information.</li> <li>There was no response from the remote node.</li> <li>FALSE: Other than the above.</li> </ul>						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Usage in user program	Possible.	Related in- structions					

Variable name	EIP_Comm2Sta	EIP_Comm2Status.TDLinkOpnErr							
Meaning	CIP Communication Failed	CIP Communications2 Tag Data Link Connecion Failed Global Global							
Function	TRUE: Establis  The information.	There was no response from the remote node.							
Data type	BOOL			Range of values	TRUE or FALSE				
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.				
Usage in user program	Possible.	Related in- structions							

Variable name	EIP_Comm1Sta	EIP_Comm1Status.TDLinkErr							
Meaning	CIP Communic	ations1 Tag Data	Link Communi-	Global/local	Global				
Function	TRUE: A timeo	Indicates that a timeout occurred in a tag data link connection for CIP communications 1.  TRUE: A timeout occurred.  FALSE: Other than the above.							
Data type	BOOL			Range of values	TRUE or FALSE				
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.				
Usage in user program	Possible.	Related in- structions							

Variable name	EIP_Comm2Status.TDLinkErr							
Meaning	CIP Communic	ations2 Tag Data	Link Communi-	Global/local	Global			
	cations Error							
Function	Indicates that a	Indicates that a timeout occurred in a tag data link connection for CIP communications 2.						
	TRUE: A timeo	TRUE: A timeout occurred.						
	FALSE: Other t	han the above.						
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.			
Usage in user pro-	Possible.	Related in-						
gram		structions						

Variable name	EIP_Comm1Status.TagAdrErr						
Meaning	CIP Communica Error	CIP Communications1 Tag Name Resolution  Global/local  Global					
Function	Indicates that the tag resolution for CIP communications 1 failed (i.e., the address could not be identified from the tag name).  TRUE: Tag resolution failed (i.e., the address could not be identified from the tag name). The following causes are possible.  • The size of the network variable is different from the tag settings.  • The I/O direction that is set in the tag data link settings does not agree with the I/O direction of the variable in the NX-series EtherNet/IP Unit.  • There is no network variable in the NX-series EtherNet/IP Unit that corresponds to the tag setting.  FALSE: Other than the above.						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Usage in user program	Possible.	Related in- structions					

Variable name	EIP_Comm2Status.TagAdrErr						
Meaning	CIP Communica	ations2 Tag Nam	e Resolution	Global/local	Global		
	Error						
Function	Indicates that th	e tag resolution	for CIP communi	cations 2 failed (i.e., the a	ddress could not be identified from the		
	tag name).						
	TRUE: Tag reso	olution failed (i.e.,	, the address cou	ld not be identified from the	ne tag name). The following causes are		
	possible.						
	The size of the network variable is different from the tag settings.						
	The I/O direct	• The I/O direction that is set in the tag data link settings does not agree with the I/O direction of the variable in					
	the NX-serie	s EtherNet/IP Un	it.				
	There is no r	etwork variable i	n the NX-series I	EtherNet/IP Unit that corre	sponds to the tag setting.		
	FALSE: Other to	nan the above.					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Usage in user pro-	Possible.	Related in-					
gram		structions					

## • Functional Classification: NX-series EtherNet/IP Unit Status

Variable name	ETN_Port1Stat	ETN_Port1Status.EtnOnlineSta							
Meaning	Port1 Online			Global/local	Global				
Function	Indicates that the EtherNet/IP port's communications can be used via the communications port 1 (that is, the link is ON, IP address is defined, and there are no errors.)  TRUE: The EtherNet/IP port's communications can be used.  FALSE: The EtherNet/IP port's communications is disabled due to an error in initial processing, restart processing, or link OFF status.								
Data type	BOOL			Range of values	TRUE or FALSE				
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.				
Usage in user program	Possible.	Related in- structions							

Variable name	ETN_Port2Status.EtnOnlineSta						
Meaning	Port2 Online Global/local Global						
Function	Indicates that the EtherNet/IP port's communications can be used via the communications port 2 (that is, the link is ON, IP address is defined, and there are no errors.)  TRUE: The EtherNet/IP port's communications can be used.  FALSE: The EtherNet/IP port's communications is disabled due to an error in initial processing, restart processing, or link OFF status.						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Usage in user program	Possible.	Related in- structions					

Variable name	EIP_Comm1Status.TDLinkRunSta							
Meaning	CIP Communications Status	ations1 Tag Data	Link Communi-	Global/local	Global			
Function	Indicates that at least one connection is in normal operation in CIP communications 1.  TRUE: Normal operation  FALSE: Other than the above.							
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.			
Usage in user program	Possible.	Related in- structions						

Variable name	EIP_Comm2Status.TDLinkRunSta						
Meaning	CIP Communications2 Tag Data Link Communi-			Global/local	Global		
	cations Status						
Function	Indicates that a	Indicates that at least one connection is in normal operation in CIP communications 2.					
	TRUE: Normal operation						
	FALSE: Other to	nan the above.					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Usage in user pro-	Possible.	Related in-					
gram		structions					

Variable name	EIP_Comm1Status.TDLinkAllRunSta						
Meaning	CIP Communications1 All Tag Data Link Com-			Global/local	Global		
	munications Sta	munications Status					
Function	Indicates that all tag data links are communicating in CIP communications 1.						
	TRUE: Tag data links are communicating in all connections as the originator.						
	FALSE: An erro	r occurred in at le	east one connect	ion.			
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Usage in user pro-	Possible.	Related in-					
gram		structions					

Variable name	EIP_Comm2Status.TDLinkAllRunSta							
Meaning	CIP Communications2 All Tag Data Link Com-			Global/local	Global			
	munications Sta	atus						
Function	Indicates that a	Indicates that all tag data links are communicating in CIP communications 2.						
	TRUE: Tag data	TRUE: Tag data links are communicating in all connections as the originator.						
	FALSE: An erro	FALSE: An error occurred in at least one connection.						
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.			
Usage in user pro-	Possible.	Related in-						
gram		structions						

Variable name	EIP_Comm1Sta	EIP_Comm1Status.RegTargetSta[255]						
Meaning	CIP Communic	ations1 Registere	ed Target Node	Global/local	Global			
	Information							
Function	Gives a list of n	Gives a list of nodes for which EtherNet/IP connections are registered for CIP communications 1.						
	This variable is	valid only when t	the EtherNet/IP p	ort is the originator.				
	Array[x] is TRU	E: The connectio	n to the node wit	h a target node ID of x is i	registered.			
	Array[x] is FALS	SE: The connection	on to the node wi	th a target node ID of x is	not registered.			
Data type	ARRAY [0255]	OF BOOL		Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained. Network Publish Do not publish.					
Usage in user pro-	Possible.	Related in-						
gram		structions						

Variable name	EIP_Comm2Sta	atus.RegTargetSt	a[255]			
Meaning		ations2 Registere		Global/local	Global	
Function	This variable is Array[x] is TRU	Gives a list of nodes for which EtherNet/IP connections are registered for CIP communications 2.  This variable is valid only when the EtherNet/IP port is the originator.  Array[x] is TRUE: The connection to the node with a target node ID of x is registered.  Array[x] is FALSE: The connection to the node with a target node ID of x is not registered.				
Data type	ARRAY [0255]	OF BOOL		Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.	
Usage in user pro- gram	Possible.	Related in- structions				
Variable name	EIP_Comm1Sta	atus.EstbTargetS	ta[255]	1		
Meaning	CIP Communication	ations1 Normal T	arget Node In-	Global/local	Global	
Function	Array[x] is TRU	E: The connectio	n to the node wit	h a target node ID of x wa	ns for CIP communications 1. s established normally. as not established, or an error occur-	
Data type	ARRAY [0255]	OF BOOL		Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.	
Usage in user pro-	Possible.	Related in-				
gram		structions				
	=:= a aa.					
		atus.EstbTargetS				
Variable name Meaning	CIP Communication	ations2 Normal T	arget Node In-	Global/local	Global	
	CIP Communication Gives a list of narray[x] is TRU	ations2 Normal Todes that have notes. The connection	arget Node In- ormally establish n to the node wit	led EtherNet/IP connection h a target node ID of x wa	ns for CIP communications 2.	
Meaning	CIP Communication Gives a list of n Array[x] is TRU Array[x] is FALS	ations2 Normal Todes that have noted that have noted that the connections.	arget Node In- ormally establish n to the node wit	led EtherNet/IP connection h a target node ID of x wa	ns for CIP communications 2. s established normally.	
Meaning Function	CIP Communication Gives a list of n Array[x] is TRU Array[x] is FALS red.	ations2 Normal Todes that have noted that have noted that the connections.	arget Node In- ormally establish n to the node wit	led EtherNet/IP connection  h a target node ID of x wa  ith a target node ID of x w	ns for CIP communications 2. as established normally. as not established, or an error occur-	
Meaning Function Data type	CIP Communication formation  Gives a list of n Array[x] is TRU  Array[x] is FALS  red.  ARRAY [0255]	odes that have note: The connections: Th	arget Node In- ormally establish n to the node wit on to the node wi	ned EtherNet/IP connection that arget node ID of x wa that a target node ID of x wa Range of values	ns for CIP communications 2. se established normally. as not established, or an error occur-	
Meaning Function  Data type R/W access Usage in user pro-	CIP Communication formation Gives a list of n Array[x] is TRU Array[x] is FALS red. ARRAY [0255]	odes that have note: The connection SE: The connection OF BOOL  Retained  Related in-	ormally establish n to the node with the nod	ned EtherNet/IP connection that arget node ID of x wa that a target node ID of x wa Range of values	ns for CIP communications 2. se established normally. as not established, or an error occur-	
Function  Data type  R/W access  Usage in user program	CIP Communication formation Gives a list of n Array[x] is TRU Array[x] is FALS red. ARRAY [0255] R Possible.	odes that have note: The connection SE: The connection OF BOOL  Retained  Related in-	ormally establish or to the node with on to the node with	ned EtherNet/IP connection that arget node ID of x wa that a target node ID of x wa Range of values	ns for CIP communications 2. se established normally. as not established, or an error occur-	
Function  Data type R/W access Usage in user program  Variable name	CIP Communication Gives a list of n Array[x] is TRU Array[x] is FALS red. ARRAY [0255] R Possible.  EIP_Comm1Sta	odes that have note: The connections: The connection OF BOOL  Retained  Related instructions	arget Node In- ormally establish n to the node wit on to the node wi Not retained	ned EtherNet/IP connection that arget node ID of x wa that a target node ID of x wa Range of values	ns for CIP communications 2. se established normally. as not established, or an error occur-	
Function  Data type  R/W access  Usage in user pro-	CIP Communication Gives a list of n Array[x] is TRU Array[x] is FALS red.  ARRAY [0255] R Possible.  EIP_Comm1State CIP Communication Mode Shows the oper EtherNet/IP por The array elemons sponding Normal	ations2 Normal Toddes that have noted that hav	narget Node Incormally establish not the node with the nod	Range of values Network Publish  Global/local	Ins for CIP communications 2. Ins established normally. Ins not established, or an error occurate TRUE or FALSE Do not publish.  Global Global Information is TRUE. If the corre us operating status.	
Function  Data type R/W access Usage in user program  Variable name Meaning	CIP Communication Gives a list of n Array[x] is TRU Array[x] is FALS red.  ARRAY [0255] R Possible.  EIP_Comm1State CIP Communication Mode Shows the oper EtherNet/IP por The array elemons sponding Normal	ations2 Normal Toddes that have note: The connection of BOOL  Retained  Related instructions  atus. Target PLCM ations1 Target PL  ating status of the tast the originator of the control on the control of the control	narget Node Incormally establish not the node with the nod	Range of values Network Publish  Global/local  Ontrollers that are connected sponding Normal Target Network Puvio	Ins for CIP communications 2. Ins established normally. Ins not established, or an error occurate TRUE or FALSE Institute Inst	
Function  Data type R/W access Usage in user program  Variable name Meaning  Function	CIP Communication Gives a list of n Array[x] is TRUI Array[x] is FALS red.  ARRAY [0255] R Possible.  EIP_Comm1Sta CIP Communication Mode Shows the oper EtherNet/IP por The array eleme sponding Norma Array[x] is TRUI Array[x] is FALS	ations2 Normal Toddes that have note: The connection of BOOL  Retained  Related instructions  atus. Target PLCM ations1 Target PL  ating status of the tast the originator of the control on the control of the control	narget Node Incormally establish not the node with the nod	Range of values Network Publish  Global/local  ontrollers that are connected esponding Normal Target NE, it indicates the previous tearget Controller with a	Ins for CIP communications 2. It is established normally. It is as not established, or an error occurate of the stablished.  It is a stablished, or an error occurate of the stablished.  It is a stablished, or an error occurate of the stablished.  It is a stablished or an error occurate of the stablished.  It is a stablished or an error occurate of the stablished of the	

Variable name	EIP_Comm2Status.TargetPLCModeSta[255]				
Meaning	CIP Communica	ations2 Target PL	.C Operating	Global/local	Global
	Mode				
Function	Shows the oper	ating status of th	e target node Co	ntrollers that are connecte	ed for CIP communications 2, with the
	EtherNet/IP por	t as the originato	r.		
	The array eleme	ents are valid onl	y when the corre	sponding Normal Target N	Node Information is TRUE. If the corre-
	sponding Norm	al Target Node In	formation is FAL	SE, it indicates the previous	us operating status.
	Array[x] is TRUE: This is the operating state of the target Controller with a node address of x.				
	Array[x] is FALSE: Other than the above.				
Data type	ARRAY [0255] OF BOOL Range of values TRUE or FALSE				
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.
Usage in user pro-	Possible.	Related in-			
gram		structions			

Variable name	EIP_Comm1Status.TargetPLCErr[255]					
Meaning	CIP Communic	CIP Communications1 Target PLC Error Infor- Global/local Global				
	mation					
Function	Shows the erro	r status (logical C	R of fatal and no	on-fatal errors) of the targe	et node Controllers that are connected	
	for CIP commu	nications 1, with t	he EtherNet/IP p	orts as the originator. The	array elements are valid only when	
	the correspond	ng Normal Targe	t Node Information	on is TRUE. The immediat	tely preceding value is retained if this	
	variable is FALS	SE.				
	Array[x] is TRU	Array[x] is TRUE: A fatal or non-fatal error occurred in the target Controller with a target node ID of x.				
	Array[x] is FALS	SE: Other than the	e above.			
Data type	ARRAY [0255]	OF BOOL		Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.	
Usage in user pro-	Possible.	Related in-				
gram		structions				

Variable name	EIP_Comm2Status.TargetPLCErr[255]					
Meaning	CIP Communica	ations2 Target PL	C Error Infor-	Global/local	Global	
	mation					
Function	Shows the error	r status (logical C	R of fatal and no	n-fatal errors) of the targe	t node Controllers that are connected	
	for CIP commu	nications 2, with t	he EtherNet/IP p	orts as the originator. The	array elements are valid only when	
	the correspondi	ng Normal Targe	t Node Informatio	on is TRUE. The immediat	ely preceding value is retained if this	
	variable is FALS	SE.				
	Array[x] is TRU	E: A fatal or non-	fatal error occurr	ed in the target Controller	with a target node ID of x.	
	Array[x] is FALS	SE: Other than the	e above.			
Data type	ARRAY [0255]	Fig OF BOOL Range of values TRUE or FALSE				
R/W access	R	Retained	Not retained. Network Publish Do not publish.			
Usage in user pro-	Possible.	Related in-				
gram		structions				

Variable name	EIP_Comm1Status.TargetNodeErr[255]						
Meaning	CIP Communica	ations1 Target No	ode Error Infor-	Global/local	Global		
	mation						
Function	Indicates that th	ne connection for	the Registered T	arget Node Information fo	r CIP communications 1 was not es-		
	tablished or tha	t an error occurre	ed in the target C	ontroller.			
	The array elem	ents are valid onl	y when the Regis	stered Target Node Inform	ation is TRUE.		
	Array[x] is TRU	E: A connection \	was not normally	established with the targe	t node for a target node ID of x (the		
	Registered Targ	jet Node Informa	tion is TRUE and	the Normal Target Node	Information is FALSE), or a connection		
	was established	d with the target r	node but an error	occurred in the target Cor	ntroller.		
	Array[x] is FALSE: The target node is not registered for a target node ID of x (the Registered Target Node Infor-						
	mation is FALSE), or a connection was normally established with the target node (the Registered Target Node						
	Information is TRUE and the Normal Target Node Information is TRUE). An error occurred in the target Controller						
	(the Target PLC Error Information is TRUE).						
Data type	ARRAY [0255] OF BOOL Range of values TRUE or FALSE						
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.		
Usage in user pro-	Possible.	Related in-					
gram		structions					

Variable name	EIP_Comm2Status.TargetNodeErr[255]					
Meaning	CIP Communica	ations2 Target No	ode Error Infor-	Global/local	Global	
	mation					
Function	Indicates that th	e connection for	the Registered T	arget Node Information fo	r CIP communications 2 was not es-	
	tablished or tha	t an error occurre	ed in the target Co	ontroller.		
	The array eleme	ents are valid onl	y when the Regis	stered Target Node Inform	ation is TRUE.	
	Array[x] is TRU	E: A connection v	was not normally	established with the targe	t node for a target node ID of x (the	
	Registered Targ	jet Node Informa	tion is TRUE and	the Normal Target Node	Information is FALSE), or a connection	
	was established	l with the target n	ode but an error	occurred in the target Cor	ntroller.	
	Array[x] is FALS	SE: The target no	de is not register	ed for a target node ID of	x (the Registered Target Node Infor-	
	mation is FALSE), or a connection was normally established with the target node (the Registered Target Node					
	Information is T	RUE and the No	rmal Target Node	Information is TRUE). Ar	error occurred in the target Controller	
	(the Target PLC	Error Information	n is TRUE).			
Data type	ARRAY [0255] OF BOOL Range of values TRUE or FALSE					
R/W access	R	Retained	Not retained.	Network Publish	Do not publish.	
Usage in user pro-	Possible.	Related in-				
gram		structions				




# Sysmac Studio Settings for the EtherNet/IP Port

This section describes the EtherNet/IP port settings with the Sysmac Studio. The EtherNet/IP port settings are made for each NX-series EtherNet/IP Unit that is connected to the CPU Unit on the Sysmac Studio. Make the EtherNet/IP port settings on the Sysmac Studio under Configurations and Setup - CPU/Expansion Racks - CPU Rack: X Bus - Unit No.: NX-EIP201 () - EtherNet/IP Port Settings.

7-1	TCP/IP Settings Display	7-2
7-2	LINK Settings Display	7-10
7-3	SNMP Settings Display	7-11
7-4	SNMP Trap Settings Display	7-13
7-5	CIP Settings Display	7-15

## 7-1 TCP/IP Settings Display



### • IP Address - Port 1

Set an IP address for the EtherNet/IP port 1.

Setting	Description	Default
IP address setting method	Select one of the following IP address setting methods for the EtherNet/IP port 1.	Fixed setting
	Fixed setting	
	Obtain from BOOTP server.	
	Fix at the IP address obtained from BOOTP server.	
IP address*1	Set the IP address for the EtherNet/IP port 1. *2	192.168.250.1
Subnet mask*2	Set the subnet mask for the EtherNet/IP port 1.	255.255.255.0

<sup>\*1.</sup> This setting is required if you set IP address setting method to Fixed setting.

### IP Address - Port 2

Set an IP address for the EtherNet/IP port 2.

Setting	Description	Default
Use Port 2	Select the check box to use the EtherNet/IP port 2.	Selected
		(use)

<sup>\*2.</sup> Refer to 8-1-2 EtherNet/IP Port IP Address Settings on page 8-4 for details on setting IP addresses.

Setting	Description	Default
IP address setting method	Select one of the following IP address setting methods for the Ether-Net/IP port 2.	Fixed setting
moulou	Fixed setting	
	Obtain from BOOTP server.	
	Fix at the IP address obtained from BOOTP server.	
IP address*1	Set the IP address for the EtherNet/IP port 2. *2	192.168.251.1
Subnet mask*2	Set the subnet mask for the EtherNet/IP port 2.	255.255.255.0

<sup>\*1.</sup> This setting is required if you set IP address setting method to Fixed setting.

<sup>\*2.</sup> Refer to 8-1-2 EtherNet/IP Port IP Address Settings on page 8-4 for details on setting IP addresses.



#### **Precautions for Correct Use**

- You cannot set IP addresses that make two EtherNet/IP ports belong to the same network.
- You can set IP addresses that make EtherNet/IP ports on two or more NX-series EtherNet/IP
   Units that are connected to the X Bus belong to the same network. However, in that case,
   you cannot perform communications by specifying the destination by the IP via the NX-series
   EtherNet/IP Units.

### Default Gateway

Setting	Description	Default
Default gateway*1	Set the IP address of the default gateway for the EtherNet/IP	None
	port. *2	
	This setting is not required when the default gateway is not used.	

<sup>\*1.</sup> If you select **Obtain from BOOTP server** or **Fix at the IP address obtained from BOOTP server** for the IP address setting method, the default gateway obtained from a BOOTP server is enabled.

## Operation at IP Address Duplication

Setting	Description	Default
Use of duplicated IP ad-	When you set an IP address for the EtherNet/IP port and find an	Stop
dress	IP address conflict with another node, select whether to stop the	
	use of the IP address.	
	• Stop	
	If the IP address conflict is not resolved for a certain length of	
	time, the use of the IP address is stopped, and an IP Address	
	Duplication Error will occur.	
	Do not stop	
	IP Address Duplication Error does not occur and you continue	
	to use the IP address that you set. This setting is used if you	
	want to avoid that communications are stopped because the	
	same IP address is assigned to more than one node.	



#### **Precautions for Correct Use**

If this setting is **Do not stop**, it is not notified that the same IP address is assigned to more than one node to the user. Also, if the same IP address is assigned to more than one node while this setting is **Do not stop**, the communications may become unstable, such as being temporarily unavailable. If it is unacceptable for the communication to be unstable, detect that the same IP address is assigned to more than one node to the remote node.

<sup>2.</sup> Even if you are using both of port 1 and port 2, you can set the default gateway for only one of the ports.

### Host Name

Setting	Description	Default
Host Name	Set the host name for the local Unit. The local host name can be set for each Unit. The set host name is set to sysName of the system group and IldpLocSysName of the Ildp group in the MIB	None*3
	(Management Information Base). *1*2 (Single-byte alphanumeric characters, dots, and hyphens: 63 characters max.)	

<sup>\*1.</sup> Since the local host name identifies the Unit, set the name so that it does not use the same name in the same network.

### DNS

Setting	Description	Default
Use/ Do not use DNS	When you specify a host name for SNMP function, select the Use Option if you use DNS for resolving host name.  A DNS server is required to use DNS.	Do not use
Priority DNS server*1 Secondary DNS server	Set the IP address of the DNS server. You can set priority and secondary IP addresses.	None None
Domain name <sup>*1</sup>	Set the domain name of the domain to which the EtherNet/IP port belongs. (Single-byte alphanumeric characters, dots, and hyphens: 48 characters max.)	None

<sup>\*1.</sup> These settings are required if you select the **Use** Option for **DNS**.

## Host Name - IP Address

Setting	Description	Default
Host Name	Addresses are converted according to this setting when a host name is used to specify remote communications nodes.  Host names can be set whether DNS is used or not.  You can set up to six host names.  (Single-byte alphanumeric characters, dots, and hyphens: 200 characters max. with up to 63 single-byte alphanumeric characters.	None
	ters between dots.)	
IP Address	Set the IP address of the registered host name.	None

<sup>\*2.</sup> Refer to 11-1-4 MIB Specifications on page 11-4 for details on the MIB.

<sup>\*3.</sup> If you do not set the local host name, the model of the Unit will be the local host name.

## Keep Alive

Setting	Description	Default
Keep Alive	Set whether to use the remote node Keep Alive function of connected servers and clients (such as Sysmac Studio and FINS/TCP) for each connection number.  If the Use Option is selected for Keep Alive and no communications are performed with the remote node for the Keep Alive monitoring time, transmission of Keep Alive packets is started. The connection will be disconnected if the remote node does not respond for longer than five times the total time of Keep Alive packet transmission + five seconds for resending.*1  The connection to the remote node is left open if the power supply to the remote node is turned OFF without warning. Select the Use Option for Keep Alive wherever possible.  • Use • Do not use	Use
Keep Alive monitoring time	This is a set period of time before the transmission of Keep Alive packets is started.  Setting range: 1 to 65,535 (seconds)	300
Linger option	Set whether to specify the Linger Option.  If the Linger Option is specified, the port number is immediately opened even before the port number is released after the TCP port closes (approx. 1 minute).  • Specify  • Do not specify	Do not specify

<sup>\*1.</sup> If the remote node does not respond, the connection is disconnected after the Keep Alive monitoring time + 30 seconds.

## IP Router Table

Setting	Description	Default
Destination IP Address	Set these settings when the EtherNet/IP port is used for tag data	None
Destination Mask IP Ad-	links or CIP message communications with nodes on other IP	
dress	network segments via an IP router.	
Gateway Address	You can set up to 64 combinations of an IP address and a gate-	None
,	way address.	
	Specify 0 for the host portions of the IP addresses.	




#### **Additional Information**

#### **IP Router Table Setting Example**

Set the following IP router table on the node A device to use tag data links or CIP message communications between node A and node B through the IP router.

For an NX-series CPU Unit or an NX-series EtherNet/IP Unit, set **Port Forward** - **IP Forward** to **Use** 

If you set the IP router table and execute a communications instruction from node A to node B, node A sends packets addressed to the gateway IP address (130.25.36.253).



The host fields are set to 0 in the destination IP address.

#### Port Forward

Setting	Description	Default
IP Forward	Select whether to transfer IP packets between communications	Do not use
	ports.	

The following shows the applications that are not supported by the NX-series EtherNet/IP Unit, and they are classified by whether this function is valid or invalid. In applications for which this function is invalid, the IP packets are not transferred even if the **Use** Option is selected.

Valid/Invalid	Application
Valid	Socket communications, secure socket communications, FTP server, FTP client, NTP client,
	DB connection service, Modbus/TCP communications, MQTT communications
Invalid	FINS/UDP, FINS/TCP, DHCP client, OPC UA, SECS/GEM connection service, Robot inte-
	grated

#### TCP/UDP Port Transfer

Setting	Description	Default
Port	Set the TCP port or UDP port that is used for TCP/IP communications if you want to access the CPU Unit via the EtherNet/IP port on the NX-series EtherNet/IP Unit from an external device such as a computer. This setting is set for each EtherNet/IP port. *1*2	None
	Port1     Port2	
Protocol	Set the protocol used for communications.  TCP  UDP	None

Setting	Description	Default
Port Number	Set the port number used for communications. *3	None
	Setting range: 1 to 65,535	

<sup>\*1.</sup> To use this function, select the **Use** Option for **IP Forward** in the port forward. If the **Do not use** Option is selected, the sent frames will be discarded.

- \*2. On the client side of the external device, specify the IP address of the EtherNet/IP port on the NX-series EtherNet/IP Unit and send the frame.
- \*3. Specify a port number that is not used by the NX-series EtherNet/IP Units. Refer to A-7 TCP/UDP Port Numbers Used for the NX-series EtherNet/IP Unit on page A-55 for details on the TCP/UDP port numbers that are used by the NX-series EtherNet/IP Units.

The following shows the applications that are not supported by the NX-series EtherNet/IP Unit, and they are classified by whether this function is valid or invalid. The invalid applications cannot access the CPU Unit even if the **Protocol** or **Port Number** are set.

Valid/Invalid	Application
Valid	Socket communications, secure socket communications, FTP server, MQTT communications
Invalid	FTP client, NTP client, FINS/UDP, FINS/TCP, DB connection service, Modbus/TCP communications, DHCP client, OPC UA, SECS/GEM connection service, Robot integrated

#### Packet Filter

For information on usage and restrictions of Packet Filter, refer to 8-4 Packet Filter on page 8-15.

Setting	Description	Default
Packet Filter	Select whether to use Packet Filter or not.	Do not use
	Use	
	Do not use	
Source	Set the conditions for the source.	
IP Address Specifi-	Select the method for specifying the IP address of the source.	any
cation Method	any*1	
	IP address specification	
IP Address	If the IP address specification method is IP address specification, set	None
	the source IP address.*2	
Mask	If the IP address specification method is IP address specification, set	None
	the mask of source IP address.*3	
Destination	Set the conditions for the destination.	
IP Address Specifi-	Same as those for the source.	
cation Method		
IP Address		
Mask		
Protocol	Set the communications protocol.	any
	any <sup>*4</sup>	
	tcp	
	udp	
	igmp <sup>*5</sup>	
	icmp <sup>*6</sup>	
Source Port	If <b>tcp</b> or <b>udp</b> is selected for Protocol, set the source port conditions.	

	Setting	Description	Default
	Specification Method	Select the method for specifying the IP packets of the source port.  any <sup>*7</sup> Port specification	any
	Range Specification	Specify whether or not to set the port range if the specification method selected is <b>Port specification</b> .  If it is selected, reception from the source ports from the <b>Start Number</b> to the <b>End Number</b> is allowed.  If it is not selected, reception from the source port specified by the <b>Start Number</b> is allowed.  No check. Checked.	No check.
	Start Number	Set the start number when <b>Port specification</b> is selected for the specification method.  1 to 65535	None
	End Number	Set the end number when the specification method is <b>Port</b> specification and the range specification is selected.  1 to 65535	None
Destir	nation Port	Set the conditions for the destination port if tcp or udp is selected for Pro	otocol.
	Specification Method	Same as the settings for the source port.	
	Range Speci- fication		
	Start Number		
	End Number		

<sup>\*1.</sup> If you select any, packets from any IP addresses will be allowed.

The following is an example of how to calculate the allowed IP addresses.

#### Example 1. Allowing IP address 192.168.250.1

If you want to allow one IP address, set 255.255.255.255 to the mask.

Setting	Decimal notation	Binary notation
IP address	192.168.250.1	11000000.10101000.11111010.00000001
Mask	255.255.255.255	11111111.11111111.11111111.11111111

### Example 2. Allowing IP address 192.168.250.\*\*\*

Set 255.255.255.0 to the mask to mask the lower 8 bits of the IP address.

Setting	Decimal notation	Binary notation
IP address	192.168.250.0	11000000.10101000.11111010.00000000
Mask	255.255.255.0	11111111.11111111.11111111.00000000

#### Example 3. Allowing IP address 192.168.250.1 to 192.168.250.31

Set 255.255.255.224 to the mask to mask the lower 5 bits if the IP address.

Setting	Decimal notation	Binary notation
IP address	192.168.250.0	11000000.10101000.11111010.00000000
Mask	255.255.255.224	11111111.11111111.11111111.11100000

\*3. Set 0 to the bits to be masked in **Mask**. Multiple bits can be masked, but only bits from the least significant can be masked. It is not possible to mask the higher bits, such as 0.255.255.255, or the middle bits, such as 255.0.255.255.

The following are examples of setting a mask.

<sup>\*2.</sup> The allowed IP address is calculated by the logical AND of the **IP address** and the **Mask**. If you want to allow more than one IP address, mask a part of the IP address by setting the **Mask**. In this case, set 0 to the bits to be masked in the **IP address** and **Mask**.

### Example 1. Masking the lower 8 bits

Set 0 to the lower 8 bits.

Setting	Decimal notation	Binary notation
Mask	255.255.255.0	11111111.11111111.11111111.00000000

#### Example 2. Masking the lower 24 bits

Set 0 to the lower 24 bits.

Setting	Decimal notation	Binary notation
Mask	255.0.0.0	11111111.00000000.00000000.00000000

- \*4. If you select any, packets from tcp, udp, igmp, and icmp will be allowed.
- \*5. Select igmp when EtherNet/IP tag data links are used for multicast and the EtherNet/IP is specified as the originator.
- \*6. Select icmp for receiving Ping requests.
- \*7. If you select any, packets from any TCP/UDP port are allowed.

## 7-2 LINK Settings Display



## Link Settings - Port 1 and Port 2

Set for each EtherNet/IP port.

Setting	Description	Default
LINK settings	Set the baud rate for the EtherNet/IP ports.	
	Auto	


### LLDP Settings - Port 1 and Port 2

Set for each EtherNet/IP port.

Setting	Description	Default
LLDP*1	Select whether to use LLDP (Link Layer Discovery Protocol)	Use
	function.	
	• Use	
	Do not use	

<sup>\*1.</sup> When the LLDP function is used, the Controller can exchange various information such as identification information with the network devices that are located within the range of physical communication. Information on network devices can be obtained with the SNMP function.

## 7-3 SNMP Settings Display



#### SNMP

Setting	Description	Default
SNMP service	Specify whether to use the SNMP monitor service.*1  If the <b>Do not use</b> Option is selected, an SNMP manager cannot connect from an external device.	Do not use
Port No.*2	Set the port number to use to connect to the SNMP server that is used to connect from an SNMP manager. This setting does not normally need to be changed.	161
Address	Set the communications device administrator's name and instal-	None
Location	lation location as text information. You do not necessarily have to input all items. This information is read by the SNMP manager. (You can input up to 255 single-byte alphanumeric characters for each item.)	None
Send a recognition	Set whether to send an authentication trap.	Not selected
trap	If you select <b>Send a recognition trap</b> and there is access from	
	an SNMP manager that is not set in Recognition 1 or Recognition	
	2, an authentication trap is sent to the SNMP manager.	
	If you select <b>Send a recognition trap</b> , specify the SNMP trap	
	settings on the <b>SNMP Trap</b> Tab.	

<sup>\*1.</sup> If you select the Use Option for the SNMP service, you also have to set Recognition 1 and 2 as described below.

<sup>\*2.</sup> The following ports are used by the system and cannot be set by the user: 25, 53, 68, 110, 2222, 2223, 2224, 9600, and 44818.



#### **Additional Information**

Refer to Section 11 SNMP Agent on page 11-1 for details on the SNMP service.


## • Recognition 1

Setting	Description	Default
Recognition method	Set the method to use to specify SNMP managers for which ac-	IP address
	cess is permitted.	
	IP address	
	Host name	
	Make these settings to permit access by only certain SNMP	
	managers.	
	Access is not allowed unless an IP address or host name is set.	
IP address	Set the IP address of the SNMP manager.	None
	If the default setting of 0.0.0.0 is used, access by all SNMP man-	
	agers is permitted.	
	(Set this setting if <b>Recognition method</b> in Recognition 1 is set to	
	the IP address Option.)	
Host name	Set the host name of the SNMP manager.	None
	(Set this setting if <b>Recognition method</b> in Recognition 1 is set to	
	the <b>Host name</b> Option.)	
	(Single-byte alphanumeric characters, dots, and hyphens: 200	
	characters max. with up to 63 single-byte alphanumeric charac-	
	ters between dots.)	
Community name	Set the community name to enable the SNMP manager to ac-	public
	cess information from the EtherNet/IP port.	
	(Single-byte alphanumeric characters, dots, and hyphens: 255	
	characters max.)	

## • Recognition 2

Setting	Description	Default
Recognition 2	Specify whether to use the recognition 2 settings.  • Use  • Do not use	Do not use
Recognition method	Set the method to use to specify SNMP managers for which access is permitted.  • IP address  • Host name  Make these settings to permit access by only certain SNMP managers.  Access is not allowed unless an IP address or host name is set.	IP address
IP address	Set the IP address of the SNMP manager.  If the default setting of 0.0.0.0 is used, access by all SNMP managers is permitted.  (Set this setting if <b>Recognition method</b> in Recognition 2 is set to the <b>IP address</b> Option.)	None
Host name	Set the host name of the SNMP manager. (Set this setting if <b>Recognition method</b> in Recognition 2 is set to the <b>Host name</b> Option.) (Single-byte alphanumeric characters, dots, and hyphens: 200 characters max. with up to 63 single-byte alphanumeric characters between dots.)	None
Community name	Set the community name to enable the SNMP manager to access information from the EtherNet/IP port. (Single-byte alphanumeric characters, dots, and hyphens: 255 characters max.)	public

## 7-4 SNMP Trap Settings Display



## SNMP Trap

Setting	Description	Default
SNMP trap	Specify whether to use the SNMP trap (network error detection).*1	Do not use
	If the <b>Do not use</b> Option is selected for SNMP trap, SNMP traps are not sent to the SNMP manager	
Port No.*2	Set the port number to use to connect to the SNMP server. It is normally not necessary to change this setting.	162

<sup>\*1.</sup> If you specify to use the SNMP trap, you also have to set Trap 1 and Trap 2 as described below.

<sup>\*2.</sup> The following ports are used by the system and cannot be set by the user: 25, 53, 68, 110, 2222, 2223, 2224, 9600, and 44818.



### **Additional Information**

Refer to 11-1-1 Overview on page 11-2 for details on the SNMP trap.

### Trap 1

If the **Use** Option is selected for **SNMP trap**, you need to make the following settings.

Setting	Description	Default
Specifying method	Set the specifying method for the SNMP manager destination for SNMP traps.  • IP address	IP address
	Host name	
IP address	Set the IP address of the SNMP manager. (Set this setting if the <b>Specifying method</b> in the Trap 1 settings is set to the <b>IP address</b> Option.)	None

Setting	Description	Default
Host name	Set the host name of the SNMP manager. (Set this setting if the <b>Specifying method</b> in the Trap 1 settings is set to the <b>Host name</b> Option.) (Single-byte alphanumeric characters, dots, and hyphens: 200 characters max. with up to 63 single-byte alphanumeric characters.	
Community name	ters between dots.)  Set the community name.  (You can use up to 255 single-byte alphanumeric characters.)	public
Version	Set the version of the SNMP manager.  • SNMPv1  • SNMPv2C	SNMPv2C

## • Trap 2

If the Use Option is selected for SNMP trap, you need to make the following settings.

Setting	Description	Default
Trap 2	Specify whether to use the Trap 2 settings.  • Use  • Do not use	Do not use
Specifying method	Set the specifying method for the SNMP manager destination for SNMP traps.  • IP address  • Host name	IP address
IP address	Set the IP address of the SNMP manager. (Set this setting if the <b>Specifying method</b> in the Trap 2 settings is set to the <b>IP address</b> Option.)	None
Host name	Set the host name of the SNMP manager. (Set this setting if the <b>Specifying method</b> in the Trap 2 settings is set to the <b>Host name</b> Option.) (Single-byte alphanumeric characters, dots, and hyphens: 200 characters max. with up to 63 single-byte alphanumeric characters between dots.)	None
Community name	Set the community name. (You can use up to 255 single-byte alphanumeric characters.)	public
Version	Set the version of the SNMP manager.  • SNMPv1  • SNMPv2C	SNMPv2C

## 7-5 CIP Settings Display



## CIP Message Server

Setting	Description	Default
CIP Message Server	Specify whether to use the CIP message server or not.	Use
	If the <b>Use</b> Option is selected, the following ports will be opened.	
	• UDP 2222	
	• UDP 44818	
	• TCP 44818	

Refer to 10-3 Server Function of CIP Message Communications on page 10-23 for restrictions when the **Do not use** Option is selected for CIP message server.

#### QoS

Setting	Description	Default
Prioritize CIP Safety	Select whether to prioritize CIP Safety communications in QoS.	Do not use
communication		

7.0	0 111	E(I N (//D D (
/ Sysmac Studio	Settings for the	EtherNet/IP Port



## **TCP/IP Functions**

8-1	<b>Determ</b> 8-1-1 8-1-2 8-1-3	Ining IP Addresses IP Addresses EtherNet/IP Port IP Address Settings Private and Global Addresses	8-2 8-4
8-2	Default	States of TCP/UDP Ports and the Changing Procedure	8-12
8-3	<b>Testing</b> 8-3-1 8-3-2 8-3-3	PING Command	8-13 8-13
8-4	Packet 8-4-1	Filter	
	8-4-2 8-4-3 8-4-4	Packet Filter Specifications	8-15 8-16


## 8-1 Determining IP Addresses

## 8-1-1 IP Addresses

## **IP Address Configuration**

IP addresses are made up of 32 bits of binary data that specify the network number (net ID) and host number (host ID). The net ID is an address used for identifying a network. The host ID is an address used for identifying a host (node).

IP addresses are divided into three classes, A, B, and C, so that the address system can be selected according to the scale of the network. (Classes D and E are not used.)



The number of networks in each class and the number of hosts possible on the network differ according to the class.

Class	Number of networks	Number of hosts
Class A	Small	2 <sup>24</sup> –2 max. (16,777,214 max.)
Class B	Medium	2 <sup>16</sup> –2 max. (65,534 max.)
Class C	Large	2 <sup>8</sup> –2 max. (254 max.)

The 32 bits of binary data in an IP address are divided into four sections of eight bits each. IP addresses are represented by the decimal equivalent of each of the four octets in the 32-bit address, each separated by a period.

For example, the binary address 10000010 00111010 00010001 00100000 would be represented as 130.58.17.32.

## **Allocating IP Addresses**

You must assign IP addresses nodes so that each IP address is assigned only once in the network or between several networks.


## **Subnet Mask**

Operation and management of a network can become very difficult if too many nodes are connected on a single network. In such a case it can be helpful to configure the system so that a single network is divided up into several subnetworks. Internally the network can be treated as a number of subnetworks, but from the outside it acts as a single network and uses only a single network ID.

To establish subnetworks, the host ID in the IP address is divided into a subnet ID and a host ID by using a setting called the subnet mask.

The subnet mask indicates which part of the host ID is to be used as the subnet ID. All bits in the subnet mask that correspond to the bits in the IP address used either as the network ID or subnet ID are set to "1", and the remaining bits, which correspond to the bits in the IP address actually used for the host ID, are set to "0".

The following example shows the subnet mask for an 8-bit subnet ID used in the class-B IP address.



Set the same subnet mask for all of the nodes on the subnetwork. The EtherNet/IP port supports CIDR (Classless Inter-Domain Routing). The subnet mask can be set to 192.0.0.0 to 255.255.255.252. If subnetworks are not used, set the following subnet mask values for IP address classes A to C.

Class	Subnet mask
Class A	255.0.0.0
Class B	255.255.0.0
Class C	255.255.255.0

A network address is information derived from a subnet mask and used to identify each network. A network address enables users to determine whether multiple nodes belong to the same network. A network address is calculated by performing a logical AND operation on the IP address and subnet mask of a node.

The following are examples of network address calculation.

In this example, the IP address of node 1 is set to 192.168.250.20, the IP address of node 2 is set to 192.168.245.30, and the subnet mask is set to 255.255.240.0. The network addresses of the two nodes are calculated as follows.

· Calculating network address of node 1

Item	Decimal notation	Binary notation
IP address	192.168.250.20	11000000.10101000.11111010.00010100
Subnet Mask	255.255.240.0	11111111.11111111.11110000.00000000
Network address	192.168.240.0	11000000.10101000.11110000.00000000

Calculating network address of node 2

Item Decimal notation		Binary notation
IP address	192.168.245.30	11000000.10101000.11111010.00010100
Subnet Mask	255.255.240.0	11111111.11111111.11110000.00000000
Network address	192.168.240.0	11000000.10101000.11110000.00000000

As shown in the above tables, node 1 and node 2 have the same network address, which means these nodes belong to the same network.

## **CIDR**

CIDR, or classless interdomain routing, is used to assign IP addresses that do not use classes.

IP addresses that use classes are separated into blocks according to network IDs and host IDs, resulting in inefficient usage of IP address space.

CIDR does not use classes, so IP address space can be divided as required to more efficiently use IP address space.

For example, using a subnet mask setting with CIDR enables building a horizontally distributed network exceeding 254 nodes even if a class C address block (e.g., 192, 168...) is used.

Subnet Mask Range	
192.0.0.0 to 255.255.255.252	

## 8-1-2 EtherNet/IP Port IP Address Settings

## **Determining IP Addresses**

Use one of the following methods to set an IP address of an EtherNet/IP port.

## Setting a User-specified IP Address


If you need to change the default IP address of the EtherNet/IP port or if you need to use the EtherNet/IP port with another EtherNet/IP node, set the IP address to a required value.

You cannot set IP addresses that make two EtherNet/IP ports belong to the same network.

## Automatically Obtaining an IP Address from the BOOTP Server

There are two methods to automatically obtain an IP address.


- Obtain an IP address from the BOOTP server each time the power is turned ON.
- Obtain an IP address from the BOOTP server at initial power on and set the address as a fixed IP address.



## **Setting IP Addresses**

Use the Sysmac Studio to set an IP address of the EtherNet/IP port.

Select a method for setting the IP address.
Select the IP address setting method as follows on the TCP/IP Settings Display under
Configurations and Setup - CPU/Expansion Racks - CPU Rack: X Bus - Unit No.: NX-EIP201 () - EtherNet/IP Port Settings.



The IP addresses must be set separately for EtherNet/IP ports 1 and 2.



#### **Precautions for Correct Use**

- You cannot set IP addresses that make two EtherNet/IP ports belong to the same network.
- You can set IP addresses that make EtherNet/IP ports on two or more NX-series EtherNet/IP
   Units that are connected by the X Bus belong to the same network. However, in that case,
   you cannot perform communications by specifying the destination by the IP via the NX-series
   EtherNet/IP Units.
- **2** Connect the Sysmac Studio.
- **3** Connect the Sysmac Studio online to the CPU Unit.

  Refer to *Online Connection* on page 8-6 for the procedure to connect online.
- 4 Use one of the following methods to download the IP address setting that was set on the Sysmac Studio to the CPU Unit.
  - Go online with the Controller, and then select Synchronization from the Controller Menu.
     The data on the computer and the data in the physical Controller are compared automatically.
  - 2) Click the Transfer to Controller Button.

Note Use the "synchronization" of the Sysmac Studio to upload and download data.

Note Since only the IP address for the NX-series EtherNet/IP Unit is set here, do not select **Do not transfer the following. (All items are not transferred.)** Check Box in the Synchronization Window on the Sysmac Studio.

- **5** After the IP address settings are downloaded, the IP address is reflected in the NX-series EtherNet/IP Unit as follows:
  - Setting a User-specified IP Address

After the IP address settings are downloaded, the set IP address is automatically reflected in the NX-series EtherNet/IP Unit.

Obtaining the IP Address from the BOOTP Server Each Time the Power Is Turned ON

After the IP address settings are downloaded, the IP address from the BOOTP server is automatically reflected in the NX-series EtherNet/IP Unit.

Each time the power supply is turned ON, the IP address from the BOOTP server is automatically reflected in the NX-series EtherNet/IP Unit.



#### **Additional Information**

If the Unit cannot obtain the IP address from the BOOTP server or the obtained IP address is not correct, select the **Fixed setting** Option in the **IP Address** Area and manually set the IP address, subnet mask, and default gateway.

Requests to the BOOTP server for an IP address will continue if connecting to the BOOTP server fails.

 Obtaining the IP Address from the BOOTP Server When the Power Is Turned ON and Fixing at It

After the IP address settings are downloaded, the IP address from the BOOTP server is automatically reflected in the Controller and set for **Fixed setting**.



#### **Additional Information**

- The TCP/IP Settings Display is not updated even if the IP address is obtained normally from the BOOTP server.
  - To check the IP address that was obtained from the BOOTP server, upload the project from the NJ/NX-series Controller and check the Controller Status Pane.
- If you cannot obtain the IP address from the BOOTP server, the Fix at the IP address
  obtained from BOOTP server Option is selected on the TCP/IP Settings Display.
  To stop obtaining the IP address from the BOOTP server, select Fixed setting in the IP
  Address Area and manually set the IP address, subnet mask, and default gateway.
- If the Controller power supply is turned OFF and then ON after the IP address was not normally obtained from the BOOTP server, the setting remains at Fix at the IP address obtained from BOOTP server.
- After you select Fix at the IP address obtained from BOOTP server and download the IP
  address from the BOOTP server, the EtherNet/IP port IP address setting is automatically set
  to Fixed setting. Therefore, the IP address will not match when the program is verified on
  the Sysmac Studio.
- To use the Packet Filter, you must allow packets (UDP:68) used for BOOTP. Refer to 8-4-4 Settings for Devices That Access the Controller on page 8-17 for details on the settings.

### **Online Connection**

Connect the Sysmac Studio online to the CPU Unit.



#### Additional Information

For the procedure to go online to the CPU Unit from the Sysmac Studio, refer to *Online Connections to a Controller* in the *Sysmac Studio Version 1 Operation Manual (Cat. No. W504)*.


 Types of Connection between the CPU Unit and Computer That Runs the Sysmac Studio

The CPU Unit and the computer that runs Sysmac Studio are connected via Ethernet as shown below:

## Direct Connection via Ethernet (1:1 Connection with Auto IP)

### Ethernet Connection via a Hub (1:N Connection)





- \*1. An Ethernet switch is not necessarily required.
- \*2. You can use a straight or cross Ethernet cable to connect.
- \*3. 1:1 connection is supported only for the built-in EtherNet/IP port 1 on the NX502 CPU Units.

\*1. An Ethernet switch is required to connect. Refer to 5-1-4 Precautions for Ethernet Switch Selection on page 5-4 for details.



#### **Precautions for Correct Use**

If you connect the computer that runs the Sysmac Studio to the EtherNet/IP port on the NX-series EtherNet/IP Unit, you cannot use direct connection via Ethernet. Use the Ethernet connection via a hub through an Ethernet switch. In that case, you must specify the destination IP address.



#### **Precautions for Correct Use**

If there is more than one node with the same IP address in the EtherNet/IP network, the EtherNet/IP port will connect to the node that is detected first.

Note that an IP Address Duplication Error will not be detected in this case.


#### Online Connection Procedure

Connect the CPU Unit and the computer that runs the Sysmac Studio via Ethernet, and then perform the following procedure.


Select Controller - Communications Setup and click the OK Button in the Sysmac Studio Project Window.

#### 1:1 Connection

Direct Connection



## 1:N Connection Ethernet Connection





#### **Additional Information**

If there is any error in the set IP address, the CPU Unit behaves as follows:

- The NET RUN indicator on the CPU Unit does not light and the NET ERR indicator flashes red. Indicators will indicate the status of each EtherNet/IP port.
- · An IP Address Setting Error is recorded in the event log.



#### **Precautions for Correct Use**

- If the IP address is duplicated or not set correctly, communications are not possible via the EtherNet/IP network. Set the IP address again.
- The IP address range shown below is used by the system and cannot be specified. 169.254.0.0 to 169.254.255.255
   192.168.255.0 to 192.168.255.255
- Due to Ethernet restrictions, you cannot specify the following IP addresses.
  - a) An IP address that is all 0's or all 1's
  - b) IP addresses that start with 127, 0, or 255 (decimal)
  - c) IP addresses that have a host ID that is all 0's or all 1's
  - d) Class-D IP addresses (224.0.0.0 to 239.255.255.255)
  - e) Class-E IP addresses (240.0.0.0 to 255.255.255.255)

## Connecting from a Saved Project

The connection configuration that is set (via EtherNet/IP) is saved in the project.

When you open a saved project on the Sysmac Studio, you can connect to the EtherNet/IP network without redoing the settings.


## **Checking the Current IP Address**

The current IP address can be confirmed in the Controller Status Pane of the Sysmac Studio, whether it is manually set or obtained from the BOOTP server.

· Basic Controller Status Pane



· Controller Status Pane with Details





#### **Additional Information**

- If the IP address of the EtherNet/IP port is not registered due to the following reasons, the IP address field shows "0.0.0.0".
  - The IP address was not obtained from the BOOTP server.
  - The EtherNet/IP port is disabled. Refer to 7-1 TCP/IP Settings Display on page 7-2 for details on the settings for the IP address of the EtherNet/IP port.


## 8-1-3 Private and Global Addresses

## **Private and Global Addresses**

There are two kinds of IP addresses, private and global.

Global address	These are IP addresses that connect directly to the Internet. Allocated by application to NIC, each address is unique in the world, and as many as 4.3 billion can be allocated worldwide.
Private address	These are IP addresses for Intranet (LAN) use. Direct connection to the Internet is not possible. Frames that include private IP addresses are restricted by the router from being sent outside the LAN.

Generally, as shown below, global addresses in the intranet are allocated only to IP routers (such as broadband routers) interfaced with the Internet. All other nodes in the intranet, which includes the EtherNet/ IP port, are allocated private addresses.



## Intranet CIP client on a Explicit message computer, such as Sysmac Studio or Network Configurator Ethernet(EtherNet/IP) Communications in intranet IP router EtherNet/IP port: Private address Intranet Explicit message CIP client on a IP router computer, such as Sysmac Studio or Network Configurator Communications in intrane Ethernet(EtherNet/IP) Communications in EtherNet/IP port: Private address EtherNet/IP port: Private address

## Using a Private Address for the EtherNet/IP Port

#### Conditions for Communications Applications

If the EtherNet/IP port uses a private address, you can use explicit message communications service under the following conditions.

- The explicit message communications service can be executed on the intranet between Ether-Net/IP ports with private addresses only.
- A device such as a personal computer (CIP applications including the Network Configurator)
  cannot connect online and communicate over the Internet with an EtherNet/IP port that has a private address.


Explicit message communications are also not possible over the Internet between EtherNet/IP ports with private addresses.



### **Precautions for Correct Use**

- To set up an intranet through a global address involves network security considerations. Be sure to consult with a network specialist in advance and consider installation of a firewall.
- Some communication applications may not be available depending on the firewall settings made by the communications company. If there are communication applications that cannot be used, be sure to check with your communications company.
- When sending and receiving data over a global address, use secure communications, such as secure socket communications and OPC UA, that ensure confidentiality and integrity.

## Using a Global Address for the EtherNet/IP Port



## Conditions for Communications Applications

You can use the explicit message communications service over the Internet under the following conditions.

- A device such as a personal computer (a CIP application including the Network Configurator)
  can connect online and communicate over the Internet with an EtherNet/IP port that has a global
  address.
- The TCP port number (44818) or UDP port number (44818) that is used for EtherNet/IP cannot be used because it is prohibited by a firewall in the communications path.



#### **Precautions for Correct Use**

- To set a global IP address for an EtherNet/IP port involves network security considerations. It is recommended that the user contract with a communications company for a dedicated line, rather than for a general line such as a broadband line. Also, be sure to consult with a network specialist and consider security measures such as a firewall.
- Some communication applications may not be available depending on the firewall settings
  made by the communications company. If there are communication applications that cannot
  be used, be sure to check with your communications company.
- When sending and receiving data over a global address, use secure communications, such
  as secure socket communications and OPC UA, that ensure confidentiality and integrity.

# 8-2 Default States of TCP/UDP Ports and the Changing Procedure

The following table shows the applications that use TCP/UDP ports for which a user can change the port state, port numbers, default port states, usages, and how to change a port from open to close and close to open.

Refer to A-7 TCP/UDP Port Numbers Used for the NX-series EtherNet/IP Unit on page A-55 for information on all TCP/UDP ports of the NX-series EtherNet/IP Unit.

Application	UDP port num- ber	TCP port num- ber	De- fault port state	Usage	How to change from open to close	How to change from close to open
SNMP	161		Close	Used when using the SNMP agent.	On the Sysmac Studio, select EtherNet/IP Port Settings - SNMP Settings, and then select Do not use for SNMP service.	On the Sysmac Studio, select EtherNet/IP Port Settings - SNMP Settings, and then select Use for SNMP service.
HTTPS serv- er		443	Open	Used for com- munications with the Sys- mac Studio.	Use the Packet Filter. *1	Use the Packet Filter.
Sysmac Stu- dio	9600		Open	Used for com- munications with the Sys- mac Studio.	Use the Packet Filter. *2	Use the Packet Filter.
CIP messages	44818	44818	Open	Used for the CIP messag- es.	On the Sysmac Studio, select EtherNet/IP Port Settings - CIP Settings, and then select Do not use for CIP Message Server.	On the Sysmac Studio, select EtherNet/IP Port Settings - CIP Settings, and then se- lect Use for CIP Message Server.

<sup>\*1.</sup> Closing the port may prevent communications with the Sysmac Studio and the NA-series HMI. Refer to Troubleshooting when support software cannot go online in the NJ/NX-series Troubleshooting Manual (Cat. No. W503) on how to make corrections.

<sup>\*2.</sup> Closing the port may prevent communications with the Sysmac Studio. Refer to *Troubleshooting When You Cannot Go Online from the Sysmac Studio* in the *NJ/NX-series Troubleshooting Manual (Cat. No. W503)* on how to make corrections.


## 8-3 Testing Communications

If the basic settings (in particular the IP address and subnet mask) are made correctly for the Ether-Net/IP port, then it is possible to communicate with nodes on the Ether-Net/IP network.

This section describes how to use the PING command to test communications with the EtherNet/IP port.

### 8-3-1 PING Command

The PING command sends an echo request packet to a remote node and receives an echo response packet to confirm that the remote node communications are normal. The PING command uses the ICMP echo request and response. The echo response packet is automatically returned in the ICMP. The PING command is normally used to check the connections of remote nodes when you set up a network. The EtherNet/ IP port supports both the ICMP echo request and response functions. If the remote node returns a normal response to the PING command, then the node is physically connected correctly and Ethernet node settings are correct.



## 8-3-2 Using the PING Command

The EtherNet/IP port automatically returns an echo response packet in response to an echo request packet by a PING command sent by another node (e.g., host computer).



#### **Precautions for Correct Use**

When the **Use** Option is selected for Packet Filter of the EtherNet/IP port, PING command cannot be received unless **icmp** is selected for **Protocol** of Pacekt Filter settings. Refer to *Packet Filter* on page 7-7 for details on the settings.

## 8-3-3 Host Computer Operation

The PING command can be executed from the host computer to an EtherNet/IP port. The following example shows how to use the PING command in the host computer.

## **Application Method**

Input the following command at the host computer's prompt (\$):

\$ ping IP\_address (host\_name)

The destination is specified by its IP address or host name.



#### **Additional Information**

The PING command is not supported by some host computers.

## **Application Example**

In this example, a PING command is sent to the node at IP address 130.25.36.8. The "\$" in the example represents the host computer prompt.

#### Normal Execution

```
$ ping 130.25.36.8 ← Executes the PING command.

PING 130.25.36.8: 56 data bytes
64 bytes from 130.25.36.8: icmp_seq=0. time=0. ms
64 bytes from 130.25.36.8: icmp_seq=0. time=0. ms
∴ ∴ ∴ ∴ ∴ ∴
64 bytes from 130.25.36.8: icmp_seq=0. time=0. ms
← Press the Ctrl+C Keys to cancel execution.

---- 130.25.36.8 PING Statistics----
9 packets transmitted, 9 packets received, 0% packets loss
round-trip (ms) min/avg/max = 0/1/16
$
```

#### Error

Refer to the command reference manual for your computer's OS for details on using the PING command.


## 8-4 Packet Filter

This section provides an overview of Packet Filter, explains the specifications, settings, and usage examples.

### 8-4-1 Introduction to Packet Filter

IP packets are filtered in the receive processing at the EtherNet/IP ports.

Packet Filter settings are configured in the permit list. If **any** is set in Packet Filter, all packets are allowed. If a value other than **any** is set in Packet Filter, the received packet is compared with Packet Filter settings. When a matching packet is received, reception is permitted. When a non-matching packet is received, reception is prohibited and the packet is discarded. Packet Filter settings include the source IP address, destination IP address, and TCP/UDP port number.





#### **Precautions for Correct Use**

- If you cannot go online with the Sysmac Studio because of forgetting the registered IP address, you can disable this function tentatively by starting the Unit in Safe Mode. Refer to Troubleshooting When You Cannot Go Online from the Sysmac Studio in the NJ/NX-series Troubleshooting Manual (Cat. No. W503) for details.
- The Packet Filter function supports the stateful inspection. Therefore, for DNS, DB connection services, and communication instructions, where the Controller is specified as a client, you do not need to add the responses from other devices to Packet Filter settings.

## 8-4-2 Packet Filter Specifications

The specifications for Packet Filter are given below.

Item	Specification	Remarks
Filtering system	Permit list	The system enables reception of packets registered in Packet Filter settings and prohibits reception of unregistered packets.

Item	Specification	Remarks
Location to perform filtering	Receive processing at the Ether- Net/IP port (The setting can be configured for each EtherNet/IP port.)	No filtering is applied to the sending process of the EtherNet/IP port.      Stateful inspection is supported.
Number of Packet Filter tables	32	1 11
Settings for Packet Filter tables	Source IP Address/Mask     Destination IP Address/Mask     Protocol (tcp, udp, igmp, icmp) If tcp or udp is selected for Protocol, specify the source port and destination port.	Range specification can be set for the IP address and TCP/UDP ports.

## 8-4-3 Packet Filter Settings

For details on Packet Filter settings, refer to Packet Filter on page 7-7.



## **Additional Information**

- For set values of **Destination Port** for each communication, refer to 8-4-4 Settings for Devices That Access the Controller on page 8-17.
- Refer to Case Where Packet Filter Is Used in the NJ/NX-series CPU Unit Built-in EtherNet/IP Port User's Manual (Cat. No. W506) for set values for each case of using the Packet Filter.

## 8-4-4 Settings for Devices That Access the Controller

This section shows the set values of Packet Filter for each device that accesses the Controller.

## **Settings for Connecting Sysmac Studio**

The following table shows the setting values for the destination port of Packet Filter when the Sysmac Studio is connected.

	Destination port settings						
Connection type <sup>*1</sup>	Protocol	Destination Port Specification Method	Destination Port Range Specifica- tion	Destination Port Start Number	Destination Port End Number		
Ethernet connection via a hub	tcp	Port specification	No check.	443			

<sup>\*1.</sup> Select **Controller – Communications Setup – Connection type** on the Sysmac Studio to make this setting.

## **Settings for Connecting Support Software Other Than Sysmac Studio**

The settings for connecting the Support Software other than Sysmac Studio are as follows.

			Destin	ation port settin	gs		
Support Software	Connection type	Protocol	Destination Port Specification Method	Destination Port Range Specification	Destination Port Start Num- ber	Destination Port End Num- ber	
Network Configura- tor for EtherNet/I P	Ethernet I/F	tcpSettings for Connecting Sup- port Software Other Than Sys- mac Studio on page 8-17	Port specifica- tion	No check.	44818		
		udp*1	Port specifica- tion	No check.	44818		
		icmpSettings for Connecting Sup- port Software Other Than Sys- mac Studio on page 8-17					
Sysmac	Ethernet	Same settings as for Sysmac Studio. Refer to Settings for Connecting Sysmac					
Conrtoller	connection via a hub	Studio on page 8- Allow tcp: 443 for	•	•	dio.		
Log Up- load Tool	via a liub	Allow (cp. 443 lot	uie desuitation p	OI t.			

<sup>\*1.</sup> When filtering by IP address is used, allow the following IP addresses.

Source IP address: Computer's IP address, Destination IP address: Local broadcast to the computer's network (When the computer's IP address is 192.168.250.100/24, allow 192.168.250.255.)

## **Settings for Connecting a Programmable Terminal**

The settings for connecting Programmable Terminals are as follows.

		Destination port settings							
Programmable Terminal	Protocol	Destination Port Specification Meth- od	Destination Port Range Specifica- tion	Destination Port Start Number	Destination Port End Number				
NA-series	tcp	Port specification	No check.	80 or 443*1					

<sup>\*1.</sup> For NA Runtime version 1.161 and NA5 system program version 10.0.0 or higher, set the destination port start number to 443.

## **Settings for Each Communications Protocol**

The settings for each communications protocol are as follows.

	Destination port settings						
Communications protocol	Protocol	Destination Port Specification Method	Destination Port Range Specifica- tion	Destination Port Start Number	Destination Port End Number		
BOOTP client	udp	Port specification	No check.	68			
SNMP agent	udp	Port specification	Checked.	161 <sup>*1</sup>	162 <sup>*1</sup>		

<sup>1.</sup> If the port number has been changed, the new port number must be set.

## **Settings for Using EtherNet/IP Communications**

Make the following settings to use EtherNet/IP communications.

				Destination port settings					
Communica- tions	Communi- cations protocol	Condition	Protocol	Destination Port Specification Method	Destination Port Range Specifica- tion	Destina- tion Port Start Number	Destina- tion Port End Number		
CIP messages	UCMM	Server	tcp	Port specifica- tion	No check.	44818			
			icmp*1						
	Class3	Server	tcp	Port specifica- tion	No check.	44818			
			icmp*1						
Tag data links	Class1	Originator	igmp*2						
		Target	tcp	Port specifica- tion	No check.	44818			
			icmp*3						
CIP Safety	Class0	Originator	igmp*2						
communica- tions		Target	tcp	Port specifica- tion	No check.	44818			

<sup>\*1.</sup> Select this if CX-Compolet/SYSMAC Gateway is a client.

<sup>\*2.</sup> Select this for Multicast.

\*3. Select this when SYSMAC Gateway is the originator.

# 8-5 Port Forward via NX-series EtherNet/IP Units

The NX-series EtherNet/IP Unit supports IP routing. This enables the following three types of port forward via the NX-series EtherNet/IP Units between the NX502 CPU Unit and external devices and between multiple external devices.

- The CPU Unit becomes the client and accesses the server of an external device via the EtherNet/IP
  port on the NX-series EtherNet/IP Unit. In this case, the port forward is performed between the CPU
  Unit and NX-series EtherNet/IP Unit.
- The external device becomes the client and accesses the server function in the CPU Unit via the EtherNet/IP port on the NX-series EtherNet/IP Unit. In this case, the port forward is performed between the NX-series EtherNet/IP Unit and the CPU Unit.
- The port forward is performed between the built-in EtherNet/IP port on the CPU Unit and the EtherNet/IP port on the NX-series EtherNet/IP Unit. Or, the port forward is performed between EtherNet/IP ports on multiple NX-series EtherNet/IP Units.

When you use these types of port forward, you must select the **Use** Option for **IP Forward** from **EtherNet/IP Port Settings - TCP/IP Settings - Port Forward** on the Sysmac Studio.

Also, IP addresses must be set so that each Unit does not have the same network address.

## 8-5-1 Port Forward on Which a CPU Unit Is a Client

When a CPU Unit becomes a client and accesses a server on an external device with special instructions such as FTP client instructions or socket communications instructions, the access can be made through the EtherNet/IP port on the NX-series EtherNet/IP Unit instead of the built-in EtherNet/IP port on the CPU Unit.


The IP packets are transferred from the CPU Unit to the EtherNet/IP port on the NX-series EtherNet/IP Unit by specifying the IP address of the server on the external device with each special instruction. Also, the response IP packets from the external device that are received by the NX-series EtherNet/IP Unit are transferred to the CPU Unit.

The applicable FTP communications mode depends on the connection configuration of the communications network.

Case	Network connection configuration	Applicable FTP communications mode
Case 1	When accessing from the EtherNet/IP port on the NX-series EtherNet/IP Unit that is connected to the CPU Unit via the Ethernet port on the computer to the FTP server, then via the built-in EtherNet/IP port on the other CPU Unit to the FTP server in order.	Passive Mode
Case 2	When accessing from the built-in EtherNet/IP port on the CPU Unit via the EtherNet/IP port on the NX-series EtherNet/IP Unit that is connected to the other CPU Unit to the FTP server on the other CPU Unit.	Active Mode

## Case 1

As shown in the following figure, the FTP servers are accessed from the EtherNet/IP port on the NX-series EtherNet/IP Unit that is connected to the CPU Unit via the Ethernet port on the computer, then via the built-in EtherNet/IP port on the other CPU Unit in order.




When the CPU Unit executes the FTP client instruction specifying PC1 with IP address 192.168.40.200, an IP packet is transferred to PC1, which is the FTP server, via the EtherNet/IP port 1 on the NX-series EtherNet/IP Unit with unit number 4 in the same network segment.

You need to set the FTP communications mode to Passive Mode for this configuration. Active Mode is not applicable. The details of the settings are as follows.

FTP communications mode	Setting
Active Mode	Not applicable.
Passive Mode	<ul> <li>Set IP Forward in Port Forward to Use for both the CPU Unit and the NX-series EtherNet/IP Unit.</li> <li>Execute the FTP client instruction in Passive Mode.</li> </ul>

## Case 2

As shown in the following figure, the FTP server on the other CPU Unit is accessed from the built-in EtherNet/IP port on the CPU Unit via the EtherNet/IP port on the NX-series EtherNet/IP Unit that is connected to the other CPU Unit.



When the CPU Unit executes the FTP client instruction specifying the NX5 CPU Unit with IP address 192.168.41.200, an IP packet is transferred to the NX5 CPU Unit, which is the FTP server, via the EtherNet/IP port 1 on the NX-series EtherNet/IP Unit in the same network segment.


You need to set the FTP communications mode to Active Mode for this configuration. Passive Mode is not applicable. The details of the settings are as follows.

FTP communica- tions mode	Setting
Active Mode	<ul> <li>Set IP Forward in Port Forward to Use for both CPU Units and the NX-series         EtherNet/IP Unit on the remote node.</li> <li>Execute the FTP client instruction in Active Mode.</li> <li>Set TCP/UDP Port Transfer of the remote node NX-series EtherNet/IP Unit as follows.         Port: Port1         Protocol: TCP         Port Number: 20</li> </ul>
Passive Mode	Not applicable.



#### **Precautions for Correct Use**

As in the following figure, if the connection was configured so that packets are transferred via the EtherNet/IP port on the NX-series EtherNet/IP Unit on both the FTP client and FTP server sides, the FTP communications cannot be performed in either of Active Mode or Passive Mode.




### 8-5-2 Port Forward on Which an External Device Is a Client

In port forward where the external device is a client, an access from an external device such as a computer is made to the server of the CPU Unit through the EtherNet/IP port on the NX-series EtherNet/IP Unit. In this case, when the TCP or UDP port that is used with TCP/IP communications is specified, TCP or UDP frames received by the NX-series EtherNet/IP Unit are transferred to the CPU Unit. The TCP and UDP ports to be used must be specified for each EtherNet/IP port on the NX-series EtherNet/IP Units. The external device that is the client must specify the IP address of the EtherNet/IP port on the NX-series EtherNet/IP Unit to pass through.

To specify the TCP and UDP ports, select **EtherNet/IP Port Settings - TCP/IP Settings - TCP/UDP Port Transfer** on the Sysmac Studio.

If the **Do not use** Option for **IP Forward** is selected under **EtherNet/IP Port Settings - TCP/IP Settings - Port Forward** on the Sysmac Studio, the port forward is not performed. The frame received by the NX-series EtherNet/IP Unit is discarded.

The following figure shows the case where the IP address 192.168.40.1 of the EtherNet/IP port 1 on the NX-series EtherNet/IP Unit with unit number 4 is specified from the FTP client of PC1. The frame received by the NX-series EtherNet/IP Unit is transferred to the CPU Unit.




The following settings are required for this configuration.

FTP communica- tions mode	Setting
Active Mode	<ul> <li>Set IP Forward in Port Forward to Use for both the CPU Unit and the NX-series Ether-Net/IP Unit.</li> <li>PC1, which is the FTP client, is set to Active Mode.</li> <li>Set TCP/UDP Port Transfer of the NX-series EtherNet/IP Unit with unit number 4 connected to PC1 as follows. Port: Port1 Protocol: TCP Port Number: 21</li> </ul>
Passive Mode	Not applicable

## 8-5-3 Port Forward Between CPU Unit and NX-series EtherNet/IP Unit or Between EtherNet/IP Ports on NX-series EtherNet/IP Units

The port forward can be performed between the built-in EtherNet/IP port on the CPU Unit and the EtherNet/IP port on the NX-series EtherNet/IP Unit or between multiple NX-series EtherNet/IP Units. If the network addresses of the Units are duplicated, the IP router table settings are required. If there are no duplicates, no IP router table settings are required.

The following figure shows communications between PC2 and PC3 and between PC3 and PC4. In this case, PC2 needs to make route settings to PC3 192.168.11.100. Similarly, PC3 needs to make route settings to PC2 192.168.20.100 and PC4 192.168.251.100, and PC4 needs to make route settings to PC3 192.168.11.100.



# Tag Data Link Functions

9-1	Introdu	uction to Tag Data Links	9-2
	9-1-1	Tag Data Links	
	9-1-2	Data Link Data Areas	9-3
	9-1-3	Tag Data Link Functions and Specifications	9-6
	9-1-4	Overview of Operation	
	9-1-5	Starting and Stopping Tag Data Links	9-10
	9-1-6	Controller Status	9-10
	9-1-7	Concurrency of Tag Data Link Data	9-12
9-2	Setting	g Tag Data Links	9-15
	9-2-1	Starting the Network Configurator	9-15
	9-2-2	Tag Data Link Setting Procedure	9-17
	9-2-3	Registering Devices	9-17
	9-2-4	Creating Tags and Tag Sets	9-19
	9-2-5	Connection Settings	9-32
	9-2-6	Creating Connections Using the Wizard	9-42
	9-2-7	Creating Connections by Dragging and Dropping Devices	9-45
	9-2-8	Connecting the Network Configurator to the Network	9-48
	9-2-9	Downloading Tag Data Link Parameters	
	9-2-10	Uploading Tag Data Link Parameters	9-54
	9-2-11	Verifying Tag Data Link Parameters	9-57
	9-2-12	Starting and Stopping Tag Data Links	
	9-2-13	Clearing the Device Parameters	9-63
	9-2-14	Saving the Network Configuration File	
	9-2-15	Reading a Network Configuration File	9-67
	9-2-16	Checking Connections	
	9-2-17	Changing Devices	
	9-2-18	Displaying Device Status	9-72
9-3	Laddei	r Programming for Tag Data Links	9-73
	9-3-1	Ladder Programming for Tag Data Links	9-73
	9-3-2	Status Flags Related to Tag Data Links	9-76
9-4	Tag Da	ta Links with Other Models	9-78
9-5	Quick(	Connect	9-82
	9-5-1	Method of Use	9-82
	9-5-2	Managed Switches	9-83

# 9-1 Introduction to Tag Data Links

## 9-1-1 Tag Data Links

Tag data links enable cyclic tag data exchanges on an EtherNet/IP network between Controllers or between Controllers and other devices. Variables are assigned to tags. (You can also assign I/O memory addresses to tags.)

The settings for tag data links are made with the Network Configurator. Refer to *9-2 Setting Tag Data Links* on page 9-15 for information on how to make the settings.




#### **Additional Information**

You can also use the Sysmac Studio to set the tag data links. Refer to A-3 Use the Sysmac Studio to Set the Tag Data Links (EtherNet/IP Connections) on page A-6 for details on setting the tag data links on the Sysmac Studio.

With a tag data link, one node requests the connection of a communications line to exchange data with another node.

The node that requests the connection is called the originator, and the node that receives the request is called the target.



For communications between Controllers, the connection information is set in the EtherNet/IP port of the Controller that receives (consumes) the data (i.e., the originator).



#### **Additional Information**

For communications between a Controller and an I/O device, the connection information is set in the EtherNet/IP port that is the originator. If an I/O device is used, the Network Configurator must have an EDS file installed that includes connection information for the I/O device. Refer to A-4 EDS File Management on page A-43 for the installation procedure.

The output words and input words for each node for which data is exchanged must be set in the connection information. These words are called an output tag set and an input tag set, respectively. Each tag set must contain at least one tag.

The size of data for data exchange is the total size of tags included in the tag set. The size of the output tag set and the size of the input tag set must match.



#### **Precautions for Correct Use**

- Select the Use Option for the CIP message server of the EtherNet/IP port. If the Do not use
  Option for the CIP message server is selected, tag data links cannot be performed. For the
  details on the settings, refer to CIP Message Server on page 7-15.
- If the **Use** Option is selected for Packet Filter of the EtherNet/IP port, make sure to permit packets to be used for tag data links. If they are not permitted, tag data links are not possible. For the details on the settings, refer to *Packet Filter* on page 7-7.
- During tag data link communications, data transfer between the CPU Unit and the X Bus Unit
  is performed during I/O refresh of the primary periodic task. I/O refresh processing can be assigned to the priority-16 periodic task for each tag set in the settings for exclusive control of
  variables in tasks. Refer to I/O Refreshing of X Bus Function Module in the NJ/NX-series
  CPU Unit Software User's Manual (Cat. No. W501) for details on task execution time and I/O
  refreshing.

### 9-1-2 Data Link Data Areas

# **Tags**

A tag is a unit that is used to exchange data with tag data links.

Data is exchanged between the local network variables and remote network variables specified in the tags or between specified I/O memory areas.



#### **Precautions for Correct Use**

To maintain concurrency in the values of network variables that are assigned to tags, you must set refreshing tasks.

Refer to 9-1-7 Concurrency of Tag Data Link Data on page 9-12 for details.

# Tag Sets

When a data link connection is established, one or more tags (up to eight tags including Controller status) are configured as a collective set of tags for the connection. This is called a tag set. Each tag set represents a unit of data for one tag data link connection.

Tag data links are therefore created through a connection between one tag set and another tag set. A tag set name must be set for each tag set.

Note A connection is used to exchange data as a unit within which data concurrency is maintained.

Thus, data concurrency is maintained for all the data exchanged for one or more tags in one tag set.




#### **Precautions for Correct Use**

Data with tags is exchanged in the order that the tags are registered in the tag set. Register the tags in the same order of the input and output tag sets.

## Example

In the following example, input tags "a" to "g" at the originator are a tag set named *SP1\_IN* and output tags "I" and "ii" are a tag set named *SP1\_OUT*. A connection is set between these two tag sets.




There are input (consume) and output (produce) tag sets. Each tag set can contain either input tags or output tags. The same input tag cannot be included in more than one input tag set.


## Number of Tags in Tag Sets

You can set one or more tags for each of the input and output tag sets for one connection. For example, you can set the input tag set with one tag, and the output tag set with more than one tag.

Tag Set with Only One Tag Each
 With basic Network Configurator procedures, each tag set contains only one tag.



Tag Sets Each with Multiple Tags
 As shown below, multiple tags can be grouped. You can assign up to eight tags (up to 722 words in total) in one tag set.



**Note** To enable a connection, each tag set must include only one of ether input tags or output tags. (Both input and output tags cannot be included in one tag set.)

# 9-1-3 Tag Data Link Functions and Specifications

The tag data link and performance specifications of the NX-series EtherNet/IP Unit are given below.

ltem		Specification
		NX-EIP201
Communications type		Standard EtherNet/IP implicit communications (connection-type cyclic communications)
Setting method		After you have set tags, tag sets, and connections with the Network Configurator, you must download tag data link parameters to all devices on the EtherNet/IP network. After the parameters are downloaded, the EtherNet/IP Units are restarted to start the tag data links. You can export network variables that you created on the Sysmac Studio to a CSV file.  You can then import the file to the Network Configurator and assign the network variables to the tags.
Tags <sup>*1</sup>	Supported variable types	You can specify the following network variables as tags.*2, *3  • Global variables
	Maximum number of words per tag	722 words (1,444 bytes)
	Maximum number of tags	1,024 (total of 2,048 with two ports)
Tag sets	Maximum number of tags per tag set	64 (63 when Controller status is included)
	Maximum number of words per tag set	722 words (1,444 bytes)
	Maximum number of tag sets	256 (total of 512 with two ports)
Connection		Maximum number of connections per Unit: 512 (256 per port)
Connection type		Each connection can be set for 1-to-1 (unicast) or 1-to-N (multicast) communications.
Packet interval (RPI)*4		1.0 to 10,000 ms in 1.0-ms increments  The packet interval can be set separately for each connection.
Allowed communications bandwidth per Unit (pps)		40,000 pps*5 *6 Note: The heartbeat and the CIP Safety routing are included.

<sup>\*1.</sup> When you specify a specific I/O memory address for a tag, create a variable with an AT specification for the I/O memory address on the Sysmac Studio, and then specify the variable with the AT specification for the tag. You need to set memory used for CJ-series Unit to use the I/O memory address.

For details on memory settings used for CJ-series Unit, refer to the NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501).

- \*2. You can import network variables created in the Sysmac Studio to the Network Configurator as tags. If variables for which Network publish attribute is set on the Sysmac Studio contain I/O memory addresses, such as "0000" and "H0000", they are not exported to CSV files.
- \*3. The following table lists variables that you can specify as tags.

Data types		Example	Specification
Variables with basic data types		aaa	Supported
Enumerated variables		bbb	Supported
Array variables	Arrays	ccc	Supported
	Elements	ccc[2]	Supported
Structure variables	Structures	ddd	Supported
	Members	ddd.xxx	Supported

Data types		Example	Specification
Union variables	Unions	eee	Supported
	Members	еее.ууу	Supported

- \*4. The approximate I/O response time of the tag data link is determined by the relationship between the packet interval and the number of connections. Refer to 12-3 Tag Data Link I/O Response Time on page 12-23 for details.
- \*5. If the two EtherNet/IP ports are used simultaneously, the maximum communications data size means the maximum data size of the total of the two ports.
- \*6. When the Unit is performing tag data link communications where the allowable communications bandwidth per Unit is close to or greater than 30,000 pps, the following functions may not be used properly. In that case, use the built-in EtherNet/IP port on the CPU Unit or an EtherNet/IP port of a different NX-series EtherNet/IP Unit.
  - · Connecting the Sysmac Studio online from the EtherNet/IP port of the NX-series EtherNet/IP Unit
  - · Connecting the Network Configurator online from the EtherNet/IP port of the NX-series EtherNet/IP Unit
  - Connecting the NA-series Programmable Terminal online from the EtherNet/IP port of the NX-series EtherNet/IP Unit
  - Port forward via the NX-series EtherNet/IP Unit
  - CIP message communications
  - SNMP function

These functions of the NX-series EtherNet/IP Unit can be used via X Bus from the built-in EtherNet/IP port on the CPU Unit or an EtherNet/IP port of a different NX-series EtherNet/IP Unit.

# 9-1-4 Overview of Operation

In this manual, the connection information that is set is called tag data link parameters.

This section describes how to set tag data links with the Sysmac Studio and the Network Configurator.

# **Setting Network Variables (Sysmac Studio)**

First, create any variables that you want to use for tag data links as network variables on the Sysmac Studio.

- 1 Set the Network Publish attribute to **Input** or **Output** in the Global Variable Table for variables you want to use for tag data links (i.e., as tags).
- 2 To maintain concurrency in tag data within a tag set, set all tags (i.e., variables with a Network Publish attribute) within the same tag set as follows:

Set a refreshing task for variables with a Network Publish attribute to maintain concurrency for tag data link data as described below.

- · Maintain concurrency in the tag data in a tag set.
- The timing of updating network variables that are assigned to tags is synchronized with the execution period of a program that accesses the network variables.

Refer to 9-1-7 Concurrency of Tag Data Link Data on page 9-12 for details on the concurrency of tag data link data.

In addition to ensuring concurrency, set the tasks in which to perform I/O refreshing to reduce the effect of I/O refresh time on the task execution time. Refer to I/O Refreshing of X Bus Function Module in the NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501) for details on the settings.



#### **Precautions for Correct Use**

- If a variable with an AT specification is used as a tag, you do not need to set a refreshing task.
  - It is refreshed in the primary periodic task.
- You cannot use the following notation, which specifies an I/O memory address, in the variable name of any variable used in a tag data link.
  - a) Variable names that contain only single-byte numerals (Example: 001)
  - b) Variable names with the following single-byte letters (uppercase or lowercase) followed by single-byte numerals
    - 1) H (Example: H30)
    - 2) W (Example: w30)
    - 3) D (Example: D100)
    - 4) E0\_ to E18\_
- When the server function of CIP message communications is disabled, the tag data links cannot be used. Enable the server function of CIP message communications. Refer to CIP Message Server on page 7-15 for details on setting CIP message server.
- NX-series EtherNet/IP Unit performs I/O refreshing in synchronization with the task of the CPU Unit. If the event I/O Refreshing Timeout Error (65900000 hex) occurs, it means that the processing load in the NX-series EtherNet/IP Unit is high and I/O refreshing synchronized with the task cycle cannot be executed. In that case, take measures such as setting tasks in which to perform I/O refreshing for tag sets to use exclusive control of variables in tasks. Refer to I/O Refreshing of X Bus Function Module in the NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501) for details on the settings. For more information about the event I/O Refreshing Timeout Error (65900000 hex), refer to the NJ/NX-series Troubleshooting Manual (Cat. No. W503).

# **Setting and Downloading Tag Data Link Parameters (Network Configurator or Sysmac Studio)**

The following tag data link parameters (e.g., connection information) are created with the Network Configurator or the Sysmac Studio, and then the parameters are downloaded to all originator devices on the EtherNet/IP network.

When the tag data links are used on EtherNet/IP ports, use the Network Configurator to make the following settings.

1 Creating the Configuration Information
Register EtherNet/IP ports and EtherNet/IP Units to create connections that define the tag data links. For details, refer to 9-2-3 Registering Devices on page 9-17.

# 2 Setting Tags

Create CPU Unit variables for input (consume) tags and output (produce) tags.

You can import and export network variables that are created on the Sysmac Studio to CSV files. This allows you to register them as tags on the Network Configurator.

Output (produce) tags can be defined to clear output data to 0 or to hold the output data from before the error when a fatal error occurs in the CPU Unit.

# **3** Setting Tag Sets

Create output tag sets and input tag sets and assign tags to them. (You can create up to eight I/O tag sets.) You can specify the Controller status that indicates the CPU Unit's operating status (operating information and error information) in a tag set.



Setting connections

Link the output tag sets for the target device and the input tag sets for the originator device as connections.

## Connection Setting Parameters

The connection settings in step 4 above have the following setting parameters.

Setting the Requested Packet Interval (RPI)
 The RPI (Requested Packet Interval) is the I/O data refresh cycle on the Ethernet line when tag data links are established. With EtherNet/IP, data is exchanged on the communications line at the RPI that is set for each connection, regardless of the number of nodes.

With the EtherNet/IP port, you can set RPI for each connection.

Setting Multi-cast or Unicast Communications

You can select a multicast connection or unicast (point-to-point) connection as the connection type in the tag data link connection settings.

With a multicast connection, you can send an output tag set in one packet to multiple nodes and make allocations to the input tag sets.

A unicast connection separately sends one output tag set to each node, and so it sends the same number of packets as the number of input tag sets.

Therefore, multicast connections can decrease the communications load if one output tag set is sent to multiple nodes.

To use a multicast connection and send an output tag set in one packet to multiple nodes, the following settings for the receiving node must be the same as the settings of the sending node: the connection type (multicast), the connection I/O type, packet internal (RPI), and timeout value.



#### **Precautions for Correct Use**

- The performance of communications devices is limited to some extent by the limitations of each product's specifications. Consequently, there are limits to the packet interval (RPI) settings.
  - Refer to 12-2 Adjusting the Communications Load on page 12-7 Checking the Device Bandwidth Usage on page A-26 and set an appropriate packet interval (RPI).
- If multicast connections are used, however, use an Ethernet switch that has multicast filtering, unless packets are received by all nodes in the network.
  - If an Ethernet switch without multicast filtering is used, multicast packets are broadcast to the entire network, and so the packets are sent to nodes that do not require them, which will cause the communications load on those nodes to increase.
- If you use data tag links with multicast traffic at a baud rate over 100 Mbps, use an Ethernet switch that supports a baud rate of 1000 Mbps.
  - If there is an Ethernet device on the same network that communicates at 100 Mbps or less, the device may affect tag data link communications and cause tag data links to be broken, even if the device is not related to tag data link communications.



#### Additional Information

- To calculate the number of connections of each connection type, refer to 12-1-2 Calculating the Number of Connections on page 12-5.
- If the maximum number of connections is exceeded, you must review the number of connections for the built-in EtherNet/IP port, or the number of nodes. Also consider adding NX-series EtherNet/IP Units.

## 9-1-5 Starting and Stopping Tag Data Links

Tag data links are automatically started when the data link parameters are downloaded from the Network Configurator and the power supply to the CPU Unit is turned ON.

Thereafter, you can start and stop tag data links for the entire network or individual devices from the Network Configurator. Starting and stopping tag data links for individual devices must be performed for the originator.

Furthermore, you can execute instructions from the user program to start and stop the entire network. Refer to *9-2-12 Starting and Stopping Tag Data Links* on page 9-61 for details.


## 9-1-6 Controller Status

You can include the Controller status as a member of a tag set in the data sent and received.

The Controller status is a set of flags that indicate the operating status of the CPU Unit (operating information, error information, Controller error level).

If the Controller status is specified as an output (produce) tag, the Controller status is added to the start of the tag set in the following format.

(Select the Include Option for Controller Status in the upper right of the Edit Tag Set Dialog Box.)



**Note** Of the flags in bits 5 to 7 that indicate the current error level, only the flag for the highest error level changes to TRUE.


For example, if a minor fault level Controller error and a major fault level Controller error occur at the same time, only the flag for the major fault level Controller error (bit 7) will change to TRUE and the flag for the minor fault level Controller error (bit 5) will remain as FALSE.


To receive the Controller status, specify the Controller status for the In - Consume Tab Page in the dialog box used to edit the receive tag set.

(Select the **Include** Option for **Controller Status** in the upper right of the **Edit Tag Set** Dialog Box.) When a tag data link is started, the contents of the Controller status is stored in the device variables that are given below.

- CIP Communications1 Target PLC Operating Mode: EIP Comm1Status.TargetPLCModeSta[255]
- CIP Communications2 Target PLC Operating Mode: EIP\_Comm2Status.TargetPLCModeSta[255]
- CIP Communications1 Target PLC Error Information: EIP Comm1Status. TargetPLCErr[255]
- CIP Communications2 Target PLC Error Information: EIP\_Comm2Status.TargetPLCErr[255]

Example: Using an NX-series EtherNet/IP Unit with unit number 1 to send the CIP Communications1 Target PLC Operating Mode of the Target Node with an IP Address of 192.168.250.2







#### **Additional Information**

The target node ID may be duplicated depending on the IP address of the target node. In this case, it is necessary to change the target node ID on the Network Configurator so that the same address could not be used by more than one node.

For information on how to change the target node ID, refer to Step 4 under Registering Devices in the Register Device List in Connection Settings in 9-2-5 Connection Settings on page 9-32.

When you use multiple connections to communicate with one specific node, the information of the Controller status is stored in the following variables if the Controller status is specified in the input tags and the output tags for all the connections.

Controller sta- tus	Variable name	Description of operation
Controller Operating Flag	EIP_Comm1Status.TargetPLCMo deSta[255] (CIP Communications1 Target PLC Operating Mode)     EIP_Comm2Status.TargetPLCMo deSta[255] (CIP Communications2 Target PLC Operating Mode)	This flag shows the operation information of the Controller at the target node. (When the EtherNet/IP Port Is the Originator of the Connection) The array element that corresponds to the target node ID at the target is set to TRUE when all information for all the connections to the relevant target node shows operating status. You can change the target node ID for the IP address from the Network Configurator. This status information is enabled when the Controller status is included in the communications data for both the originator and the target node. This variable is updated when necessary.
Controller Error Flag	EIP_Comm1Status.TargetPLCErr[     255] (CIP Communications1 Target PLC Error Information)     EIP_Comm2Status.TargetPLCErr[     255] (CIP Communications2 Target PLC Error Information)	This variable shows the error status (logical OR of fatal and non-fatal errors) of the target node Controllers.  (When the EtherNet/IP Port Is the Originator of the Connection)  You can change the target node ID for the IP address from the Network Configurator.  The Controller Error Flags are enabled when the Controller status is included in the communications data for both the originator and target node.  This variable is updated when necessary.



## **Additional Information**

Even if you specify including the Controller status in output (produce) tags, you do not necessarily need to include the Controller status in input (consume) tags.

If you do not include the Controller status in an input (consume) tag, the contents of the Controller status are not updated in the Target PLC Operating Mode and Target PLC Error Information variables, but they are sent in the input (consume) tag.

Therefore, you can use the Controller status data that was received in the input (consume) tag as receive data.

# 9-1-7 Concurrency of Tag Data Link Data

To maintain the concurrency of data in a tag data link, you must set a refreshing task for each network variable that is assigned to a tag.

- · Maintain concurrency in tag data in a tag set.
- The timing of updating network variables that are assigned to tags is synchronized with the execution period of the program that accesses the network variables



#### **Additional Information**


A refreshing task maintains concurrency of the value of a global variable from all tasks that access that global variable. This is achieved by specifying a single task that can write to that global variable and not allowing any other task to write to that global variable.

For details on refreshing tasks, refer to the *NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501)*.


# Maintaining Concurrency in the Tag Data in a Tag Set

To maintain concurrency in the values of multiple tags in a tag set, the tags (variables with a Network Publish attribute) must satisfy all of the following conditions.

- a. The tags must be assigned to the same tag set (connection).
- b. A refreshing task must be set for network variables assigned to the tags, and the refreshing task must be the same for all the tags in the tag set.
- Setting Refreshing Tasks for Tags (Network Variables)
   Concurrency of the tags in the tag set is maintained.



Not Setting Refreshing Tasks for Tags (Network Variables)
 Concurrency of the tags in the tag set is not maintained.



# Synchronization of Tag Set Update and User Program Execution Period

The tag set update timing is synchronized with the execution period of the task to which the tag set is assigned as a network variable. The tag set and the task to which it is assigned are determined as follows.

- In Setting for Exclusive Control of Variable in Tasks under Configurations and Setup Task
  Settings on the Sysmac Studio, tag sets containing variables assigned to the primary periodic task
  are assigned to the primary periodic task.
- Tag sets other than the above are assigned to the priority-16 periodic task.
- All tag sets are assigned to the primary periodic task if the priority-16 periodic task is not existed in the user program.



#### **Precautions for Correct Use**

For a tag set that contains variables assigned to the setting for exclusive control of variables in tasks, whether or not processing is included in the I/O refresh processing time of the primary periodic task depends on the setting. Consider the effect on task execution time and configure the settings for exclusive control of variables in tasks.

# **Update Timing of Tag Sets**

The tag set update timing is determined by the task period of the task to which the tag set is assigned and the set value of the packet interval (RPI) as follows.

Relationship between RPI and task period of the task to which the tag set is assigned	Update timing of the tag set
RPI ≥ task period	At least once per RPI period, a tag set update and a refreshing of the NX-series EtherNet/IP Unit are performed on the CPU Unit.
RPI < task period	At least one time per task period, a tag set update and a refreshing of the NX-series EtherNet/IP Unit are performed on the CPU Unit.



#### **Additional Information**

The tag set update is performed outside of the variable access time. Therefore, the tag set update timing is not affected by the variable access time setting.

# 9-2 Setting Tag Data Links



#### **Additional Information**

You can also use the Sysmac Studio to set the tag data links. Refer to A-3 Use the Sysmac Studio to Set the Tag Data Links (EtherNet/IP Connections) on page A-6 for details on setting the tag data links on the Sysmac Studio.

## 9-2-1 Starting the Network Configurator


## **Procedure**

Tag data links are set from the Network Configurator. Use the following procedure to start the Network Configurator.

## Using the Windows Start Menu


To start the Network Configurator, select **OMRON** – **Sysmac Studio** – **Network Configurator for EtherNetIP** – **Network Configurator**.

When the Network Configurator starts, the following window is displayed.




## **Main Window**


The Main Window consists of a Hardware List and a Network Configuration Pane, as shown in the following diagram.



To manage two or more networks, you can select **Network** – **Add**. You can add a new Network Configuration Pane.



To change the network name displayed in the Network Tab Page, select **Network** – **Property**. You can change the network name as set in the Comment Field of the Network Property Dialog Box.



# 9-2-2 Tag Data Link Setting Procedure

This section describes the procedure to set tag data links (i.e., connection information). For data links between Controllers, the connection information is set only in the originator, i.e., the node that receives data.

#### 1 Create the network configuration.

1. Register all the EtherNet/IP ports for which to create connections, in the EtherNet/IP Network Configuration Pane. (Refer to 9-2-3 Registering Devices on page 9-17.)

**Note** If a system has already been installed, connect online to the EtherNet/IP network and upload the network configuration. (Refer to 9-2-10 Uploading Tag Data Link Parameters on page 9-54)

### 2 Create the tag and tag set connections.

- 1. Create tags and tag sets for all the registered devices (EtherNet/IP ports). (Refer to 9-2-4 Creating Tags and Tag Sets on page 9-19.)
- 2. Create a connection for the originator device (i.e., the registered device that receives data as input data). (Refer to 9-2-5 Connection Settings on page 9-32)
- 3 Download the tag data link parameters. (Refer to 9-2-9 Downloading Tag Data Link Parameters on page 9-51)
- 4 Make sure that the tag data links are operating normally, by using the indicators for the Ether-Net/IP port (refer to the NJ/NX-series Troubleshooting Manual (Cat. No. W503)) and the device monitor function of the Network Configurator. (Refer to 14-6-1 The Network Configurator's Device Monitor Function on page 14-47.)
- Make sure that the output tag data is reflected in the input tags by checking the Watch Tab Page on the Sysmac Studio.

  Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for the procedure.



#### **Additional Information**

If the tag data links are performed with a device that do not have EDS files, use the Generic Device to make the settings.


Refer to A-6 Tag Data Link Settings with Generic Devices on page A-50 for information on how to make the settings with the Generic Device.

# 9-2-3 Registering Devices

Register all of the devices required in the equipment (such as EtherNet/IP Units performing tag data links) in the network configuration.

Register the devices that will participate in the tag data links by dragging the devices from the Hardware List and dropping them in the Network Configuration Pane on the right. (To drag and drop an icon, click and hold the left mouse button over the icon, move the icon to the destination, and release the mouse button.)

You can also select a device in the Hardware List and press the Enter Key to register it. The icon of the device is displayed in the Network Configuration Pane, as shown in the following picture.



The device names and major CIP revisions (Rev  $\square$ ) are displayed in the hardware list. For the NJ/NX-series Controllers, device names of Units and major CIP revisions are as shown in the following table.

Device name in		CIP revisions	
Hardware List	Unit version	Major revision	Revision name in Hardware List
NX701	Unit version 1.10 or later	2	None
NX502-□□□□	Unit version 1.60 or later	2	None
NX102-□□□□	Unit version 1.30 or later	2	None
NX1P2	Unit version 1.13 or later	2	None
NJ501-□□□□	Unit version 1.00 to 1.02	1	Rev1
	Unit version 1.03 or later	2	Rev2
NJ301-□□□□	Unit version 1.01 or 1.02	1	Rev1
	Unit version 1.03 or later	2	Rev2
NJ101	Unit version 1.10 or later	2	None
NX-EIP201	Unit version 1.00 or later	2	None



#### **Precautions for Correct Use**

Make sure that you select the devices with the same device names and the same major CIP revisions as the devices you use in the actual operation. The following will occur if any device name or CIP revision is incorrect when you attempt to download tag data link parameters on the Network Configurator.

- If a device name is incorrect, an error message will be displayed saying "Specified device can not be accessed, or wrong device type", and the download will fail.
- If a revision is incorrect, a message will be displayed saying "Wrong unit revision", and the download will fail.

Similarly, the above will occur when performing upload or comparison of the tag data link parameters.

In any of the above cases, refer to 9-2-17 Changing Devices on page 9-70 and change the device.

Right-click the registered device's icon to display the pop-up menu, and select Change IP Address.



- **3** Set the IP address to match the node address (IP address) actually used in the device, and click the **OK** Button.
- **4** Repeat steps 1 to 3, and register all devices to which tag data links are made.



# 9-2-4 Creating Tags and Tag Sets

You must create tag sets and member tags that are required to create connections for a registered EtherNet/IP port and EtherNet/IP Unit. You can set the network variables used in control programs for tags.

This section first describes the basic procedure to create tags and tag sets, as described in (1) below. Then it explains how to import variables with a Network Publish attribute from the Sysmac Studio to the Network Configurator, as described in (2) below.


1. Creating Tags and Tag Sets with the Network Configurator's Device Parameter Editing Function

2. Importing Variables with a Network Publish Attribute Created in the Sysmac Studio to the Network Configurator


# (1) Creating Tags and Tag Sets with the Network Configurator's Device Parameter Editing Function

## Creating a Tag Set

1 Double-click the icon of the device for which to create a tag set to display the **Edit Device**Parameters Dialog Box. Or, right-click the icon to display the pop-up menu, and select
Parameter – **Edit**.




**2** Click the **Tag Sets** Tab at the top of the **Edit Device Parameters** Dialog Box. There are two kinds of tag sets: input (consume) and output (produce).



# Creating and Adding Tags

1 Click the Edit Tags Button.
The Edit Tags Dialog Box is displayed. Register input (consume) tags and output (produce) tags separately.



2 Click the In - Consume Tab, and then click the New Button.
The Edit Tag Dialog Box is displayed.



**3** Enter the variable name directly into the **Name** Box. (Example: Var In a)



#### **Additional Information**


- You can use the following characters in tag names.
   0 to 9, A to Z, a to z, single-byte kana, \_ (underbar), and multi-byte characters (e.g., Japanese)
- You cannot use the following characters in tag names.
   ! "#\$&'()\*+,-./:;<=>?@[]^'% spaces or text strings that start with numerals (0 to 9)
- The maximum length of a tag name is 255 bytes.
- Specify array variables, structure variables, and union variables, if any, as shown below.
  - Specifying array elements Example: array [2][3] (or array [2,3]) and array [2][3][4] (or array [2,3,4])
  - Specifying structure members
     Example: Struct.member (Separate the member name with a period.)
  - Specifying union members
     Example: Union.member (Separate the member name with a period.)



#### **Precautions for Correct Use**

- To specify an I/O memory address for a tag, create a variable with an AT specification of the I/O memory address on the Sysmac Studio, and then specify the variable with the AT specification for the tag.
  - You need to set memory used for CJ-series Unit to use the I/O memory address. For details on memory settings used for CJ-series Unit, refer to the *NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501)*.
- If you enter the following I/O memory addresses for tag names on the Network Configurator, the tags are directly assigned to the I/O memory addresses in the CPU Unit, and not to the variables. Always specify variable names for tags.
  - a) Variable names that contain only single-byte numerals from 0000 to 6143
  - b) Variable names with the following single-byte letters (uppercase or lowercase) followed by single-byte numerals
    - H (H000 to H511)
    - W (W000 to W511)
    - D (D00000 to D32767)
    - E0\_ to E18\_ (E0\_00000 to E0\_32767, to E18\_00000 to E18\_32767)

You can check the memory address or variable to which a tag is assigned, with icons in the **Edit Tags** Dialog Box.



- Input the size of the tag in bytes in the Size Field.
  Specify the tag size to be the same as the data type size of the variable.
  To use a BOOL variable, select the Use Bit Data Check Box, and enter 1 in the Size Field.
- **5** Click the **Regist** Button to register the tag.


If an I/O memory address is specified as the tag name, another **Edit Tag** Dialog Box will be displayed with the next address as the tag name so that you can register the next tag consecutively.

After you register the tags, click the **Close** Button.

6 Click the Out - Produce Tab, and then click the New Button. The Edit Tag Dialog Box is displayed. Input output tags in the same way. In case a major fault occurs in the CPU Unit, use the Fault Action setting of the output (produce) tag to select whether to clear output data or continue to send data.

The Fault Action setting is not required for input (consume) tag sets.

- Retain output after major fault: Hold (default)
   Output data maintains its previous status even after a major fault occurs.
- Clear output at major fault: Clear
   Output data is cleared to 0 when a major fault occurs.






#### **Precautions for Correct Use**

Connections are cut off if any of the following errors occurs in the CPU Unit that is the originator while tag data links are active.

- Major fault level Controller error
- · Partial fault level Controller error
- 7 After you register all of the required tags, click the **OK** Button in the **Edit Tags** Dialog Box.






#### **Precautions for Correct Use**

Make the following settings to refresh all of the tag data in one tag set at the same time.

- Use the Sysmac Studio, in advance, to specify the same refreshing task for all of the variables that are assigned to tags in the tag set.
- Do not place tag variables that have AT specifications in I/O memory and tag variables that
  do not have AT specifications in the same tag set.


**8** At this point, a confirmation dialog box is displayed to check whether the registered tag names are used as the tag set names. A tag set can contain up to eight tags, but tag sets are registered with one tag per tag set if the tag names are registered as tag set names. In this case, click the **Yes** Button.



If the **No** Button is clicked, you can add more tags to the tag set. Refer to step 8 in Changing and Registering Tag Sets for details on how to register new tags first and add more tags to the tag set later.


## Changing and Registering Tag Sets

**1** The following dialog box is displayed when the tags in the **Edit Tags** are registered directly as tag sets.



2 If an input tag is already registered in an input tag set, and you want to change its registration to a different input tag set, it is necessary to delete the tag from the tag set in which it was originally registered.

Open the **Edit Device Parameters** Dialog Box, select the tag set containing the tag that you want to delete on the **Tag Sets** Tab Page, and click the **Delete** Button. (If there are other tags registered in the tag set, it is possible to delete just one tag by selecting the tag that you want to delete in the **Edit Tag Set** Dialog Box and clicking the Button.)




A confirmation message is displayed.



If the **No** Button is clicked, only the selected tag set is deleted. Click the **No** Button.

To edit a registered tag set and add tags, either double-click the tag set, or select the tag set and click the **Edit** Button.

The Edit Tag Set Dialog Box is displayed.




The **Tag List** on the left side of the dialog box shows tags that are already registered, and the **Candidate Tag List** on the right side of the dialog box shows the other tags that are not registered yet.

To add a tag, select it in the **Candidate Tag List** and click the <u>Solution</u>.


To include the Controller status in the tag set, select the **Include** Option for the **Controller Status** at the upper-right corner of the **Edit Tag Set** Dialog Box.




- **5** To confirm the change, click the **OK** Button in the **Edit Tag Set** Dialog Box.
- 6 Click the **OK** Button in the **Edit Device Parameters** Dialog Box.
- If you want to just add a new tag and register it in an existing tag set, first register the new tag by following steps 1 in Creating a Tag Set to 7 in Creating and Adding Tags. In this example, input tags, Var\_In\_e and Var\_In\_f, are newly added.



- **8** After you register the tags, click the **OK** Button in the **Edit Tags** Dialog Box.
- **9** At this point, a confirmation dialog box is displayed to check whether you want to use the registered tag names as tag set names. They are supposed to be added as tags in this case, so click the **No** Button. Then, the tags are registered just as tags but not as tag sets.




10 To register the newly added tags in an existing tag set, either double-click the desired tag set, or select the tag set and click the Edit Button.



The Tag List on the left side of the dialog box shows tags that are already registered in the tag set, and the Candidate Tag List on the right side of the dialog box shows the other tags that are not registered yet.

11 Select the tags that you want to add from the Candidate Tag List and click the 🖾 Button.



You can register up to eight tags in a tag set. (If you include the Controller status in the tag set, you can register up to only seven tags, and two bytes are added to the size.)

Tag data is sent and received in the order of tags displayed in the tag list. To change the order

of tag data, select a tag and click the or Button


- 12 To confirm the change, click the **OK** Button in the **Edit Tag Set** Dialog Box.
- 13 Click the OK Button in the Edit Device Parameters Dialog Box.

# Importing Variables with a Network Publish Attribute Created in the Sysmac Studio to the Network Configurator

You can create network variables in the Sysmac Studio and import these variables to the Network Configurator to assign them to tags and tag sets. Use the following procedure.

## Exporting Global Variables on the Sysmac Studio

1 Create a global variable on the global variable table of the Sysmac Studio and select Input or Output for the Network Publish attribute of the variable.



Select Export Global Variables - Network Configurator... from the Tools Menu. Any global variables with Input or Output set for the Network Publish attribute are imported from the csv file through the import procedure described below (Importing to the Network Configurator).


#### Importing to the Network Configurator




#### **Precautions for Correct Use**

Variables with a Network Publish attribute that have variable names that are the same as the I/O memory address notation, such as, "0000" and "H0000" are not exported to CSV files.

- Variable names that contain only single-byte numerals (Example: 001)
- Variable names with the following single-byte letters (uppercase or lowercase) followed by single-byte numerals
  - H (Example: H30)
  - W (Example: w30)
  - D (Example: D100)
  - E0\_ to E18\_ (Example: EA\_100)
- 1 From the devices registered on the Network Configurator, select and double-click the icon of the device for which you want to import the variable with a Network Publish attribute. Then, the Edit Device Parameters Dialog Box is displayed.
  - Or, right-click the icon to display the pop-up menu, and select Device Parameter Edit.
- 2 Click the Tag Sets Tab at the top of the Edit Device Parameters Dialog Box. Select Import from File from the To/From File Button.




To import all variables with a Network Publish attribute, click the **Yes** Button. To import only some of these variables, click the **No** Button.



After you import the variables to the tags, click the **Yes** Button to automatically create tag sets, or click the **No** Button to set up tag sets manually.



If you select the **Yes** Button in the previous step, the variables will be imported as shown below on the **Tag Sets** Tab Page. Each variable will be imported into a separate tag set and the device parameters will be automatically edited. (The variable name will be used for the tag set name.)




To place more than one input variable (input tag) imported from the Sysmac Studio into one tag set, you must delete the input tags that were registered.

Select the tag set containing the variables you want to put into a tag set, then click the **Delete** Button. A message box is displayed to confirm that you want to delete the selected tag set and the tags contained in that tag set. You only want to delete the tag set, so click the **No** Button.



Click the **New** Button to create a new tag set. To place more than one tag in an existing tag set, double-click the tag set, or select it and click the **Edit** Button.

The **Edit Tag Set** Dialog Box is displayed. Imported tags that are not registered in another tag set are displayed in the **Candidate Tag List** on the right side of the **Edit Tag Set** Dialog Box. Click the Button to add tags individually.



- **3** You can change tag set names in this dialog box. To confirm a change, click the **Regist** Button in the **Edit Tag Set** Dialog Box.
- **4** Perform steps 1 to 3 for all the devices to which tag data links are made to import variables and to create tag sets.

# 9-2-5 Connection Settings

After you create the tag sets, click the **Connections** Tab at the top of the **Edit Device Parameters** Dialog Box, and set the following connection information.

- The target devices and tag sets with which connections are opened
- The connection type (multicast or unicast)
- The length of the packet intervals (RPI)
- Connection name (optional)

Make the connections settings on the originator only. The connections settings are not necessary on the target device.




#### **Precautions for Correct Use**

Make the connections settings after you create tag sets for all of the devices involved in tag data links.


# **Connection Settings (Connections Tab Page)**

- Registering Devices in the Register Device List
  - 1 Double-click the icon of the device for which to make originator settings in the Network Configuration Pane of the Network Configurator. The **Edit Device Parameters** Dialog Box is displayed. Or, right-click the icon to display the pop-up menu, and select **Parameter Edit**.
  - Click the Connections Tab in the Edit Device Parameters Dialog Box.
    All of the devices registered in the network (except the local node) are displayed.




In the Unregister Device List, click the target device that requires connection settings so its color changes to gray, and click the Button.

The selected target device is displayed in the **Register Device List**, as shown below.



4 Target node IDs are assigned to the devices that are registered in the Register Device List. The target node ID serves as the bit array position for the following variables in the originator Controller: Target Node Controller Mode, Target Node Controller Error Information, Target Node Error Information, Registered Target Node Information, and Normal Target Node Information. By default, the target ID is automatically set to the rightmost 8 bits of the IP address. In the example above, the target device's IP address is 192.168.250.2, so the target node ID is #002. If a target node ID is duplicated and you want to change the target node ID, click the **Change Target Node ID** Button and change the target ID.




## Editing Settings for Individual Connections


You can edit each connection separately.

Refer to *Editing Settings for All Connections* on page 9-36 for information on how to edit all the connections in a table format.

- 1 Click the Connections Tab and then the click the New Button.
  The following Edit Connection Dialog Box is displayed according to the type of device that is selected.
  - (A) Using EtherNet/IP Ports as Targets (for Input Only)



• (B) Using Other EtherNet/IP Devices as Targets (for Settings Other Than Input Only)



## The settings are as follows:

Setting	Description	
Connection I/O Type	Select Input Only (Tag type) to use tag data links with an NX-EIP201, CS1W-EIP21, CJ1W-EIP21, CJ2B-EIP21, CJ2M-EIP21, CJ1W-EIP21(CJ2), CJ1W-EIP21(NJ), NX701, NX102-□□□, NX1P2, NJ501-□□□□, NJ301-□□□□, or NJ101 CPU Unit.  When you create tag data links for other devices, select the connection I/O type specified in that device's EDS file.  Use the Input Only (ID type) setting when another company's node is the originator and does not support connection settings with a Tag type setting.	
Connection Type	Select whether the data is sent in multicast or unicast (point-to-point) form. The default setting is multicast.  • Multi-cast connection: Select when the same data is shared by multiple nodes. This setting is usually used.  • Point-to-point connection: Select when the same data is not shared by multiple nodes. In a unicast transmission, other nodes are not burdened with an unnecessary load.  Refer to 9-1-4 Overview of Operation on page 9-7 for details on using multi-cast and unicast connections, and counting the number of connections.	
The <b>Connection Structure</b> Area and the following items are not displayed if the <b>Hide Detail</b> Button is clicked.		
Packet Interval (RPI)*1	Set the data update cycle (i.e., the packet interval) of each connection between the originator and target.  The default setting is 50 ms (i.e., data is updated once every 50 ms).  Set the RPI between 1.0 and 10,000 ms in 1.0-ms increments.	

Setting	Description
Timeout Value	Set the time elapsed until a connection timeout is detected. The timeout value is set as a multiple of the packet interval (RPI) and can be set to 4, 8, 16, 32, 64, 128, 256, or 512 times the packet interval.  The default setting is 4 times the packet interval (RPI).
Connection Name	Set a name for the connection. (32 single-byte characters max.)


<sup>1.</sup> The approximate I/O response time of the tag data link is determined by the relationship between the packet interval and the number of connections. Refer to 12-3 Tag Data Link I/O Response Time on page 12-23 for details.

**2** After you make all of the settings, click the **OK** Button.

## Editing Settings for All Connections

You can edit the connection settings between the originator and all of the target devices selected in the Register Device List together in a table.

1 Click the Connections Tab, and then click the Edit All Button.
The following Edit All Connections Dialog Box is displayed.



The settings are as follows:

Setting	Description
Target Device	Select the target device.
Connection Name	Any name can be given to the connection. (32 single-byte characters
	max.)
	If this field is left blank, a default name is assigned.
	The connection name is used as a comment.
Connection I/O Type	Select Input Only (Tag type) to use tag data links with an NX-EIP201,
	CS1W-EIP21, CJ1W-EIP21, CJ2B-EIP21, CJ2M-EIP21, CJ1W-EIP21
	(CJ2), CJ1W-EIP21 (NJ), NX701, NX502-□□□□, NX102-□□□□,
	NX1P2, NJ501-□□□□, NJ301-□□□□, or NJ101 CPU Unit.
	When you create tag data links for other devices, select the connection
	I/O type specified in that device's EDS file.
	Use the <b>Input Only (ID type)</b> setting when another company's node is the
	originator and does not support connection settings with a Tag type set-
	ting.


Description
The connection's I/O is automatically displayed based on the selected
connection.
Input Only: Just In is displayed.
Select the target node's tag set to assign.
In: Select the target's output (produce) tag set.
Out: Select the target's input (consume) tag set.
Select the originator node's tag set to assign.
In: Select the originator's input (consume) tag set.
Out: Select the originator's output (produce) tag set.
Select whether the data is sent in multi-cast or unicast (point-to-point)
form. The default setting is multi-cast.
Multi-cast connection:
Select when the same data is shared by multiple nodes. This setting is
usually used.
Point-to-point connection:
Select when the same data is not shared by multiple nodes. In a unicast
transmission, other nodes are not burdened with an unnecessary load.
Refer to 9-1-4 Overview of Operation on page 9-7 for details on using mul-
ti-cast and unicast connections, and counting the number of connections.
Set the data update cycle (i.e., the packet interval) of each connection be-
tween the originator and target.
The default setting is 50 ms (i.e., data is updated once every 50 ms).
Set the RPI between 1.0 and 10,000 ms in 1.0-ms increments.
Set the time elapsed until a connection timeout is detected. The timeout
value is set as a multiple of the packet interval (RPI) and can be set to 4,
8, 16, 32, 64, 128, 256, or 512 times the packet interval.
The default setting is 4 times the packet interval (RPI).

The approximate I/O response time of the tag data link is determined by the relationship between the packet interval and the number of connections. Refer to 12-3 Tag Data Link I/O Response Time on page 12-23 for details.


**2** After you make all of the settings, Click the **OK** Button.

### • Confirming the Connection Settings

**1** An overview of the connections that were set in the Register Device List is displayed in the Connections Tab Page.



**2** Click the **OK** Button. The following figure is displayed.



**3** Repeat the connections setting procedure until all of the connections are set.



### **Precautions for Correct Use**

After you have made all of the settings, always click the **OK** Button before you close the **Edit Device Parameters** Dialog Box. If the **Cancel** Button is clicked and the dialog box is closed, all the settings you made here are discarded.

4 If you change the size of a tag set for the originator or a target node after the connection settings, a parameter data mismatch will occur due to the size difference between them. if you change the connection settings, be sure to check the connections. (Refer to 9-2-16 Checking Connections on page 9-69 for details.)

Indicates the IP address of the

### **Automatically Setting Connections (Network - Auto Connection)**


You can use automatic detection of the tag set names that are set for devices to automatically set connections between input and output tag sets with the same name (or the same names excluding specified ellipses).

Connections are automatically set under the following conditions.

Output tag set names for connec-	Except for specified ellipses, the output tag set name must be the same as
tion setting	the input tag set name.
	Ellipses can be set for the beginning or end of tag set names.
Input tag set names for connection	Except for specified ellipses, the input tag set name must be the same as
settings	the output tag set name.
	Ellipses can be set for the beginning or end of tag set names.
Connection type	The connection I/O type must be Input Only.
	Multicast or unicast connections can be specified for a connection.
RPI	The default setting is used.
Timeout	The default setting is used.


#### **Example 1: Automatic Connections with the Same Tag Set Names**

The following connections are automatically set with the same tag set name (*A\_Signal*) if there is an output (produce) tag set named *A\_Signal* at node A, and input (consume) tag sets named *A\_Signal* at nodes B and C.




### **Example 2: Automatic Connections with the Ellipses**

The following connections are automatically set with the same tag set name (*Signal*) if there is an output (produce) tag set named *O\_Signal* at node A, and input (consume) tag sets named *I\_Signal* at nodes B and C, and *O\_* and *I\_* are set as forward ellipses.




- 1 Set the same tag set names for the output and input tag sets for the connection. The tag set names can also include forward and backward ellipses.
- Select Auto Connection Configuration from the Network Menu.
  A dialog box will appear to set forward and backward ellipses for both output and input tag sets as soon as automatic connection setting processing starts.




Input the ellipses and click the **OK** Button. Processing for automatic setting is started.

**3** If there are tag sets that meet the conditions for automatic connection setting, they are displayed.



Click the **OK** Button. Processing for automatic setting is started.

**4** A device connection structure tree is displayed when processing is completed.




**5** Use the device connection structure tree to change the RPI and timeout settings if necessary.

### **Device Connection Structure Tree**

Connection settings can be displayed on the network configuration.

Select View Device's Connection Structure Tree from the Network Menu.



- You can check the **Display the detail of Connection** Check Box to switch between device-level and connection-level views of tag data link communications.
- · An asterisk is displayed after the device name of the originator set for the connection.
- The **Edit Device Parameters** Dialog Box is displayed if you select a connection and click the **Edit** Button. You can edit the connections in this dialog box.

### 9-2-6 Creating Connections Using the Wizard

You can use the Network Configurator's Wizard to easily create connections between OMRON PLCs following the instructions provided by the Wizard.




#### **Additional Information**

The Wizard can be used only with the following OMRON EtherNet/IP devices.


Device name	Remarks
NX-EIP201	EtherNet/IP port in NX-series EtherNet/IP Unit
CJ1W-EIP21 (NJ)	CJ1W-EIP21 mounted to NJ-series Controller
CJ1W-EIP21	CJ1W-EIP21 mounted to CJ1 CPU Unit
CJ1W-EIP21 (CJ2)	CJ1W-EIP21 mounted to CJ2 CPU Unit
CJ2B-EIP21	Built-in EtherNet/IP port in CJ2H CPU Unit
CJ2M-EIP21	Built-in EtherNet/IP port in CJ2M CPU Unit
CS1W-EIP21	CS1W-EIP21 mounted to CS1 CPU Unit
NX701	Built-in EtherNet/IP port on NX-series CPU Unit
NX502-□□□	
NX102-□□□	
NX1P2	
NJ501-□□□	Built-in EtherNet/IP port on NJ-series CPU Unit
NJ301-□□□	
NJ101	

Use the following procedure to create connections (i.e., tag data links) with the Wizard.

- **1** Set tags and tag sets for all the devices before starting the Wizard. Refer to *9-2-4 Creating Tags and Tag Sets* on page 9-19 for the setting procedure.
- **2** For tag data links between OMRON PLCs, a connection is created in the PLC (i.e., the originator device) that receives data as input data. First, select the registered device for which you want to create a connection in the Network Configuration Window of the Network Configurator, and then select **Device Parameters Wizard** from the menu.




The following message box will be displayed before the Wizard starts.



Click the **Yes** Button to delete the connections that are set with OMRON PLCs before starting the Wizard.

**3** Create the connection following the instructions that are given by the Wizard after the Wizard starts. (See the following figure.)



**4** A list of tag sets is displayed on the right side of the Wizard with target devices that support receiving input data.


Select the tag sets that you want to receive at the originator device.

The following table describes the meanings of the icons and check marks displayed in the tag set list.

Icon	Display posi- tion	Status
<b>✓</b>	All	All output tag sets for all devices are selected.
	Device	All output tag sets for the applicable device are selected.
	Tag set	The applicable output tag sets are selected. These are the tag sets that will be set in the connection.
<u> </u>	All	All or some output tag sets for some devices are selected.
	Device	Some output tag sets for applicable devices are selected.
	All	All output tag sets for all devices are not selected.
	Device	All output tag sets for applicable devices are not selected.
	Tag set	The applicable output tag sets are not selected. The connections for this tag set will be deleted.
	Device	No applicable tag sets.

Note Tag sets used in connections that are already set are not displayed.


The following display will appear when you click the **Show Detail** Button.



The preset values for detailed parameters will be displayed. Change the values as required. The connection name cannot be set. They are automatically created using the following rule.

default\_N (where N is a 3-digit number (001, 002, etc.) starting from 1)

Click the Next Button to switch to the table in the following Wizard Dialog Box. Follow the instructions to select the input tag set of the originator device that receives the output tag set of the target device from the list box.




- The blank area in the Input Tag Set Column is for the connection that you are creating.
- For the connections that are already set, values are already given in the Input Tag Set Column.
- To prevent duplicate settings, input tag sets that are used are not displayed in the list box for input tag sets.
- If there is no applicable input tag set, you can edit a tag set or create a new one by using the Edit Tag Sets Button and the Edit Tag Button.
- 6 Once the input tag set settings are completed, click the Finish Button. You can check the set connection by selecting Network View Devices Connection Structure Tree from the menu.
  - The Wizard can be ended even if the input tag set includes a blank row. In that case, a connection is not created for the blank row.
  - You can delete a connection by deleting the input tag sets that were previously set.

## 9-2-7 Creating Connections by Dragging and Dropping Devices

You can create a connection to the originator by dragging a target device and dropping it at the originator device.

Example) Drag the target device at 192.168.250.1 and drop it at the originator device at 192.168.250.100.






#### **Additional Information**

The EtherNet/IP originator device (i.e., a device in which connections can be set) must be one of the following OMRON EtherNet/IP devices.

Device name	Remarks
NX-EIP201	EtherNet/IP port on NX-series EtherNet/IP Unit
CJ1W-EIP21 (NJ)	CJ1W-EIP21 mounted to NJ-series Controller
CJ1W-EIP21	CJ1W-EIP21 mounted to CJ1 CPU Unit
CJ1W-EIP21 (CJ2)	CJ1W-EIP21 mounted to CJ2 CPU Unit
CJ2B-EIP21	Built-in EtherNet/IP port in CJ2H CPU Unit
CJ2M-EIP21	Built-in EtherNet/IP port in CJ2M CPU Unit
CS1W-EIP21	CS1W-EIP21 mounted to CS1 CPU Unit
NX701	Built-in EtherNet/IP port on NX-series CPU Unit
NX502-□□□□	
NX102-□□□	
NX1P2	
NJ501-□□□□	Built-in EtherNet/IP port on NJ-series CPU Unit
NJ301-□□□□	
NJ101	


Use the following procedure to create connections (i.e., tag data links) by dragging and dropping devices.

- **1** Set the tags and tag sets for the target device that will be dragged.
  - Refer to 9-2-4 Creating Tags and Tag Sets on page 9-19 for information on the settings if the target is one of the OMRON EtherNet/IP devices given above.
  - If the target is another EtherNet/IP device, refer to the manual of that device and perform settings as required.
- **2** A dialog box as in the following figure for connection allocation will be displayed when you drag the target device and drop it at the OMRON EtherNet/IP device.
  - Using One of the Above OMRON EtherNet/IP Devices As Target



Select an output tag set from the **Target Device** Area on the right side of the **Edit Connection** Dialog Box, and then select an input tag set to receive the output tag set in the **Originator Device** Area on the left.


- If there is no applicable input tag set at the originator, you can create a new one by using the **Edit Tag Sets** Button and the **Edit Tag** Button.
- · Using Other EtherNet/IP Devices as Target



The **Connection I/O Type** list box in the upper part of the **Edit Connection** Dialog Box lists connection I/O types. Select a connection I/O type according to your application.

- The connection I/O types that can be selected depend on the target device.
- Items that can be selected depend on the connection I/O type that is selected.
- Select the output, input, or both output and input tag sets at the target and specify the corresponding input, output, or both input and output tag sets at the originator.
- If there is no applicable tag set at the originator, you can create a new one by using the Edit Tag Sets Button and the Edit Tag Button.

The following view will appear when you click the **Show Detail** Button.



The specified values for detailed parameters will be displayed. Change the values as required. Connection names are automatically created using the following rule. default N (where N is a 3-digit number (001, 002, etc.) starting from 1)



#### **Additional Information**

The following dialog box will be displayed if a target device that does not have I/O data is dropped.



Before dropping again, refer to the manual of the applicable device and create the I/O data (i.e., output tag sets) required to create a connection.

After you complete the settings, click the **Regist** Button to create the connection. When the connection is completed, the input tag set box and the output tag set box will be blank. You can continue to create another connection by selecting a next connection I/O type and setting a tag set.

## 9-2-8 Connecting the Network Configurator to the Network

This section describes how to connect the Network Configurator to the network.



#### **Precautions for Correct Use**

Connection may not be possible if the following settings are made on an NJ/NX-series Controller on the connection path or on a connection destination NJ/NX-series Controller. If connection fails, check the following settings. For the details on the settings, refer to *CIP Message Server* on page 7-15 and *Packet Filter* on page 7-7.

- The Do not use Option is selected for the CIP message server.
- · The Use Option is selected for Packet Filter.



### **Additional Information**

Although the NX-series EtherNet/IP Unit provides two EtherNet/IP ports, the Network Configurator treats these two ports as two different Units and connects them individually.

## **Connecting through Ethernet**

Connect to the EtherNet/IP port on the CPU Unit or NX-series EtherNet/IP Unit via an Ethernet switch.



#### **Precautions for Correct Use**


The first time you connect via Ethernet with the computer to use, you must change the Windows firewall settings.

For the procedure, refer to A-5 Precautions for Using the Network Configurator on Windows XP, Windows Vista, or Windows 7 or Higher on page A-47.


- 1 Select Option Select Interface Ethernet I/F.
- 2 Select Network Connect.

If there are multiple Ethernet interfaces on the computer, the **Select Interface** Dialog Box is displayed. Select the interface to connect, and press the **OK** Button.

The following dialog box is displayed.




Click the **OK** Button.
Select the network to connect to.




The Network Configurator will connect to the EtherNet/IP network. If the Network Configurator goes online normally, **On-line** is displayed in the status bar at the bottom of the window.


The network connection icon is displayed in blue on the Network Tab Page in which the Network Configurator is connected.




Select Network - Change Connect Network to switch the connected network.



**4** The following dialog box is displayed.




**5** Click the **OK** Button. Select the network to connect to.





#### **Additional Information**

If the following dialog box appears in the Network Configurator when you go online with an NX-series EtherNet/IP Unit, refer to the following table for possible causes and corrections.



Assumed cause	Correction
The cable is not connected cor-	Check if the cable is disconnected or loose.
rectly.	
Connection with the Controller is	If connection with the Controller is blocked due to the firewall set-
blocked due to the firewall set-	tings, disable the blocking.
tings.	For the firewall settings, refer to A-5 Precautions for Using the Net-
	work Configurator on Windows XP, Windows Vista, or Windows 7 or
	Higher on page A-47.
Communications with Network	Allow communications with Network Configurator.
Configurator are blocked due to	For details on Packet Filter settings, refer to Packet Filter on page
Packet Filter of the Controller.	7-7.
The server function of CIP mes-	Enable the server function of CIP message communications. Refer
sage communications is disa-	to CIP Message Server on page 7-15 for details on setting CIP mes-
bled.	sage server.
	1

## 9-2-9 Downloading Tag Data Link Parameters

To make tag data links, you must download tag data link parameters, such as tag set settings and connection settings, to all devices in the EtherNet/IP network.

When the download operation is executed, the tag data link parameters are transferred to the Ether-Net/IP devices that require the settings.

The following procedure shows how to download the tag data link parameters.


For details on how to connect to the network from the Network Configurator, refer to 9-2-8 Connecting the Network Configurator to the Network on page 9-48.




#### **Precautions for Correct Use**

- If the node addresses (IP addresses) are not set correctly, you may connect to the wrong Controller and set incorrect device parameters. Download data only after you confirm that you are connected to the correct Controller.
- If incorrect tag data link parameters are set, it may cause equipment to operate unpredictably.
   Even when the correct tag data link parameters are set, make sure that there will be no effect on equipment before you transfer the data.
- When network variables are used in tag settings, a connection error will result if the variables are not set in the NX-series EtherNet/IP Unit. Before downloading the tag data link parameters, check to confirm that the network variables are set in the NX-series EtherNet/IP Unit. Check whether the network variable, tag, and connection settings are correct on the Connection Tab Page and the Tag Status Tab Page as described in 14-6-1 The Network Configurator's Device Monitor Function on page 14-47.
- If a communications error occurs, the output status depends on the specifications of the device being used. When a communications error occurs for a device that is used along with output devices, check the operating specifications and implement safety countermeasures.
- The EtherNet/IP port is automatically restarted after the parameters are downloaded. This restart is required to enable the tag set and connection information. Before you download the parameters, check to confirm that problems will not occur with the equipment when the port is restarted.
- Make sure that the major CIP revision of the device registered with the Network Configurator
  is the same as the major CIP revision of the NX-series EtherNet/IP Unit that you use. If the
  major CIP revisions are not the same, the parameters may not be downloaded. To determine
  whether downloading is possible, refer to 9-2-3 Registering Devices on page 9-17.
- Do not disconnect the Ethernet cable or reset or turn OFF the power to the NX-series Ether-Net/IP Unit during the parameter download.
- Tag data links (data exchange) between relevant nodes are stopped during a download. Before you download data in RUN mode, make sure that it will not adversely affect the controlled system.
  - Also implement interlocks on data processing in ladder programming that uses tag data links when the tag data links are stopped or a tag data link error occurs.
- **1** Connect the Network Configurator to the network.
- **2** There are two ways to download the parameters.
  - Downloading to All Devices in the Network Select Network - Download.

The following dialog box is displayed.




Downloading Individually to Particular Devices
 Select the icon of the NX-series EtherNet/IP Unit to which you want to download. To select
 multiple nodes, press and hold the Shift Key or the Ctrl Key while you select additional icons.
 (In the following example, 2 nodes are selected: 192.168.250.1 and 192.168.250.2.)
 Right-click the icon to display the popup menu, and select Parameter - Download.



The following dialog box is displayed.




Click the Yes Button to download the tag data link parameters to the EtherNet/ IP Unit.
The following dialog box is displayed if any of the CPU Units is not in PROGRAM mode.




If the **Download after changed to Program mode** Button is clicked, all CPU Units are changed to PROGRAM mode and the parameters are downloaded. Confirm safety for all controlled equipment before you change the CPU Units to PROGRAM mode. You can restore the operating modes after the parameters are downloaded.

You can click the **Download with Current mode** Button to download the parameters even when one or more CPU Units is in RUN mode.

During the download, the following progress indicator is displayed to show the progress of the download.



If the operating mode of one or more CPU Units was changed to download the parameters, you can return the CPU Units to the previous operating modes. If the **No** Button is clicked, the CPU Units remain in PROGRAM mode.



**4** The following dialog box is displayed to show that the download was completed.



### 9-2-10 Uploading Tag Data Link Parameters

You can upload tag data link parameters (such as tag set settings and connection settings) from Ether-Net/IP devices in the EtherNet/IP network.

The following procedure shows how to upload the parameters. For details on how to connect to the network from the Network Configurator, refer to 9-2-8 Connecting the Network Configurator to the Network on page 9-48.



### **Precautions for Correct Use**


• Make sure that the major CIP revision of the device registered with the Network Configurator is the same as the major CIP revision of the NX-series EtherNet/IP Unit that you use. If the major CIP revisions are not the same, the parameters may not be uploaded. To determine whether uploading is possible, refer to 9-2-3 Registering Devices on page 9-17.

There are two ways to upload the parameters.

## **Uploading from All Devices in the Network**

1 Connect the Network Configurator online, and then select **Upload** from the **Network** Menu.

**2** The following dialog box is displayed.



• Clicking the Yes Button:

The tag data link parameters in the current project are uploaded.

• Clicking the **No** Button:

You open a new project to upload the tag data link parameters. The current project is closed.

Clicking the Cancel Button:
 The upload operation is canceled. The upload is not performed.

**3** If you click the **Yes** Button in step 2, the following dialog box is displayed.



Clicking the Yes Button:

Parameters are uploaded only from the devices registered in the Network Configuration Pane. Parameters are not uploaded from devices that are not registered in the Network Configuration Pane.


• Clicking the No Button:

Performing a Batch Upload over the Network


Parameters are uploaded from all devices on the network.

The current Network Configuration Information will be lost.

The following dialog box will be displayed. Select the devices for which to upload parameters and click the **OK** Button.



- Clicking the Cancel Button:
   The upload operation is canceled. The upload is not performed.
- 4 If you click the **No** Button in step 2, the following dialog box is displayed. Select the devices for which to upload parameters and click the **OK** Button.




## **Uploading Individually from Particular Devices**


Connect the Network Configurator to the network.

Select the icon of the EtherNet/IP Unit from which you want to upload parameters. To select multiple nodes, press and hold the Shift Key or the Ctrl Key while you select additional icons. (In the following example, 2 nodes are selected: 192.168.250.1 and 192.168.250.2.)

Right-click the icon to display the pop-up menu, and select Parameter - Upload.




**2** The following dialog box is displayed.




Click the Yes Button or the No Button.

**3** During the upload, the following progress indicator is displayed to show the progress of the upload.



**4** The following dialog box is displayed to show that the upload was completed.



## 9-2-11 Verifying Tag Data Link Parameters

Tag data link parameters (such as tag set settings and connection settings) can be compared with the parameters of the EtherNet/IP ports in the EtherNet/IP network.

The following procedure shows how to compare the parameters. For details on how to connect to the network from the Network Configurator, refer to 9-2-8 Connecting the Network Configurator to the Network on page 9-48.



#### **Precautions for Correct Use**


Make sure that the major CIP revision of the device registered with the Network Configurator
is the same as the major CIP revision of the NX-series EtherNet/IP Unit that you use. If the
major CIP revisions are not the same, the parameters may not be compared. To determine
whether comparison is possible, refer to 9-2-3 Registering Devices on page 9-17.

# **Verifying the Network Configuration**

You can use the following procedure to compare the list of registered devices in the Network Configuration Pane with the devices connected on the EtherNet/IP network, and check the IP addresses and device types.

This function does not verify device parameters.


- **1** Connect the Network Configurator to the network.
- Select Network Verify Structure.
  The following progress indicator is displayed to show the progress as data is read from the network and compared.



- **3** The result of the comparison between the network configuration file and data from the network is displayed as shown below.
  - · Differences Not Found in the Comparison



· Differences Found in the Comparison



• Differences Found in the Device Type



Click the **OK** Button or the **Close** Button.


### **Verifying the Device Parameters**

Use the following procedure to compare the device parameters for the devices selected in the Network Configuration Pane with those of the devices connected on the EtherNet/IP network.


The IP addresses, device types, and device parameters are compared.

- **1** Connect the Network Configurator to the network.
- Click the icon of the EtherNet/IP port to verify. To select multiple nodes, press and hold the Shift Key or the Ctrl Key while you select additional icons. (In the following example, 2 nodes are selected: 192.168.250.1 and 192.168.250.2.)

Right-click the icon to display the pop-up menu and select **Parameter** – **Verify**.



**3** The following dialog box is displayed.




Click the Yes Button or the No Button.

- **4** The following dialog box is displayed.
  - · Differences Not Found in the Comparison



• Differences Found in the Comparison



· Differences Found in the Device Type



Click the **OK** Button or the **Close** Button.

**5** If multiple nodes have been selected and compared, the following message is displayed. Click the **Yes** Button.



The comparison results are displayed in order of the selected nodes.

## 9-2-12 Starting and Stopping Tag Data Links

This section describes the procedure for starting/stopping tag data links. For details on how to connect Network Configurator to a network, refer to 9-2-8 Connecting the Network Configurator to the Network on page 9-48.

## **Automatically Starting Tag Data Links**

Tag data links are automatically started immediately after the data link parameters are downloaded from the Network Configurator.

(They are automatically started after the CPU Unit's power is turned ON or the Unit is restarted.)



#### **Additional Information**

With a CPU Unit that operates as the originator device, a *Tag Data Link Connection Timeout* error will occur if a connection is not established with the target device within one minute after the tag data links are started.

Even after this error occurs, reconnection processing is continued periodically until automatic recovery is performed.

If the application environment allows you to ignore this error, such as when a target device is started later than the originator device, you can change the event level to the observation level.

## Starting and Stopping Tag Data Links for the Entire Network

You can start and stop tag data links for the entire network by instructions from the user program or operations from the Network Configurator.



#### **Precautions for Correct Use**

Use the same method (i.e., either the user program or the Network Configurator) to both start and stop tag data links.

For example, if you execute an instruction to stop tag data links, you cannot restart them from the Network Configurator.

### Executing Instructions in the User Program

You can start tag data links for the entire network by executing the TDLinkStartConnection (Start Tag Data Link Target Connection) instruction from the user program. You can stop tag data links for the entire network by executing the TDLinkStopConnection (Stop Tag Data Link Target Connection) instruction.

Refer to Section 13 Instructions Specific to NX-series EtherNet/IP Units on page 13-1 for detailed instruction specifications.

### Using the Network Configurator


You can select **I/O Connection - Start** or **Stop** from the **Network** Menu to start and stop tag data links for individual devices.

## Starting and Stopping Tag Data Links for Individual Devices

### Using the Network Configurator

You can start and stop tag data links on a device basis (at the originator) by selecting **Monitor** from the **Device** Menu and performing the following operation in the **Connection** Tab Page in the **Monitor Device** Dialog Box.

You can start and stop tag data links for each of the EtherNet/IP ports 1 and 2 connected to the Network Configurator.



#### Start Connection Button:

Starts all connections for which the device is the originator.

#### Stop Connection Button:

Stops all connections for which the device is the originator.

### 9-2-13 Clearing the Device Parameters

You can clear the tag data link settings (or return them to their factory settings) that are saved in the registered EtherNet/IP device.


The following shows how to clear tag data link parameters. For details on how to connect to the network from the Network Configurator, refer to 9-2-8 Connecting the Network Configurator to the Network on page 9-48.



#### **Precautions for Correct Use**


- Use the Network Configurator version 3.58 or higher to perform the following procedure to clear the tag data link settings.
- If you perform the following procedure from the Network Configurator version 3.57 or lower, the tag data link settings are not cleared. Refer to Additional Information in this section for the procedure to clear the tag data link settings from the Network Configurator version 3.57 or lower.
- 1 Connect the Network Configurator to the network.
- 2 Select the icon of the device from which you want to clear the device parameters.

  In the following example, two nodes are selected: 192.168.250.1 and 192.168.250.2. To select multiple nodes, press and hold the **Shift** Key while you select additional icons.



### 3 Select Device - Reset.

You can also right-click the icon and select Reset from the pop up menu.



**4** The following dialog box is displayed.



If you click the Yes Button:
 The following dialog box is displayed.



Select the **Initialize tag data link configuration, and then emulate cycling power** Option, and then click the **OK** Button.



#### **Precautions for Correct Use**

The Controller is not restarted. Only the EtherNet/IP port is reset.

• If you click the **No** Button:

The tag data link settings will not be cleared and the built-in EtherNet/IP port will not be reset.



#### **Additional Information**

You can also execute the Reset service of the Identity Object for the NX-series EtherNet/IP Unit to clear the tag data link settings. The procedure to execute the service from the Network Configurator is given below.

- 1. Connect the Network Configurator to the network.
- Select Tool Setup Parameters in the main window.
   Then the dialog box for the general parameter settings are displayed.
- 3. Specify the target device and message to send.

• Target Node Address : Enter the IP address of the target device.

Service : Select Reset.
Class : Enter 01.
Instance : Enter 01.
Attribute : Enter 00.
Data : Enter 02\*1.


4. Click the Send Button.

### 9-2-14 Saving the Network Configuration File

You can save device parameters set in the Network Configurator or device parameters uploaded from the network in a network configuration file.


1 Select File - Save As.

The following dialog box is displayed.




Untitled.nvf is displayed as the default file name.

2 Input the file name, and then click the Save Button.




This completes the network configuration file save operation.

- **3** When the network configuration is changed later, you can overwrite the existing network configuration file if you select **File Save**, or click the **B** Button.
- 4 You can select the **Select target network** Check Box in the **Option** Area to select and save only the required network configuration files from the existing multiple files.




Select the check boxes of the networks to save and click the  ${\bf OK}$  Button.



### 9-2-15 Reading a Network Configuration File


You can read out a previously saved network configuration file into the Network Configurator.

Select File - Open, or click the Button.
The following dialog box is displayed.




If the network configuration file that you want to read out is not displayed, change to another folder.

**2** If you select the network configuration file that you want to read out, that file name is displayed in the File name Field.



- **3** Click the **Open** Button to read out the network configuration file.
- **4** The Network Configurator's Title Bar will display the name of the file that was read out.



Select options in the Option Area as necessary. The options are listed below.

Setting	Description
Select target network	Allows you to select specific networks from the network configura-
	tion and open them.
Add to current document	Allows you to add the networks from the network configuration file
	that is currently open to the current configuration file.




### **Additional Information**

The save format will depend on the version of the Network Configurator. You can import configuration files (\*.ncf) created with the Network Configurator for EtherNet/IP (version 2 or lower) if you select **External Data - Import** from the **File** Menu.


### 9-2-16 Checking Connections

You can check the consistency of connection parameters for network configuration files with device parameters that were set with the Network Configurator or device parameters uploaded from the network.

Select Check Connection from the Network Menu.
The following dialog box is displayed if parameters are normal.




The following dialog box is displayed if there are parameter errors. Check the displayed details and review the settings.



If an inconsistency is found, open the originator's **Edit Device Parameter** Dialog Box and click the **Connection** Tab. The inconsistent connection in the **Register Device List** is displayed

with a  $\stackrel{1}{•}$  icon (instead of the normal  $\stackrel{1}{•}$  icon).

To change the connection setting and select a different target variable, select the connection as shown below and click the **Edit** Button.



## 9-2-17 Changing Devices

You can change devices that are registered in a network configuration with the Network Configurator. Select **Change Device** from the **Device** Menu to display a list of the possible devices to change. You can change a device only when there is complete or upward compatibility with the device.

# **Device Changes**

			Model after change									
Model be- fore change	CIP Rev	NX- EIP20 1	CS1W- EIP21	CS1W - EIP21 (NE)	CS1W - EIP21 S	CJ1W- EIP21	CJ1W- EIP21 (CJ2)	CJ1W - EIP21 S	CJ1W- EIP21 (NJ)	CJ1W - EIP21 S (CJ2)	CJ2B- EIP21	CJ2M
		Rev 2	Rev 3	Rev 3	Rev 4	Rev 3	Rev 3	Rev 4	Rev 3	Rev 4	Rev 3	Rev 2
NX-EIP201	Rev 2		No	No	No	No	△2/6/7	No	△2/4/7	△2/6/ 7	△2/6/ 7	△2/4/7
CS1W- EIP21	Rev 3	No		Yes	Yes	Yes	Yes	Yes	△5	Yes	Yes	△3
CS1W- EIP21 (NE)	Rev 3	No	△1		Yes	△1	Yes	Yes	△5	Yes	Yes	△3
CS1W- EIP21S	Rev 4	No	Yes	Yes		Yes	Yes	Yes	△5	Yes	Yes	△3
CJ1W- EIP21	Rev 3	No	Yes	Yes	Yes		Yes	Yes	△5	Yes	Yes	△3
CJ1W- EIP21 (CJ2)	Rev 3	△5	△1	△0	△1	△1		△1	△5	Yes	Yes	△3
CJ1W- EIP21S	Rev 4	No	Yes	Yes	Yes	Yes	Yes		△5	Yes	Yes	△3
CJ1W- EIP21 (NJ)	Rev 3	Yes	△1/2	△0/2	△1/2	△1/2	△2	△1/2		△2	△2	△2/6
CJ1W- EIP21S (CJ2)	Rev 4	△5	△1	△0	△1	△1	Yes	△1	△5		Yes	△3
CJ2B- EIP21	Rev 3	△5	△1	△0	△1	△1	Yes	△1	△5	Yes		△3
CJ2M	Rev 2	△5	△1	△0	△1	△1	Yes	△1	△5	Yes	Yes	

		Model after change											
		NX-	CS1W-	CS1W	CS1W	CJ1W-	CJ1W-	CJ1W	CJ1W-	CJ1W	CJ2B-	CJ2M	
Model be-	CIP	EIP20	EIP21	-	-	EIP21	EIP21	-	EIP21	-	EIP21		
fore	Rev	1		EIP21	EIP21		(CJ2)	EIP21	(NJ)	EIP21			
change	IXCV			(NE)	S			S		S			
										(CJ2)			
		Rev 2	Rev 3	Rev 3	Rev 4	Rev 3	Rev 3	Rev 4	Rev 3	Rev 4	Rev 3	Rev 2	
NJ501	Rev 1	No	△1/2	△0/2	△1/2	△1/2	△2	△1/2	Yes	△2	△2	△2/6	
NJ301	Rev 2	Yes	△1/2	△0/2	△1/2	△1/2	△2	△1/2	Yes	△2	△2	△2/6	
NJ101	Rev 2	Yes	△1/2	△0/2	△1/2	△1/2	△2	△1/2	Yes	△2	△2	△2/6	
NX701	Rev 2	Yes	No	No	No	No	△2	No	Yes	△2	△2	△2/6	
NX502	Rev 2	Yes	No	No	No	No	△2/7	No	△2/7	△2/7	△2/7	△2/6/7	
NX102	Rev 2	Yes	No	No	No	No	△2	No	Yes	△2	△2	△2/6	
NX1P2	Rev 2	Yes	No	No	No	No	△2	No	Yes	△2	△2	△2/6	

		Model after change									
Model before	CIP Rev	NJ501 NJ301		NJ101	NX701	NX502	NX102	NX1P2			
change		Rev 1 *1	Rev 2 *2	Rev 2 *2	Rev 2	Rev 2	Rev 2	Rev 2			
NX-EIP201	Rev 2	No	△4/7	△4/7	△6/7	△4	△4/7	△4/7			
CS1W-EIP21	Rev 3	△4/5	△4/5	△4/5	No	No	No	No			
CS1W-EIP21 (NE)	Rev 3	△4/5	△4/5	△4/5	No	No	No	No			
CS1W-EIP21S	Rev 4	△4/5	△4/5	△4/5	No	No	No	No			
CJ1W-EIP21	Rev 3	△4/5	△4/5	△4/5	No	No	No	No			
CJ1W-EIP21 (CJ2)	Rev 3	△4/5	△4/5	△4/5	△5	△4/5	△4/5	△4/5			
CJ1W-EIP21S	Rev 4	△4/5	△4/5	△4/5	No	No	No	No			
CJ1W-EIP21 (NJ)	Rev 3	△4	△4	△4	Yes	△4	△4	△4			
CJ1W-EIP21S (CJ2)	Rev 4	△4/5	△4/5	△4/5	△5	△4/5	△4/5	△4/5			
CJ2B-EIP21	Rev 3	△4/5	△4/5	△4/5	△5	△4/5	△4/5	△4/5			
CJ2M	Rev 2	△4/5	△4/5	△4/5	△5	△5	△4/5	△4/5			
NJ501	Rev 1		Yes	△4	No	No	No	No			
NJ301	Rev 2	Yes		△4	Yes	Yes	Yes	△4			
NJ101	Rev 2	Yes	Yes		Yes	Yes	Yes	△4			
NX701	Rev 2	No	△4	△4		△4	△4	△4			
NX502	Rev 2	No	△4/7	△4/7	△7		△4/7	△4/7			
NX102	Rev 2	No	Yes	Yes	Yes	Yes		△4			
NX1P2	Rev 2	No	Yes	Yes	Yes	Yes	Yes				

<sup>1.</sup> CPU Unit with a unit version 1.00 to 1.02

Yes Can be changed.

No: Cannot be changed.

 $\triangle 0$  Cannot be changed if a Japanese variable is specified in the tag.

 $\triangle$ 1 Cannot be changed if a network variable is specified as a tag.

 $\triangle$ 2 Cannot be changed if the maximum size of a tag name or tag set name (size after conversion into UTF-8) exceeds 48 bytes.


<sup>\*2.</sup> CPU Unit with a unit version 1.03 or later

- $\triangle 3$  Cannot be changed if the following items exceed the permissible settings of the device after the change:
  - Number of I/O connections, number of tags, number of tag sets, and size of one tag set.
- $\triangle 4$  Cannot be changed in any of the following cases:
  - The number of I/O connections, number of tags, number of tag sets, or size of one tag set exceeds the permissible settings for the device after the change.
  - RPI exceeds the permissible settings or is set in 0.5-ms increments (such as 10.5ms)
- $\triangle 5$  Cannot be changed if a tag set size is an odd number of bytes.
- △6 Cannot be changed if tags, tag sets, or refreshing sizes exceed the permissible settings.
- △7 Cannot be changed if the maximum number of tags per tag set exceeds the permissible setting.

### 9-2-18 Displaying Device Status

Device status is displayed using the following icons in Maintenance Mode.

To enter Maintenance Mode, select Large Icons - Maintenance Mode from the View Menu.



lcon	Status
0	Offline
(white)	
<b>(</b>	Default (including no Controller Configurations and Setup)
(gray)	
<b>@</b>	Idle (including when the Controller is in PROGRAM mode)
(green)	
<b>(4)</b>	Normal communications state (including when the Controller is in RUN mode)
(blue)	
<u> </u>	Warning status (including when there is a partial fault or non-fatal error in the Con-
(yellow)	troller)
<b>@</b>	Alarm status (including when there is a major fault or fatal error in the Controller)
(red)	

# 9-3 Ladder Programming for Tag Data Links

# 9-3-1 Ladder Programming for Tag Data Links

The following conditions 1 to 3 should be fulfilled if you use tag data link data for a ladder programming. The additional conditions 4 and 5 should be also fulfilled if you input the Controller information of the target node.

The device variables listed below assume that the communications port 1 of an NX-series EtherNet/IP Unit with unit number 2 is used. *N*2 at the beginning of the device variable represents unit number 2. Refer to *Section 6 Device Variables Related to the NX-series EtherNet/IP Unit* on page 6-1 for the variable names of device variables when the communications port 2 is used.

### Conditions for Enabling Tag Data Links for the EtherNet/IP Port

The following conditions 1 and 2 should be both fulfilled.

No.	Condition
1	The following error status bits in the N2_ETN_ErrSta (Communications Port Error) variable are FALSE.  • Major fault: Bit 7  • Partial fault: Bit 6
2	Minor fault: Bit 5  The N2_ETN_Port1Status.EtnOnlineSta (Port1 Online) variable is TRUE.

### Condition for Tag Data Links with Connection Established to the Target Device

The following condition 3 should be fulfilled.

No.	Condition
3	In the N2_EIP_Comm1Status.EstbTargetSta[255] (CIP Communications1 Normal Target Node Information) variable, the bit corresponding to the target node address is TRUE.

# Condition of the Controller Operating Mode (Operating or Stopped) (Only for OMRON Controllers)

The following condition 4 should be fulfilled.

No.	Condition
4	In the N2_EIP_Comm1Status.TargetPLCModeSta[255] (CIP Communications1 Target PLC Operating Mode) variable, the bit corresponding to the target node address is
	TRUE.

# Condition of the Controller Error Status (Fatal or Non-fatal Error) of the Target Node (Only for OMRON Controllers)


The following condition 5 should be fulfilled.

No.	Condition
5	In the N2_EIP_Comm1Status.TargetPLCErr[255] (CIP Communications1 Target PLC
	Error Information) variable, the bit corresponding to the target node address is FALSE.
	When you want to use the Target Node Controller Error Flag, the Controller status
	must be included in the tag sets for both the originator and target. Include the Control-
	ler status by using the Network Configurator to select the Include Option in the Edit
	Tag Set Dialog Box.


### Programming Example for Normal Operation Detection

The following program can be used to confirm that normal communications are being performed for each target node. If the Controller status is included in the tag data, the status of the Controller can also be detected.

· Normal Operation Detection Programming Example 1




• Normal Operation Detection Programming Example 2




## Programming Example for Error Detection

The following program can be used to check for tag data link errors for each target node. This programming is used to detect errors which may occur after the data links for all the nodes are started normally.




### Data Processing Programming Example

 The following shows an example where data processing is performed only when data links are operating normally.



• The following shows an example where data processing is performed only when data links are operating normally with MC and MCR instructions, or with JMP instructions.





### **Precautions for Correct Use**

Even if an error occurs in communications with a target device, the input data from the target device will remain stored in words allocated in memory to the local node. To prevent malfunctions, write the user program so that no input processing is performed when any of the following bits of the *ETN\_ErrSta* (Communications Port Error) variable is TRUE.

Major fault: Bit 7Partial fault: Bit 6Minor fault: Bit 5

# 9-3-2 Status Flags Related to Tag Data Links

The status of the tag data links is reflected in the following device variables.

Variable	Description
<ul> <li>EIP_Comm1Status.TargetPLCModeSta[255] (CIP Communications1 Target PLC Operating Mode)</li> <li>EIP_Comm2Status.TargetPLCModeSta[255] (CIP Communications2 Target PLC Operating Mode)</li> <li>(Corresponds to the Controller Operating Flag in the Controller status.)</li> </ul>	This variable shows the operating status of the target node Controller that is connected with the EtherNet/IP port as the originator.  The information in this area is valid only when the corresponding Normal Target Node Information is TRUE. If the value is FALSE, the Target Node Controller Operating Information indicates the previous operating status.
	Array[x] is TRUE: The target Controller with a node address of x is in operating status.  Array[x] is FALSE: Other than the above.

Variable		Description
EIP_Comm1Status.TargetNodeErr[255] (CIP Communications1 Target Node Error Information)     EIP_Comm2Status.TargetNodeErr[255] (CIP Communications2 Target Node Error Information)     (Corresponds to the Controller Error Flag in the Controller status.)	tered Target Node that an error has of The array elements	ates that the connection for Regis- Information is not established or occurred in the target the Controller. Information is TRUE.  The Registered Target Node Information for a node address of x is TRUE, and the Normal Target Node Information is FALSE or the Target PLC Error Information is TRUE.
		tion is TRUE, the Normal Target Node Information is TRUE, and the Target PLC Error Information is FALSE.
EIP_Comm1Status.EstbTargetSta[255] (CIP Communications1 Normal Target Node Information)	This variable gives established EtherN	a list of nodes that have normally let/IP connections.
EIP_Comm2Status.EstbTargetSta[255] (CIP Communications2 Normal Target Node Information)  (This status is not included in the Controller status.)	Array[x] is TRUE:	The connection to the node with a node address of x is established normally.
	Array[x] is FALSE:	A connection is not established yet, or an error has occurred.

# 9-4 Tag Data Links with Other Models

The performance of tag data links depends on the CPU Unit model and EtherNet/IP Unit model as shown below.

When you use tag data links between the NX-series EtherNet/IP Unit and another CPU Unit or an EtherNet/IP Unit, configure the tag data link settings based on the Unit which has the lower level of communications performance.

## • Differences in Tag Data Link Performance Specifications

li	tem	NX-ser- ies Ether- Net/IP Unit	NX-series	s CPU Unit	NJ-series CPU Unit		CJ2M-CPU3□		CS1W-EIP21 CJ1W-EIP21		
		NX-	NX701	NIVEOO	NV400	NV4D0	Ver.		Unit vers		CJ2H- CPU6⊡-EIP
		EIP201	NX/U1	NX502	NX102	NX1P2	1.00 to 1.02	1.03 or later	2.0	2.1 or later	
Tag	Total size of all tags	184,832 words (total of 369,664 words with two ports)	184,832 words (total of 369,664 words with two ports)	46,208 words (total of 92,416 words with two ports)	9,600 words (total of 19,200 words with two ports)	9,600 wor	ds		640 words	S	184,832 words
	Maxi- mum size of tag	722 words (721 words when the tag set in- cludes the Con- troller status)	722 words (721 word the tag se the Contro tus)	s when t includes	300 word	s when the	tag set incl	ludes the	20 words (19 words when the tag set in- cludes the Con- troller status)	640 words (639 words when the tag set in- cludes the Con- troller status)	722 words (721 words when the tag set includes the Controller status)
	Number of regis- trable tags	1024 (total of 2048 with two ports)	256 (total of 5	12 with two	ports)	256*1			32	,	256

ies Ether		Ether- Net/IP	NX-series	X-series CPU Unit			NJ-series CPU Unit		CJ2M-CPU3□		CS1W-EIP21 CJ1W-EIP21 CJ2H-	
	NX- EIP201			NX502	NX102	NX1P2	Ver. 1.00 to 1.02		Unit vers	2.1 or later	- CPU6□-EIP	
Tag set	Maxi- mum size of 1 tag set	722 words (721 words when the tag set in- cludes the Con- troller status)	722 words (721 word the tag se the Contro tus)	ls when t includes	300 words (299 word Controller	ds when the	tag set inc	ludes the	20 words (19 words when the tag set in- cludes the Con- troller status)	640 words (639 words when the tag set in- cludes the Con- troller status)	722 words (721 words when the tag set includes the Controller status)	
	Number of tags per tag set	64 (63 tags when the tag set includes the Controller status) Note: Input and output variables cannot be combined in one tag set.	8 (7 tags when the tag set in- cludes the Con- troller status) Note: In- put and output varia- bles cannot be com- bined in one tag set.	64 (63 tags when the tag set includes the Controller status) Note: Input and output variables cannot be combined in one tag set.	1 -	_			roller status) combined i		et.	
	Number of regis- trable tag sets	256 (total of 512 with two ports)	256 (total of 512 with two ports)	64 (total of 128 with two ports)	32 (total of 40 with two ports)*2	32			32		256	
Connection	Number of con- nections	256 (total of 512 with two ports)	256 (total of 512 with two ports)	64 (total of 128 with two ports)	32 (total of 64 with two ports)	32			32		256	
	Maxi- mum data size per connec- tion	words *3 (Data concurrency is maintained at each connection.)	722 words (Data con is maintai each conr	currency ned at	Link Data	9-1-7 Conc on page 9- aining data	urrency of 1.12 for the concurrency	conditions	words (Data con is maintai each coni	ned at	252 or 722 words*3 (Data concurrency is maintained at each connection.)	

ltem	NX-ser- ies Ether- Net/IP Unit	NX-series	s CPU Unit			NJ-series CPU Unit		CJ2M-CPU3□		CS1W-EIP21 CJ1W-EIP21
								Unit version		CJ2H- CPU6□-EIP
	NX- EIP201	NX701	NX502	NX102	NX1P2	Ver. 1.00 to 1.02	1.03 or later	2.0	2.1 or later	CPU6LI-EIP
Packet intervals	1.0 to	0.5 to	1 to 10,00	0 ms in 1-	2 to	10 to	1 to	1 to 10,00	0 ms in	0.5 to 10,000
(RPIs)	10,000	10,000	ms increm	nents	10,000	10,000	10,000	0.5-ms inc	crements	ms in 0.5-ms
	ms in	ms in			ms in 1-	ms in 1-	ms in 1-			increments
	1.0-ms	0.5-ms			ms in-	ms in-	ms in-			
	incre-	incre-			cre-	cre-	cre-			
	ments	ments			ments	ments	ments			
Communications	40,000	40,000	20,000	12,000	3,000	1,000	3,000	3,000 pps		6,000 pps
bandwidth used (pps)*4	pps*5*6	pps*5	pps*5	pps*5	pps	pps	pps			

<sup>\*1.</sup> The maximum number of tags is given for the following conditions.

- · All tag sets contain eight tags.
- The maximum number of tag sets (32) is registered.
- \*2. When tag sets that exceed total of 40 are set, a Number of Tag Sets for Tag Data Links Exceeded (840E0000 hex) event occurs.
- \*3. To use data of 505 bytes or more, large forward open (an optional CIP specification) should be supported. The SYSMAC CS/CJ-series Units support large forward open, and if you use nodes from other companies, confirm that the devices also support it.
- \*4. Here, pps means "packets per second" and indicates the number of packets that can be processed in one second.
- \*5. If the two EtherNet/IP ports are used simultaneously, the maximum communications data size means the maximum data size of the total of the two ports.
- \*6. When the Unit is performing tag data link communications where the allowable communications bandwidth per Unit is close to or greater than 30,000 pps, the following functions may not be used properly. In that case, use the built-in EtherNet/IP port on the CPU Unit or an EtherNet/IP port of a different NX-series EtherNet/IP Unit.
  - Connecting the Sysmac Studio online from the EtherNet/IP port of the NX-series EtherNet/IP Unit
  - Connecting the Network Configurator online from the EtherNet/IP port of the NX-series EtherNet/IP Unit
  - · Connecting the NA-series Programmable Terminal online from the EtherNet/IP port of the NX-series EtherNet/IP Unit
  - Port forward via the NX-series EtherNet/IP Unit
  - CIP message communications
  - SNMP function

These functions of the NX-series EtherNet/IP Unit can be used via X Bus from the built-in EtherNet/IP port on the CPU Unit or an EtherNet/IP port of a different NX-series EtherNet/IP Unit.

\*7. An NX-EIP201 can only be used with the NX502 CPU Unit. However, check the effect on task execution time because it increases I/O refreshing time.

### Specifying Tags

When you assign a tag to a device, you can specify the device with its network variable or I/O memory address. Some CPU Units, however, may not support both of these methods. Communications with such CPU Units are possible though, regardless of whether the I/O memory address or network variable is specified for the tag assignment.

The supported tag specification methods for each CPU Unit are listed in the table below.

Yes: Supported, No: Not supported

CPU Unit		Network Configura-	Specifying	Specifying
	EtherNet/IP Unit	tor	with network	with I/O memo-
		hardware list name	variable	ry address
NX-series CPU Unit		NX701	Yes	No
		NX502	Yes	Yes *1
		NX102	Yes	Yes *1*2
		NX1P2□□□□	Yes	Yes *1*2
	NX-EIP201	NX-EIP201	Yes	Yes *1*2
NJ-series CPU Unit		NJ501-□□□□	Yes	Yes*1
		NJ301-□□□□		
		NJ101		
	CJ1W-EIP21	CJ1W-EIP21 (NJ)	Yes	Yes*1
CJ2H-CPU6□-EIP		CJ2B-EIP21	Yes	Yes
	CJ1W-EIP21	CJ1W-EIP21 (CJ2)	Yes	Yes
CJ2H-CPU6□	CJ1W-EIP21	CJ1W-EIP21 (CJ2)	No	Yes
CJ2M-CPU3□		CJ2M-EIP21	Yes	Yes
	CJ1W-EIP21	CJ1W-EIP21 (CJ2)	Yes	Yes
CJ2M-CPU1□	CJ1W-EIP21	CJ1W-EIP21 (CJ2)	No	Yes
CJ1 CPU Unit	CJ1W-EIP21	CJ1W-EIP21	No	Yes
CS1 CPU Unit	CS1W-EIP21	CS1W-EIP21	No	Yes

<sup>1.</sup> To specify an I/O memory address for tag assignment, do not specify the address directly. Instead, create a variable with an AT specification of the I/O memory address on the Sysmac Studio, and then specify the variable for the tag.

<sup>\*2.</sup> For NX102 and NX1P2 CPU Units, you need to set memory used for CJ-series Unit to use the I/O memory address. For details on memory settings used for CJ-series Unit, refer to the NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501).


# 9-5 QuickConnect

The NX-series EtherNet/IP Unit supports the QuickConnect function of the EtherNet/IP standard. This allows for fast start and connection to the EtherNet/IP network.

The QuickConnect function is mainly used for the following purposes.

- · Fast switching of tools at the tip of the robot
- · Changing the production line equipment

The following gives an example of fast switching of the tools at the tip of the robot. Use the QuickConnect function to quickly switch between tools.



### 9-5-1 Method of Use

Use the QuickConnect function as follows.

- When the communications port of the NX-series EtherNet/IP Unit is online, turn ON the power supply of the device that is an adapter, and execute the TDLinkStartConnection (Start Tag Data Link Target Connection) instruction to start the tag data link after a certain period of time.
- Also, execute the TDLinkStopConnection (Stop Tag Data Link Target Connection) instruction to stop the tag data link before turning OFF the power supply of the device that is an adapter.

Refer to Section 13 Instructions Specific to NX-series EtherNet/IP Units on page 13-1 for detailed instruction specifications.

If the NX-series EtherNet/IP Unit is disconnected from the network without stopping the tag data link with the target node, a *Tag Data Link Error* occurs.

A *Tag Data Link Error* also occurs if the correct IP address is not set for the switched target node after starting the tag data link with the target node. A *Verification Error* occurs if the correct connection settings are not configured on the switched target node.

# 9-5-2 Managed Switches

To use the QuickConnect function, the managed switches that support the QuickConnect function are required. Follow the instructions in the operation manual of the managed switches for details on the settings on the managed switch side.



# **CIP Message Communications**


10-1 Overv	view of the CIP Message Communications Service	10-2
10-1-1	Overview of the CIP Message Communications Service	
10-1-2	Message Communications Service Specifications	
10-2 Client	Function of CIP Message Communications	10-3
10-2-1	Overview	
10-2-2	CIP Communications Instructions	10-3
10-2-3	Using CIP Communications Instructions	10-4
10-2-4	Route Path	10-4
10-2-5	Request Path (IOI)	10-13
10-2-6	Service Data and Response Data	
10-2-7	Operation Timing	10-18
10-2-8	Response Codes	10-19
10-3 Serve	r Function of CIP Message Communications	10-23
10-3-1	CIP Message Structure for Accessing CIP Objects	
10-4 Speci	fying Request Path	10-26
10- <b>4</b> -1	Examples of CIP Object Specifications	
10-4-2	Logical Segment	10-27
10-5 CIP O	bject Services	10-28
10-5-1	CIP Objects Sent to the EtherNet/IP Port	
10-5-2	Identity Object (Class ID: 01 hex)	
10-5-3	TCP/IP Interface Object (Class ID: F5 hex)	10-32
10-5-4	Ethernet Link Object (Class ID: F6 hex)	

# 10-1 Overview of the CIP Message Communications Service

# 10-1-1 Overview of the CIP Message Communications Service

CIP commands can be sent to devices on the EtherNet/IP network whenever they are required. You execute CIP\_SEND instructions in a program in the NJ/NX-series CPU Unit to send CIP commands, such as those to read and write data and to receive the responses.

You can use CIP messages from the client to read and write memory in the Controller with the server without adding any special programming to the user program of the Controller with the server.



# 10-1-2 Message Communications Service Specifications

Ite	em	Specification		
Message type		Either of the following can be selected.		
		CIP UCMM connectionless messages		
		CIP class 3 connection messages		
Execution method		CIPSend (Send Explicit Message Class 3) instruction or CI-		
		PUCMMSend (Send Explicit Message UCMM) instruction		
Data contents		Sending required CIP commands and receiving responses		
Communications para	meters	Message type, timeout value, and route path specification		
Maximum length per	Non-connection type	502 bytes		
connection	(UCMM)			
	Connection type	Using Forward_Open		
	(class 3)	502 bytes		
		Using Large_Forward_Open		
		8,192 bytes		


# 10-2 Client Function of CIP Message Communications

### 10-2-1 Overview

The NX-series EtherNet/IP Units can send a CIP message to an external device to request a service by specifying an internal object of the device which supports the server function of CIP message communications.

This is called the client function of CIP message communications.

The NX-series EtherNet/IP Units execute CIP communications instructions in the user program and send CIP messages.



### 10-2-2 CIP Communications Instructions

The following CIP communications instructions are available.

For details on CIP communications instructions, refer to the *NJ/NX-series Instructions Reference Manual (Cat. No. W502*).

Instruc- tions	Name	Description	Communica- tions method
CIPUCMM-	Send Explicit Mes-	Sends a specified CIP command to the specified remote	CIP UCMM
Send	sage UCMM	Controller on the CIP network.	connectionless
		Refer to 10-2-8 Response Codes on page 10-19 and	message
		10-5 CIP Object Services on page 10-28 for informa-	
		tion on the service codes and response codes that are	
		used with the NJ/NX-series CPU Units.	

Instruc- tions	Name	Description	Communica- tions method
CIPOpen	Open CIP Class 3 Connection (Large_For- ward_Open)	Opens a CIP class 3 connection (Large_Forward_Open) with the specified remote node.	CIP class 3 connection message
CIPOpen- WithData- Size	Open CIP Class 3 Connection with Specified Data Size	Opens a CIP class 3 connection with the specified remote node that allows class 3 explicit messages of the specified data length or shorter to be sent and received.	
CIPSend	Send Explicit Message Class 3	Sends a specified class 3 CIP command to the specified remote Controller on the CIP network.  Refer to 10-2-8 Response Codes on page 10-19 and 10-5 CIP Object Services on page 10-28 for information on the service codes and response codes that are used with the NJ/NX-series CPU Units.	
CIPClose	Close CIP Class 3 Connection	Closes the CIP class 3 connection that is specified by the handle.	

# **10-2-3 Using CIP Communications Instructions**

CIP message communications include the following processes.

If CIP class 3 connections are used, the open and close processes are required before and after the data is sent and received.

Process	Description	Instruction
Open process (only for CIP class 3 connections) <sup>*1</sup>	Execute this process before you use a CIP message.  Open processing is continued until a CIP class 3 connection is established.	CIPOpen CIPOpenWithData- Size
Sending CIP commands	You can set the required CIP command.	CIPUCMMSend CIPSend
Close process (only for CIP class 3 connections)	This process closes the connection.	CIPClose

<sup>\*1.</sup> The maximum number of connection handles that you can obtain simultaneously through the opening process is 32. Even if a connection is disconnected for a timeout, the handle is not released. Execute the CIP-Close instruction to close the connection.



#### **Precautions for Correct Use**

You can execute up to 32 CIP communications instructions at the same time regardless of the instruction types.

Use exclusive control in the user program so that the number of CIP communications instructions executed at the same time does not exceed the above number.

## 10-2-4 Route Path

The route path indicates the path from the source Controller of CIP communications instructions to the destination Controller on the network.

Routing for CIP communications instructions is performed based on the route path. Set the route path in the *RoutePath* input variable of the CIP communications instructions.


## **Route Path Notation**

The route path describes the route from the source Controller to the destination Controller using the network type number and destination address as follows.

### Network type number\#Destination address\Network type number\#Destination address

Do not add # to the network type number, and add # to the beginning of the destination address.

The meaning of network type number and destination address is described below.



## Network Type Number

A network type number is a number that is assigned to each port on the path to the destination Controller. There are two types of port: backplane port and communications port.

A backplane port is a port between CIP Protocol Stacks\*1 in the CPU Unit or the NX-series Ether-Net/IP Unit. The NX502 CPU Unit and NX-series EtherNet/IP Unit each have two built-in CIP Protocol Stacks. CIP Protocol Stack1 is connected to the EtherNet/IP port 1 and CIP Protocol Stack2 is connected to the EtherNet/IP port 2.

A communications port is an EtherNet/IP port on the NX-series EtherNet/IP Unit.

The network type numbers that are assigned to the backplane port and communications port are as follows.

Port	Network type number (hexadecimal)
Backplane port	#01
Communications port	#02

<sup>\*1.</sup> A CIP Protocol Stack is a collection of communications protocols related to CIP message communications that are gathered to perform the CIP message communications. The CIP Protocol Stack has the function to send, receive, and transfer the communications data from one port to another port.

### Destination Address

The destination address indicates the address of the Controller at the destination of the port or the CIP Protocol Stack in the Controller. The destination address of the Controller is represented by the IP address of the EtherNet/IP port on that Controller. The destination address of the CIP Protocol Stack is determined as follows.

Destination Unit	Unit number	CIP Protocol Stack	Destination address (hexadecimal)
CPU Unit		CIP Protocol Stack1	#00
		CIP Protocol Stack2	#01
NX-series EtherNet/IP Unit	1	CIP Protocol Stack1	#10
		CIP Protocol Stack2	#11
	2	CIP Protocol Stack1	#20
		CIP Protocol Stack2	#21
	3	CIP Protocol Stack1	#30
		CIP Protocol Stack2	#31
	4	CIP Protocol Stack1	#40
		CIP Protocol Stack2	#41


# **Route Path Notation Examples**

The following gives examples of route path.

- Communicating from the EtherNet/IP port 1 on an NX-series EtherNet/IP Unit to the EtherNet/IP port 1 on an NX701 CPU Unit
- Communicating from the EtherNet/IP port 2 on an NX-series EtherNet/IP Unit to CIP Protocol Stack2 via the EtherNet/IP port 1 on an NX701 CPU Unit
- Communicating from the EtherNet/IP port 1 on an NX701 CPU Unit to the EtherNet/IP port 1 on an NX-series EtherNet/IP Unit
- Communicating from the EtherNet/IP port 2 on an NX701 CPU Unit to CIP Protocol Stack1 via the EtherNet/IP port 2 on an NX-series EtherNet/IP Unit
- Communicating from the EtherNet/IP port 1 on an NX-series EtherNet/IP Unit with unit number 2 to the EtherNet/IP port 1 on an NX701 CPU Unit

 Communicating from the EtherNet/IP port 2 on an NX701 CPU Unit to CIP Protocol Stack1 via the EtherNet/IP port 2 on an NX-series EtherNet/IP Unit with unit number 2

# Communicating from the EtherNet/IP Port 1 on an NX-series Ether-Net/IP Unit to the EtherNet/IP Port 1 on an NX701 CPU Unit




The network type numbers and the destination addresses for routes (a) and (b) in the above figure are as shown in the table below.

Route	Network type number	Destination address
(a)	#01	#10
(b)	#02	192.168.1.7

Therefore, the route path is as follows.

01\#10\02\192.168.1.7

# Communicating from the EtherNet/IP Port 2 on an NX-series Ether-Net/IP Unit to CIP Protocol Stack2 via the EtherNet/IP Port 1 on an NX701 CPU Unit




The network type numbers and the destination addresses for routes (a) to (d) in the above figure are as shown in the table below.

Route	Network type number	Destination address
(a)	#01	#01
(b)	#01	#11
(c)	#02	192.168.2.7
(d)	#01	#01

Therefore, the route path is as follows. 01\#01\01\#11\02\192.168.2.7\01#01

# Communicating from the EtherNet/IP Port 1 on an NX701 CPU Unit to the EtherNet/IP Port 1 on an NX-series EtherNet/IP Unit




The network type numbers and the destination addresses for routes (a) and (b) in the above figure are as shown in the table below.

Route	Network type number	Destination address
(a)	#02	192.168.1.1
(b)	#01	#00

Therefore, the route path is as follows.

02\192.168.1.1\01#00

# Communicating from the EtherNet/IP Port 2 on an NX701 CPU Unit to CIP Protocol Stack1 via the EtherNet/IP Port 2 on an NX-series EtherNet/IP Unit




The network type numbers and the destination addresses for routes (a) to (d) in the above figure are as shown in the table below.

Route	Network type number	Destination address
(a)	#01	#01
(b)	#02	192.168.2.1
(c)	#01	#01
(d)	#01	#00

Therefore, the route path is as follows. 01\#01\02\192.168.2.1\01\#01\01\#00

# Communicating from the EtherNet/IP Port 1 on an NX-series Ether-Net/IP Unit with Unit Number 2 to the EtherNet/IP Port 1 on an NX701 CPU Unit




The network type numbers and the destination addresses for routes (a) and (b) in the above figure are as shown in the table below.

Route	Network type number	Destination address
(a)	#01	#20
(b)	#02	192.168.1.7

Therefore, the route path is as follows.

01\#20\02\192.168.1.7

# Communicating from the EtherNet/IP Port 2 on an NX701 CPU Unit to CIP Protocol Stack1 via the EtherNet/IP Port 2 on an NX-series EtherNet/IP Unit with Unit Number 2



The network type numbers and the destination addresses for routes (a) to (d) in the above figure are as shown in the table below.

Route	Network type number	Destination address
(a)	#01	#01
(b)	#02	192.168.2.2
(c)	#01	#01
(d)	#01	#00

Therefore, the route path is as follows. 01\#01\02\192.168.2.2\01\#01\01\#00


# 10-2-5 Request Path (IOI)

A request path indicates an object of a device on the network.

A CIP communications instruction uses the request path to access an object of a device.

# **Overview of Request Path**

In the CIP world, each device is modeled as a collection of objects. An Object abstractly represents the specific configuration elements of a device.




In the CIP Common Specification, Object, Class, Instance, Attribute, and Service are defined as follows: (Source: CIP Common Specification)

Term	Definition	
Object	An abstract representation of a particular component within a device.	
Class	A set of objects that all represent the same kind of system component.	
Instance	A specific and real (physical) occurrence of an object.	
Attribute	A description of an externally visible characteristic or feature of an object.	
Service	A request from an external object (e.g., to read data).	

You use the Class ID Instance ID and Attribute ID to access an object.

You specify these three IDs to designate an object in a device.

When you make a request from an external device for a service, you must specify the Class ID Instance ID and Attribute ID. (The Instance ID and Attribute ID are not required for some services.)



These are called *IOI* (Internal Object Identifier) because they identify the Class ID, Instance ID, and Attribute ID within the device.

Refer to 10-5 CIP Object Services on page 10-28 for the class ID, instance ID, attribute ID, and service code for each object.

# **Providing the Structure Variables to Input Request Paths**


For a CIP communications instruction, you prepare a variable to store the request path. In this variable, you specify the object to access with the user program.

A structure in which the Class ID, Instance ID, and Attribute ID are specified is provided for the data type of a variable for a request path.

There are two types of structures: standard structure (\_sREQUEST\_PATH) and extension structure (\_sREQUEST\_PATH\_EX). When you use an extension structure, it is possible to specify the size according to the size of values of the Class ID, Instance ID, and Attribute ID of the object that you access. When you use a standard structure, the size is always set to 16 bits.


### When a Standard Structure Variable Is Used

Example: Using a standard structure variable to input values into *RqPath* (Request Path) for the CIPSend instruction



**1** Create a standard structure variable.

To use a standard structure variable to input values into *RqPath* (Request Path) for a CIP communications instruction, first you need to create a standard structure user-defined variable. When you create a variable in a variable table, select the pre-registered standard structure (\_sREQUEST\_PATH) for a CIP communications instruction.




Select a standard structure for the data type of variable A.

**2** Input a value for each standard structure variable member.

10-14


Input the following values into the communications parameters that were registered as members of the standard structure variable.



### When an Extension Structure Variable Is Used

Example: Using an extension structure variable to input values into *RqPath* (Request Path) for the CIPSend instruction


Create variable *A* with a variable with the extension structure (\_sREQUEST\_PATH\_EX).



# **1** Create an extension structure variable.


To use an extension structure variable to input values into *RqPath* (Request Path) for a CIP communications instruction, first you need to create an extension structure user-defined variable.

When you create a variable in a variable table, select the pre-registered extension structure (\_sREQUEST\_PATH\_EX) for a CIP communications instruction.



Select an extension structure for the data type of variable A.

Input a value for each extension structure variable member.
Input the following values into the communications parameters that were registered as members of the extension structure variable.



# 10-2-6 Service Data and Response Data

CIP communications instructions send and receive data that is stored in array variables.


# Preparing Array Variables to Input and Output Service Data and Response Data

This section describes the array variables for storing service data and response data that CIP communications instructions send and receive.

# Creating Array Variables


To input a value into the array variable of a CIP communications instruction, you must create a variable with the same configuration as the array variable in advance.

Example: Creating a Variable to Input Data to the CIPSend Instruction Array Variables




### (1) Input the service data to send


The data to send is stored in array variable *A*. If only certain elements are specified in array variable *A*, specify the number of elements in variable *B*.



The byte size of the data that was actually received is stored in variable *C*.




If the service data (ServiceDat) is Array[2] and number of elements (Size) = 2, Array[2] and Array[3] are sent.



Use the following procedure to create a variable in the variable table.

Specify the element first number, the element last number, and the data type.

Example: UINT Array



## CIP Communications Instructions That Use Array Variables


Instruction	Structure variable name		
Instruction	Input variable	In-out variable	Output variable
CIPSend	ServiceDat (Command Da-	ResServiceDat (Response	
	ta)	Data)	

# 10-2-7 Operation Timing

# **Output Variable Operation and Timing**

You can monitor the values of the output variables to determine the status throughout instruction execution.

The following timing chart shows the operation of the output variables.



- 1. When Execute changes to TRUE, the instruction is executed and Busy changes to TRUE.
- 2. After the results of instruction execution are stored in the output variables, *Done* changes to TRUE and *Busy* changes to FALSE.
- 3. When Execute changes to FALSE, Done returns to FALSE.
- 4. When Execute changes to TRUE again, Busy changes to TRUE.
- 5. Execute is ignored if it changes to TRUE during instruction execution (i.e., when Busy is TRUE).
- 6. If an error occurs, several retries are attempted internally. The error code in *ErrorID* is not updated during the retries.
- 7. When a communications error occurs, *Error* changes to TRUE and the value of *ErrorID* is stored. Also, *Busy* and *Done* change to FALSE.
- 8. When Execute changes to FALSE, Error changes to FALSE.




#### **Precautions for Correct Use**

If *Execute* changes back to FALSE before *Done* changes to TRUE, *Done* stays TRUE for only one task period. (Example 1)

If you want to see if *Done* is TRUE at any time, make sure to keep *Execute* TRUE until you confirm that *Done* is TRUE.

If *Execute* is TRUE until *Done* changes to TRUE, *Done* stays TRUE until *Execute* changes to FALSE. (Example 2)




# 10-2-8 Response Codes

This section describes the response codes stored in the *ErrorIDEx* output variable if an error occurs during execution of a CIP message communications instruction.

# **General Status Codes**

As response codes, general codes are stored in the *ErrorIDEx* output variable (DWORD data) after execution of a CIP communications instruction is completed.

If an additional code is added, the additional code is also stored.



General status code (hex)	Status name	Description of status
00	Success	Service was successfully performed by the object specified.
01	Connection failure	A connection related to service failed along the connection path.
02	Resource unavailable	Resources needed for the object to perform the requested service were unavailable.
03	Invalid parameter value	See Status Code 20 hex.
04	Path segment error	The path segment identifier or the segment syntax was not understood by the processing node. Path processing stops when a path segment error occurs.
05	Path destination unknown	The path is referencing an object class, instance, or structure element that is not known or is not contained in the processing node. Path processing stops when a Path Destination Unknown Error occurs.

General status code (hex)	Status name	Description of status
06	Partial transfer	Only part of the expected data was transferred.
07	Connection lost	The message connection was lost.
08	Service not supported	The requested service was not supported or was not defined for this object class/instance.
09	Invalid attribute value	Invalid attribute data was detected.
0A	Attribute list error	An attribute in the Get_Attribute_List or Set_Attribute_List response has a non-zero status.
0B	Already in requested mode/state	The object is already in the mode/state being requested by the service.
0C	Object state conflict	The object cannot perform the requested service in its current mode/ state.
0D	Object already exists	The requested instance of object to be created already exists.
0E	Attribute not settable	A request to modify a non-modifiable attribute was received.
0F	Privilege violation	A permission/privilege check failed.
10	Device state conflict	The device's current mode/state prohibits the execution of the requested service.
11	Reply data too large	The data to be transmitted in the response buffer is larger than the allocated response buffer.
12	Fragmentation of a primitive value	The service specified an operation that is going to fragment a primitive data value, i.e. half a REAL data type.
13	Not enough data	The requested service did not supply enough data to perform the specified operation.
14	Attribute not supported	The attribute specified in the request is not supported.
15	Too much data	The service supplied more data than was expected.
16	Object does not exist	An object that does not exist was specified for the requested service.
17	Service fragmentation sequence not in progress	The fragmentation sequence for this service is not currently active for this data.
18	No stored attribute data	The attribute data of this object was not saved prior to the requested service.
19	Store operation failure	The attribute data of this object was not saved due to a failure during the attempt.
1A	Routing failure (request packet too large)	The service request packet was too large for transmission on a network in the path to the destination. The routing device was forced to abort the service.
1B	Routing failure (response packet too large)	The service response packet was too large for transmission on a network in the path from the destination. The routing device was forced to abort the service.
1C	Missing attribute list entry data	The service did not supply an attribute in a list of attributes that was needed by the service to perform the requested behavior.
1D	Invalid attribute value list	The service is returning the list of attributes supplied with status information for those attributes that were invalid.
1E	Embedded service error	An embedded service resulted in an error.
1F	Vendor specific error	A vendor-specific error occurred. The Additional Code Field of the error response defines the error. This is a general error code that is used only for errors that do not correspond to any of the error codes in this table and are not in an object class definition.

General status code (hex)	Status name	Description of status
20	Invalid parameter	A parameter for the requested service is invalid. This code is used when a parameter does not meet the requirements of the specification and/or the requirements defined in an application object specification.
21	Write-once value or medi- um already written	An attempt was made to write to a write-once medium (e.g. WORM drive or PROM) that was previously written or cannot be changed.
22	Invalid Reply Received	An invalid reply was received. (For example, the reply service code does not match the request service code. Or, the reply message is shorter than the minimum expected reply size.) This status code is used for other causes of invalid replies.
23-24		Reserved by CIP for future extensions.
25	Key Failure in path	The key segment that was included as the first segment in the path does not match the destination module. The object specific status must indicate which part of the key check failed.
26	Path Size Invalid	The size of the path that was sent with the service request is either too large or too small for the request to be routed to an object.
27	Unexpected attribute in list	An attempt was made to set an attribute that is not able to be set at this time.
28	Invalid Member ID	The member ID specified in the request does not exist in the specified class, instance, and attribute.
29	Member not settable	A request to modify a non-modifiable member was received.
2A	Group 2 only server general failure	This error code is reported only by group 2 only servers with 4K or less of code space and only in place of Service not supported, Attribute not supported, or Attribute not settable.
2B-CF		Reserved by CIP for future extensions.
D0-FF	Reserved for Object Class and service errors	This range of error codes is to be used to indicate object class-specific errors. This code range is used only when none of the error codes in this table accurately reflect the error that occurred. The additional code field is used to describe the general error code in more detail.

# Examples of Additional Status When General Status Is 01 hex (Status of Connection Manager Object)

General Status (hex)	Additional Status (hex)	Description
01	0100	Connection in use or duplicate forward open.
01	0103	Transport class and trigger combination not supported.
01	0106	Ownership conflict.
01	0107	Connection not found at target application.
01	0108	Invalid connection type. There is a problem with either the connection type or priority of the connection.
01	0109	Invalid connection size.
01	0110	Device not configured.
01	0111	RPI not supported. May also indicate problem with connection time-out multiplier, or production inhibit time.
01	0113	Connection Manager cannot support any more connections.

General Status (hex)	Additional Status (hex)	Description
01	0114	Either the vendor ID or the product code in the key segment does not match
		the device.
01	0115	Device type in the key segment does not match the device.
01	0116	Major Revision or Minor Revision in the key segment.
01	0117	Invalid connection point.
01	0118	Invalid configuration format.
01	0119	Connection request failed because there is no controlling connection currently open.
01	011A	Target application cannot support any more connections.
01	011B	RPI is smaller than the production inhibit time.
01	0203	Connection cannot be closed because the connection has timed out.
01	0204	Unconnected_Send service timed out while waiting for a response.
01	0205	Parameter error in Unconnected_Send service.
01	0206	Message too large for unconnected message service.
01	0207	Unconnected acknowledgment without reply.
01	0301	No buffer memory available.
01	0302	Network bandwidth not available for data.
01	0303	No tag filters available.
01	0304	Not configured to send real-time data.
01	0311	Port that was specified in port segment is not available.
01	0312	Link address that was specified in port segment is not available.
01	0315	Invalid segment type or segment value in path.
01	0316	Path and connection were not equal when closing the connection.
01	0317	The segment is not present. Or, the encoded value in the network segment is invalid.
01	0318	Link address to self is invalid.
01	0319	Resources on secondary are unavailable.
01	031A	Connection is already established.
01	031B	Direct connection is already established.
01	031C	Others
01	031D	Redundant connection mismatch.
01	031E	There are no more reception resources available on the sending module.
01	031F	No connection resources exist for the target path.
01	0320-07FF	Vendor specific.

# 10-3 Server Function of CIP Message Communications

After the NX-series EtherNet/IP Unit receives the CIP messages from external devices, this function executes services for a specified self-contained object in the NX-series EtherNet/IP Unit. This is called the server function of CIP message communications.


This section describes the structure of CIP messages that are sent to read/write CIP objects from/to the NX-series EtherNet/IP Unit from a program on a computer, etc. using the server function of CIP message communications.

To read and write CIP objects between NX-series EtherNet/IP Units or between an NX-series EtherNet/IP Unit and an NJ/NX-series Controller, use the CIP communications instructions.

Refer to 10-2 Client Function of CIP Message Communications on page 10-3 for information on how

to use CIP communications instructions for CIP message communications.

Request Computer





#### **Precautions for Correct Use**

- To allow the NX-series EtherNet/IP Unit to receive CIP messages, select the Use Option for the CIP message server of the EtherNet/IP port. If the Do not use Option for the CIP message server is selected, the Unit cannot receive CIP messages. For the details on the settings, refer to CIP Message Server on page 7-15.
- If the Use Option is selected for Packet Filter of the EtherNet/IP port, make sure to permit
  packets to be used for CIP messages. If they are not permitted, the CIP message cannot be
  received. For the details on the settings, refer to Packet Filter on page 7-7.
- If the **Do not use**, Option for the CIP message server is selected, EtherNet/IP communications cannot be used. This causes the following restrictions on the functionality of connection tools and Controllers.

Category	Restrictions	
Tools	Tag data link setting using Sysmac Studio is not possible.	
	CX-Compolet and SYSMAC Gateway cannot be connected. *1	
	Network Configurator cannot be connected. Or, devices cannot be displayed.	
Controller	The tag data link function cannot be used.	
features	CIP Safety communications cannot be used.	
	The server function of CIP messages (UCMM, Class3) in the EtherNet/IP port cannot	
	be used.	

- \*1. The tag monitoring function of CX-Compolet and the tag monitoring function of the EtherNet/IP Monitor Tool included with the SYSMAC Gateway do not allow the NX-series EtherNet/IP Unit to be specified as a connected device.
- NX-series EtherNet/IP Units do not have the server function of CIP message communications
  to read and write variables. However, they can use CIP routing to read/write variables from/to
  the NX-series EtherNet/IP Unit. Refer to the NJ/NX-series CPU Unit Built-in EtherNet/IP Port
  User's Manual (Cat. No. W506) for details on the CIP routing function of the CPU Unit.



#### **Additional Information**


- Selecting the **Do not use** Option for the CIP message server closes the TCP/UDP ports used for EtherNet/IP communications. This improves security of communications over the network.
- Even if the **Do not use** Option for the CIP message server is selected, the TCP/UDP message services can be used. You can also use the client function (CIP communications instructions) of CIP message communications.

# 10-3-1 CIP Message Structure for Accessing CIP Objects

This section shows how to specify messages to access CIP objects.

The CIP objects to be accessed are expressed by connecting the segments defined in the CIP Common Specifications in the request path field in a CIP explicit message.

Example: Performing the Reset service (0x05) to the Instance (01 hex) of the Identity object (class: 01 hex)



<sup>\*1.</sup> Refer to 10-5 CIP Object Services on page 10-28 for information about the service codes.

# 10-4 Specifying Request Path

The CIP object is specified in the request path.

In CIP, the EPATH data type is used for the request path.

With this method, the request path is divided into segments and a value is assigned to each segment.

The request path notation shows the path to the final destination when the data segments are joined together.

Each segment includes the segment type information and the segment data.

The first byte gives the interpretation method for the segment. It consists of two parts; a 3-bit segment type and a 5-bit segment format.

Segment Type			Segment Format				at	
7	6	5		4	3	2	1	0

The segment type specifications are defined as follows in the CIP specifications.

Seg	ment T	уре	Magning		
7	6	5	Meaning		
0	0	0	Port Segment		
0	0	1	Logical Segment		
0	1	0	Network Segment		
0	1	1	Symbolic Segment		
1	0	0	Data Segment		
1	0	1	Data Type		
1	1	0	Data Type		
1	1	1	Reserved		

The specifications for the segment format are different for each segment type. Use the segment format to request a service from a particular object of a particular device.

Logical segments and data segments, which are needed to specify variables in CIP message communications, are described below.


#### 10-4-1 **Examples of CIP Object Specifications**

Logical Segments are joined to form the request path that specifies the object to access.

Logical Segment (Class ID)	Logical Segment (Instance ID)	Logical Segment (Attribute ID)		
Specify the Class ID.	Specify the Instance ID.	Specify the Attribute ID.		

# 10-4-2 Logical Segment

A logical segment is used to give the CIP Object in the request path.



Lo	Logical Type		Meaning		
4	3	2	Meaning		
0	0	0	Class ID		
0	0	1	Instance ID		
0	1	0	Member ID		
0	1	1	Connection Point		
1	0	0	Attribute ID		
1	0	1	Special (Do not use the logical addressing definition for the Logical Format.)		
1	1	0	Service ID (Do not use the logical addressing definition for the Logical Format.)		
1	1	1	Reserved		

Logical Format		Meaning
1	0	
0	0	8 bit logical address
0	1	16 bit logical address
1	0	32 bit logical address
1	1	Reserved

An 8-bit or 16-bit logical address can be used for the class ID and attribute ID.

An 8-bit,16-bit, or 32-bit logical address can be used for the instance ID.

# 10-5 CIP Object Services

This section shows services that specify the CIP object in the Request Path and access the CIP message server function of the NJ/NX-series Controllers.

# 10-5-1 CIP Objects Sent to the EtherNet/IP Port

The following CIP objects can be sent to an EtherNet/IP port.

Object name	Function	Reference
Identity object	Reads ID information from the CPU Unit.	page 10-28
	Resets the EtherNet/IP port.	
TCP/IP interface object	Writes and reads TCP/IP settings.	page 10-32
Ethernet link object	Makes Ethernet settings and reads the settings.	page 10-35
	Reads Ethernet status.	

### 10-5-2 Identity Object (Class ID: 01 hex)

This object reads the ID information of the Unit and resets the EtherNet/IP port.

Use the route path to specify the port number (1 or 2) of the EtherNet/IP port to access.

# **Service Codes**

Specify the service to execute with the service code.

Service	B	D	Supported serv- ices		
code	Parameter name	Description	Classes	Instan- ces	
01 hex	Get_Attribute_All	Reads the values of the attributes.	Support- ed	Support- ed	
0E hex	Get_Attribute_Single	Reads the value of the specified attribute.	Support- ed	Support- ed	
05 hex	Reset	Resets the EtherNet/IP port.  This parameter is used to reset the EtherNet/IP port when you change the IP address or other parameter settings and want to apply them.  Input one of the following values for the ServiceDat input variable to the CIPSend instruction to specify the reset method.  00 hex: Resets the EtherNet/IP port.  02 hex: Clears the saved tag data link settings and resets the EtherNet/IP port.	Not sup- ported	Support- ed	

#### **Class ID**

Specify 01 hex.

# **Instance ID**

Specify 00 or 01 hex.

# **Attribute ID**

The attribute ID specifies the information to read.

#### Class Attribute ID

The class attribute ID specifies the attribute of the entire object.

			Attrib-	Read data		
Attribute ID	Parameter name	Description	ute	Data type	Value	
01 hex	Revision	Revision of the object	Read	UINT	0001 hex	
02 hex	Max Instance	The maximum instance number	Read	UINT	0001 hex	

#### Instance Attribute ID

The instance attribute ID specifies the attribute of the instance.

				Read data		
Attribute ID	Parameter name	Description	Attribute	Data type	Value	
01 hex	Vendor ID	Vendor ID	Read	UINT	002F hex	
02 hex	Device Type	Device type	Read	UINT	000C hex	
03 hex	Product Code	Product code	Read	UINT	Refer to (1) Product Codes for Each Model, below.	
04 hex	Revision	Device revision	Read	Struct		
	Major Revision	Major revision	Read	USINT	Refer to (2) Major and Minor	
	Minor Revision	Minor revision	Read	USINT	CIP Revisions, below.	
05 hex	Status	Status of the EtherNet/IP port	Read	WORD	Refer to (3) Status Details of the Built-in EtherNet/IP Port, below.	
06 hex	Serial Number	Serial number	Read	UDINT	Set value	
07 hex	Product Name	Product name	Read	STRIN G	Set value	

#### 1. Product Codes for Each Model

Model	Product Code
NX701-□□□	067D hex
NX502-1300	0BF5 hex
NX502-1400	0BF6 hex
NX502-1500	0BF7 hex
NX-EIP201	0BF4 hex
NX102-1200	0BBB hex
NX102-1100	0BBA hex
NX102-1000	0BB9 hex

Model	Product Code
NX102-9000	0BB8 hex
NX102-1220	0BBF hex
NX102-1120	0BBE hex
NX102-1020	0BBD hex
NX102-9020	0BBC hex
NX1P2-□□□□	068B hex
NJ501-13□□	0665 hex
NJ501-14□□	0666 hex
NJ501-15□□	0667 hex
NJ501-43□□	066E hex
NJ501-44□□	066F hex
NJ501-45□□	0670 hex
NJ501-5300	068C hex
NJ501-R300	069C hex
NJ501-R400	069D hex
NJ501-R500	069E hex
NJ501-R320	069F hex
NJ501-R420	06A0 hex
NJ501-R520	06A1 hex
NJ301-11□□	066B hex
NJ301-12□□	066C hex
NJ101-□□□□	0680 hex

### 2. Major and Minor CIP Revisions

Madal	Unit version	CIP revisions			
Model			Minor revision		
All CPU Unit	Unit version 1.00	01 hex	01 hex		
models	Unit version 1.01 or 1.02		03 hex		
	Unit version 1.03 to 1.08	02 hex	01 hex		
	Unit version 1.09		02 hex		
	Unit version 1.10		03 hex		
	Unit version 1.11 or 1.12		04 hex		
	Unit version 1.13 to 1.20		05 hex		
NJ Series	Unit version 1.21 to 1.23		06 hex		
	Unit version 1.26		08 hex		
	Unit version 1.27		09 hex		
	Unit version 1.40 to 1.41		06 hex		
	Unit version 1.46		08 hex		
	Unit version 1.47		09 hex		
NX Series	Unit version 1.21 to 1.22		06 hex		
	Unit version 1.28		09 hex		
	Unit version 1.30 to 1.43		06 hex		
	Unit version 1.44		08 hex		
	Unit version 1.60		0A hex		
NX-series Ether- Net/IP Unit	Unit version 1.00		0A hex		

#### 3. Status Details of the EtherNet/IP Port

Bit	Name	Description				
0	Owned	Indicates when the EtherNet/IP port has an open connection as the target of				
		a tag data link.				
1	Reserved	Always FALSE.				
2	Configured	Tag data link settings exist.				
3	Reserved	Always FALSE.				
4 to 7	Extended Device Status	Indicates the status of the EtherNet/IP port.*1				
8	Minor Recoverable Fault	TRUE when any of the following errors occurs.				
		IP Router Table Setting Error				
		Tag Data Link Setting Error				
		Tag Data Link Timeout				
		Tag Data Link Connection Timeout				
		FTP Server Setting Error				
		SNMP Setting Error				
		Tag Name Resolution Error				
9	Minor Unrecoverable Fault	TRUE when the following error occurs.				
		Identity Error				
10	Major Recoverable Fault	TRUE when any of the following errors occurs.				
		IP Address Duplication Error				
		BOOTP Server Error				
		Basic Ethernet Setting Error				
		IP Address Setting Error				
11	Major Unrecoverable Fault	TRUE when any of the following errors occurs.				
		Communications Controller Error				
		MAC Address Error				
12 to 15	Reserved	Always FALSE.				

<sup>\*1.</sup> Bits 7 to 4 indicate the status of the EtherNet/IP port.

b7	b6	b5	b4	
0	1	0	1	A major fault occurred.
0	0	1	0	A timeout occurred in one or more target connections.
0	0	1	1	Indicates that there are no tag data link settings.
0	1	1	0	Indicates that one or more connections are performing communications normally.
0	1	1	1	Other than the above.

# Request Paths (IOIs) to Specify Objects

When you specify an object, specify the request path (IOI) for each service code as given below.

S	Service code	Class ID	Instance ID	Attribute ID
01 hex	Get_Attribute_All	01 hex	Specifying a service for a class	Not required.
0E hex	Get_Attribute_Single		: 00 hex • Specifying a service for an instance : Always 01 hex	<ul> <li>Reading a class attribute</li> <li>: 01 or 02 hex</li> <li>Reading an instance attribute</li> <li>: 01 to 07 hex</li> </ul>
05 hex	Reset		Always 01 hex	Not required.

# 10-5-3 TCP/IP Interface Object (Class ID: F5 hex)

This object is used to read and write settings such as the IP address, subnet mask, and default gateway.

It is necessary to use the route path of the CIP communications instruction (the *RoutePath* input variable) to specify the port number (1 or 2) of the EtherNet/IP port to access.

# **Service Codes**

Specify the service to execute with the service code.

Service	Parameter name	Departmen	Supported services		
code	Parameter name	Description	Classes	Instances	
01 hex	Get_Attribute_All	Reads the values of the attributes.	Supported	Not sup- ported	
0E hex	Get_Attribute_Single	Reads the value of the specified attribute.	Supported	Supported	
10 hex	Set_Attribute_Single	Writes a value to the specified attribute. The EtherNet/IP port restarts automatically after the value is written to the attribute. When the next Set_Attribute_Single is executed before the restart process is completed, the general status "0C hex" (Object State Conflict) is returned.	Not sup- ported	Supported	

# **Class ID**

Specify F5 hex.

#### **Instance ID**

Specify 00 or 01 hex. 00: Specify the class

01: EtherNet/IP port

# **Attribute ID**

The attribute ID specifies the information to read.

#### Class Attribute ID

The class attribute ID specifies the attribute of the entire object.

Attrib-					Read data		
ute ID	Parameter name	Description	trib- ute	Data type	Value		
01 hex	Revision	Revision of the object	Read	UINT	0001 hex: Unit version 1.01 or earlier 0002 hex: Unit version 1.02 to 1.09 0003 hex: Unit version 1.10 0004 hex: Unit version 1.11 or later		
02 hex	Max Instance	The maximum instance number	Read	UINT	0001 hex		
03 hex	Number of Instances	The number of object instances	Read	UINT	0001 hex		

### • Instance Attribute ID

The instance attribute ID specifies the attribute of the instance.

			A 44 will		Read/write data
Attribute ID	Parameter name	Description	Attrib- ute	Data type	Value
01 hex	Interface Configuration Status	Indicates the IP address setting status of the interface.	Read	DWOR D	Bits 0 to 3: Interface Configuration Status:  0 = IP address is not set. (This includes when BOOTP is starting.)  1 = IP address is set.  Bits 4 and 5: Reserved (always FALSE).  Bit 6: AcdStatus*1:  FALSE = IP address collisions have not been detected.  TRUE = IP address collisions have been detected.  Bits 7 to 31: Reserved (always FALSE).

			Attrib-		Read/write data
Attribute ID	Parameter name	Description	ute	Data type	Value
02 hex	Configuration Capability	Indicates a Controller Configurations and Setup that can be set to the interface.	Read	DWOR D	Bit 0: BOOTP Client: Always TRUE. Bit 1: DNS Client: Always TRUE. Bit 2: DHCP Client: Always FALSE. Bit 3: DHCP-DNS Update: Always FALSE. Bit 4: Configuration Settable: Always TRUE. Bit 5: Hardware Configurable: Always FALSE. Bit 6: Interface Configuration Change Requires Reset: Always FALSE. Bit 7: ACD Capable*1: Always TRUE. Bits 8 to 31: Reserved (always FALSE).
03 hex	Configuration Control	Sets the method used to set the IP address when the in- terface starts.	Read/ Write	DWOR D	Bit 0 to 3: IP Address Setting Method 0 = Setting the static IP address. 1 = Setting by BOOTP. Bit 4: DNS Enable/Disable Setting FALSE = DNS disabled. TRUE = DNS enabled. Bits 5 to 31: Reserved (always FALSE).
04 hex	Physical Link Object	The path to the link object in the physical layer.	Read	Struct	
	Path size	The path size (WORD size).		UINT	0002 hex
	Path	The path to the link object in the physical layer (static).		EPATH	20 F6 24 01 hex
05 hex	Interface Configura- tion	The interface settings.	Read/ Write	Struct	
	IP Address	IP address.		UDINT	Set value
	Network Mask	Subnet mask.		UDINT	Set value
	Gateway Address	The default gateway.		UDINT	Set value
	Name Server	The primary name server.		UDINT	Set value
	Name Server2	The secondary name server.		UDINT	Set value
	Domain Name	The domain name.		STRIN G	Set value*2
06 hex	Host Name	The host name (reserved).	Read/ Write	STRIN G	Set value*3

<sup>\*1.</sup> The value is always FALSE for a CPU Unit with unit version 1.01 or earlier.

<sup>\*2.</sup> The value is the size of domain name (2 bytes) + domain name (48 bytes max.).

<sup>\*3.</sup> The value is the size of host name (2 bytes) + host name (64 bytes max.).

\*4. The value is always TRUE for CPU Units that support the DHCP client. The value is always FALSE for unsupported CPU Units.

# Request Paths (IOIs) to Specify Objects

When you specify an object, specify the request path (IOI) for each service code as given below.

Service code		Class ID	Instance ID	Attribute ID
01 hex	Get_Attribute_All	F5 hex	Specifying a service for a class: 00	Not required.
0E hex	Get_Attribute_Single		hex	Reading a class attribute: 01
10 hex	Set_Attribute_Single		Specifying a service for an in- stance: 01 hex	or 03 hex • Reading and writing an instance attribute: 01 to 06 hex

# 10-5-4 Ethernet Link Object (Class ID: F6 hex)

This object is used to set and read Ethernet communications and read Ethernet communications status information.

It is necessary to use the route path of the CIP communications instruction (the *RoutePath* input variable) to specify the port number (1 or 2) of the EtherNet/IP port to access.

# **Service Codes**

Specify the service to execute with the service code.

Service	Parameter name	Description	Supported service range		
code	code		Class	Instance	
0E hex	Get_Attribute_Single	Reads the value of the specified attribute.	Support- ed	Support- ed	
10 hex	Set_Attribute_Single	Writes a value to the specified attribute.	Support- ed	Support- ed	
4C hex	Get_and_Clear	Specify Attribute4 or Attribute5 to reset the value of the attribute to 0.	Not sup- ported	Support- ed	

### Class ID

Specify F6 hex.

## **Instance ID**

Specify 00 or 01 hex. 00: Specify the class

01: EtherNet/IP port

# **Attribute ID**

The attribute ID specifies the information to read.

#### • Class Attribute ID

The class attribute ID specifies the attribute of the entire object.

Attrib-			At-		Read data
ute ID	Parameter name	Description	trib- ute	Data type	Value
01 hex	Revision	Revision of the object	Read	UINT	0002 hex: Unit version 1.11 or earlier 0004 hex: Unit version 1.12 or later
02 hex	Max Instance	The maximum instance number	Read	UINT	0001 hex
03 hex	Number of Instances	The number of object instances	Read	UINT	0001 hex

#### • Instance Attribute ID

The instance attribute ID specifies the attribute of the instance.

Attribute			A 44 wills	Read/write data		
ID	Parameter name	Description	Attrib- ute		Value	
01 hex	Interface Speed	Gives the baud rate for the interface.	Read	UDINT	Reads the current value.	
02 hex	Interface Flags	Gives the status of the interface.	Read	DWOR D	Refer to (1) Interface Flag Details, below.	
03 hex	Physical Address	Gives the MAC address of the interface.	Read	ARRAY [05] OF USINT	Reads the current value of the MAC address.	

					Read/write data
Attribute ID	Parameter name	Description	Attrib- ute	Data	Value
				type	
04 hex	Interface Counters	The number of packets sent/	Read	Struct	
		received through the interface.			
	In Octets	The number of octets re-		UDINT	Reads the current value.
		ceived through the interface.			
		This includes unnecessary			
		multicast packets and dis-			
		carded packets counted by InDiscards.			
	In Unicast Packets	The number of unicast pack-		UDINT	Reads the current value.
	III Officast Facilities	ets received through the inter-		ODIIVI	reads the ourient value.
		face. This does not include			
		discarded packets counted by			
		InDiscards.			
	In NonUnicast Packets	The number of packets be-		UDINT	Reads the current value.
		sides unicast packets received through the interface.			
		This includes unnecessary			
		multicast packets, but does			
		not include discarded packets			
		counted by InDiscards.			
	In Discards	The number of discarded in-		UDINT	Reads the current value.
		coming packets received through the interface.			
	In Errors	The number of incoming		UDINT	Reads the current value.
		packets that had errors. This			
		is not included in InDiscards.			
	In Unknown Protos	The number of incoming		UDINT	Reads the current value.
		packets that were of an un-			
	Out Octets	known protocol.  The number of octets sent		UDINT	Reads the current value.
	Out Octors	through the interface.		ODIIVI	reads the current value.
	Out Unicast Packets	The number of unicast pack-		UDINT	Reads the current value.
		ets sent through the interface.			
	Out NonUnicast Pack-	The number of packets be-		UDINT	Reads the current value.
	ets	sides unicast packets sent			
	Out Discards	through the interface.  The number of discarded sent		UDINT	Reads the current value.
	Out Discards	packets.		ואווסט	incaus the current value.
	Out Errors	The number of sent packets		UDINT	Reads the current value.
		that had errors.			

A 44 11 4			A !!	Read/write data		
Attribute ID	Parameter name	Description	Attrib- ute	Data type	Value	
05 hex	Media Counters	Media counters for the communications port.	Read	Struct		
	Alignment Errors	Number of frames received that were not octets in length.		UDINT	Reads the current value.	
	FCS Errors	Number of frames received that did not pass the FCS check.		UDINT	Reads the current value.	
	Single Collisions	Number of frames sent successfully with only one collision.		UDINT	Reads the current value.	
	Multiple Collisions	Number of frames sent successfully with two or more collisions.		UDINT	Reads the current value.	
	SQE Test Errors	Number of times a SQE test error message was generated.		UDINT	Reads the current value.	
	Deferred Transmissions	The number of frames for which the first attempt to send was delayed because the media was busy.		UDINT	Reads the current value.	
	Late Collisions	The number of collisions detected in packets that were sent after 512 bit times.		UDINT	Reads the current value.	
	Excessive Collisions	The number of frames that failed to be sent because of excessive collisions.		UDINT	Reads the current value.	
	MAC Transmit Errors	The number of frames that failed to be sent due to an internal MAC sublayer transmission error.		UDINT	Reads the current value.	
	Carrier Sense Errors	The number of times the carrier sense condition was lost or the number of times an assertion did not occur when an attempt was made to send the frame.		UDINT	Reads the current value.	
	Frame Too Long	The number of frames received that exceeded the maximum allowed frame size.		UDINT	Reads the current value.	
	MAC Receive Errors	The number of frames that could not be received through the interface due to an internal MAC sublayer reception error.		UDINT	Reads the current value.	

A ( ) 1			Read/write d		Read/write data
Attribute ID	Parameter name	Description	Attrib- ute	Data type	Value
06 hex	Interface Control	Control settings for the interface.	Read/ Write	Struct	
	Control Bits	Auto Nego for Ethernet communications that specifies full duplex.		WORD	Refer to (2) Control Bit Details, below.
	Forced Interface Speed	Gives the set value of the Ethernet baud rate.		UINT	Reads the set value.
0C hex *1	HC Interface Counters	The number of packets sent/ received through the HC interface.	Read	Struct	
	HCInOctets	The number of octets received through the interface. This counter is the 64-bit edition of In Octets.		ULINT	Reads the current value.
	HCInUnicastPkts	The number of unicast packets received through the interface. This counter is the 64-bit edition of In Ucast Packets.		ULINT	Reads the current value.
	HCInMulticastPkts	The number of multicast packets received through the interface.		ULINT	Reads the current value.
	HCInBroadcastPkts	The number of broadcast packets received through the interface.		ULINT	Reads the current value.
	HCOutOctets	The number of octets sent through the interface.		ULINT	Reads the current value.
	HCOutUnicastPkts	The number of unicast packets sent through the interface. This counter is the 64-bit edition of Out Octets.		ULINT	Reads the current value.
	HCOutMulticastPkts	The number of multicast packets sent through the interface.		ULINT	Reads the current value.
	HCOutBroadcastPkts	The number of broadcast packets sent through the interface.		ULINT	Reads the current value.

A II			A 11		Read/write data
Attribute ID	Parameter name	Description	Attrib- ute	Data	Value
				type	33343
0D hex*1	HC Media Counters	Media counters for the communications port.	Read	Struct	
	HCStatsAlignmentErrors	The number of frames received that were not octets in length. This counter is the 64-bit edition of Alignment Errors.		ULINT	Reads the current value.
	HCStatsFCSErrors	The number of frames received that did not pass the FCS check. This counter is the 64-bit edition of FCS Errors.		ULINT	Reads the current value.
	HCStatsInternalMac- TransmitErrors	The number of frames that failed to be sent due to an internal MAC sublayer transmission error. This counter is the 64-bit edition of MAC Transmit Errors.		ULINT	Reads the current value.
	HCStatsFrameToo- Longs	The number of frames received that exceeded the maximum allowed frame size. This counter is the 64-bit edition of Frame Too Long.		ULINT	Reads the current value.
	HCStatsInternalMa- cReceiveErrors	The number of frames that could not be received through the interface due to an internal MAC sublayer reception error. This counter is the 64-bit edition of MAC Receive Errors.		ULINT	Reads the current value.
	HCStatsMacSymbolErrors	The number of frames that could not be received through the interface due to an internal MAC sublayer rsymbol error.		ULINT	Reads the current value.

<sup>\*1.</sup> A CPU Unit with unit version 1.13 or later is required to use this attribute.

# 1. Interface Flag Details

Bit	Name	Description
0	LinkStatus	FALSE: The link is down. TRUE: The link is up.
1	Half/FullDuplex	FALSE: Half duplex TRUE: Full duplex
2 to 4	Negotiation Status	00 hex: Auto-negotiation is in progress.
		01 hex: Auto-negotiation and speed detection failed.
		02 hex: Auto-negotiation failed, but speed detection succeeded.
		03 hex: Speed and duplex mode negotiation succeeded.
		04 hex: Auto-negotiation was not attempted.
5	Manual Setting Requires	Always FALSE: Changes can be applied automatically.
	Speed	
6	Local Hardware Fault	Always FALSE

Bit	Name	Description
7 to 31	Reserved	Always FALSE

#### 2. Control Bit Details

Bit	Name	Description
0	Auto-negotiate	FALSE: Auto-negotiation is disabled.
		TRUE: Auto-negotiation is enabled.
1	ForcedDuplex Mode	FALSE: Half duplex TRUE: Full duplex*1
2 to 16	Reserved	Always FALSE

<sup>\*1.</sup> When auto-negotiation is enabled (bit 0 is TRUE), this should always be FALSE.

# Request Paths (IOIs) to Specify Objects

When you specify an object, specify the request path (IOI) for each service code as given below.

S	Service code	Class ID	Instance ID	Attribute ID
0E hex	Get_Attribute_Single	F6 hex	Specifying a service for a class: 00	Reading a class attribute: 01
10 hex	Set_Attribute_Single		hex	to 03 hex
			Specifying a service for an in-	Reading and writing a in-
			stance: Always 01 hex	stance attribute: 01 to 06 hex,
				0C hex, and 0D hex
4C hex	Get_and_Clear			Specify an attribute to clear the
				value to 0: 04 hex, 05 hex, 0C
				hex, 0D hex

10	CIP	Message	Communications
----	-----	---------	----------------



# **SNMP** Agent


11-1 SNM	P Agent	11-2
	Overview	
	Specifications	
	SNMP Messages	
	MIB Specifications	
11-2 Proc	edure to Use the SNMP Agent	11-25
11-2-1	Procedures	11-25
11-2-2	Settings Required for the SNMP Agent	11-25

# 11-1 SNMP Agent

The SNMP (simple network management protocol) is a network management protocol.

You can use the SNMP to manage any network that consists of devices that support SNMP.

The server that manages the network is called the SNMP manager. The managed network devices are called SNMP agents.




#### 11-1-1 Overview

# **SNMP Agent**

The EtherNet/IP port has its own management information called the MIB (management information base). This information can be provided to the SNMP manager.

The SNMP manager is software that gathers and processes information about devices on the SNMP network and provides that information to the network administrator.

You can use the SNMP manager to monitor the EtherNet/IP port.



The SNMP manager has a SNMP command to request MIB information.

The EtherNet/IP port SNMP agent function supports SNMPv1 (RFC1157) and SNMPv2C (RFC1901). Use the SNMPv1 or SNMPv2C protocol to manage the EtherNet/IP port with the SNMP manager. You can also use both the SNMPv1 and SNMPv2C protocols together at the same time.


### **SNMP Traps**

When a failure or some other specific problem occurs, a status report called a trap is sent.

This enables monitoring changes in status even if the SNMP manager does not monitor the EtherNet/IP port periodically.

However, traps use UDP. Therefore, you cannot check to see if the SNMP manager receives traps from the EtherNet/IP port.

Thus, depending on the network status, some traps may not reach the SNMP manager.




# 11-1-2 Specifications

Item	Specification			
Protocol	SNMP			
Agent	SNMPv1, SNMPv2C			
MIB	MIB-II			
Port No.	SNMP agent: 161 (UDP)			
	SNMP trap: 162 (UDP)			
	These can be changed in the EtherNet/IP Port Settings from the Sysmac Studio.			
Timing of SNMP trap	Status reports are sent to the SNMP manager at the following times.			
operation	When the Controller is turned ON			
	When links are established			
	When an SNMP agent fails to be authorized			
Supported MIB com-	GetRequest/GetNextRequest			
mands				

# 11-1-3 SNMP Messages

The structure of SNMP messages is as follows:




Item	Set value			
Version	This value gives the SNMP version.			
	SNMPv1: 0			
	SNMPv2C: 1			
Community	Community name for verification			
PDU	This depends on the PDU type.			

# 11-1-4 MIB Specifications

This section describes the specifications of the MIB that is supported by the EtherNet/IP port.

# **MIB System Diagram**

The EtherNet/IP port MIB consists of the following tree structure.



# **MIB Groups**

	MIB group	Stored information		
Standard MIB	system group		The MIB for information related to the de-	
			vice.	
	interfaces group		The MIB for information related to the inter-	
			face.	
	ip group	ip	The MIB for IP information.	
		ipAddrTable	The MIB for addressing table information re-	
			lated to IP addresses.	
		ipRouteTable	The MIB for information related to IP routing	
			tables.	
		ipNetToMediaTable	The MIB for information related to IP ad-	
			dress conversion tables.	
		ipForward	The MIB for information related to IP for-	
			warding tables.	
	icmp group		The MIB for ICMP information.	
	tcp group	tcp	The MIB for TCP information.	
	udp group	udp	The MIB for UDP information.	
	snmp group	snmp	The MIB for SNMP information.	
	lldp group		The MIB for LLDP information.	

# **Detailed Descriptions of MIB Objects**

# System Group

Subtree name	Standard [(identifier) attribute]	Support	Implementation spec- ifications
sysDescr	[(1) RO] Device information (including hardware, OS, software names, and versions) ASCII characters only.	Support- ed	"OMRON Corporation" + CPU Unit model + CPU Unit version • CPU Unit model (example): NJ501-1200 • CPU Unit version (example): Version 1.0
sysObjectID	[(2) RO] Vendor OID. Tells where this device information was assigned in the private MIB.	Support- ed	1.3.6.1.4.1.16838.1.10 25.5
sysUpTime	[(3) RO] The time elapsed since the system was started (unit: 1/100 s).	Support- ed	According to the standard.
sysContact	[(4) RW] How to contact the administrator and information on the administrator.	Support- ed	Set by the user.
sysName	[(5) RW] The name for management. Sets the full domain name of the device.	Support- ed	Host Name

Subtree name	Standard [(identifier) attribute]	Support	Implementation specifications
sysLocation	[(6) RW]	Support-	Set by the user.
	The physical location of the device.	ed	
sysServices	[(7) RO]	Support-	64
	The value of the provided service.	ed	

# • Interfaces Group

	Subtree name	Standard [(identifier) attribute]	Support	Implementation specifications
ifNur	mber	[(1) RO] The number of network interfaces.	Support- ed	4
if	fTable	[(2) NA] Interface entity table		
	ifEntry	[(1) NA] Row data for interface information The index is <i>ifIndex</i> .		
	ifIndex	[(1) RO] A number used to identify the interface.	Support- ed	1 to 4
	ifDescr	[(2) RO] Information related to the interface (includes manufacturer name, product name, and hardware interface version).	Support- ed	10/100/1000M Gigabit Ethernet Port     Internal Network     Port
	ifType	[(3) RO] The type of interface classified according to the physical/link layer protocol directly under the network layer of the protocol stack.	Support- ed	ethernet-csmacd (6)
	ifMtu	[(4) RO] MTU value The maximum size (in octets) of datagrams that can be sent and received through this interface.	Support- ed	1500
	ifSpeed	[(5) RO] Estimated bandwidth If a stable, accurate value cannot be obtained for the bandwidth, a nominal value is set instead.	Support- ed	10000000/ 100000000/ 1000000000
	ifPhysAddress	[(6) RO] MAC address The physical address under the network layer of the interface.	Support- ed	The MAC address of the EtherNet/IP port
	ifAdminStatus	[(7) RW] The preferred status of the interface. You cannot send normal packets in the testing state. up (1) down (2) testing (3)	Support- ed	According to the standard.

Subtree name	Standard [(identifier) attribute]	Support	Implementation spec- ifications
ifOperStatus	[(8) RO] The current status of the interface. You cannot send normal packets in the testing state. up (1) down (2) testing (3)	Support- ed	According to the standard.
ifLastChange	[(9) RO] The sysUpTime (in 0.01 seconds) at the last change in ifOperStatus for this interface.	Support- ed	According to the standard.
ifInOctets	[(10) RO] The number of octets received through this interface. This includes framing characters.	Support- ed	According to the standard.
ifInUcastPkts	[(11) RO] The number of unicast packets reported to a higher level protocol.	Support- ed	According to the standard.
ifInNUcastPkts	[(12) RO] The number of non-unicast packets (broadcast or multicast packets) reported to a higher level protocol.	Support- ed	According to the standard.
ifInDiscards	[(13) RO] The number of packets that had no errors but could not be passed to a higher level protocol (i.e., the number of packets received but discarded due to a buffer overflow).	Support- ed	According to the standard.
ifInErrors	[(14) RO] The number of packets discarded because they contained errors.	Support- ed	According to the standard.
ifInUnknown- Protos	[(15) RO] The number of packets received, but discarded because they were of an illegal or unsupported protocol. For example, Ethernet packets did not have IP set for the field that identifies their higher level protocol.	Support- ed	According to the standard.
ifOutOctets	[(16) RO] The number of octets of packets sent through this interface. This includes framing characters.	Support- ed	According to the standard.
ifOutUcastPkts	[(17) RO] The number of unicast packets sent by higher level protocols. This includes discarded packets and unsent packets.	Support- ed	According to the standard.
ifOutNU- castPkts	[(18) RO] The number of non-unicast packets sent by higher level protocols. This includes discarded packets and unsent packets.	Support- ed	According to the standard.

Subtree name	Standard [(identifier) attribute]	Support	Implementation spec- ifications
ifOutDiscards	[(19) RO]	Support-	According to the stand-
	The number of packets that had no errors but	ed	ard.
	were discarded in the sending process (due		
	to a send buffer overflow, etc.).		
ifOutErrors	[(20) RO]	Support-	According to the stand-
	The number of packets that could not be sent	ed	ard.
	because of an error.		
ifOutQLen	[(21) RO]	Support-	Always 0.
	The size of the send packet queue (i.e., the	ed	
	number of packets).		
ifSpecific	[(22) RO]	Support-	0.0
	The object ID that represents a reference to	ed	
	the media-specific MIB for the interface.		
	For example, for Ethernet, set the object ID		
	of the MIB that defines Ethernet. If there is no		
	information, set { 0.0 }.		

# • Ip Group: Ip

Subtree name	Standard [(identifier) attribute]	Support	Implementation spec- ifications
ipForwarding	[(1) RW] Indicates if the device operates as a gateway. IP gateways can transfer datagrams, but IP hosts can perform only source routing. Some nodes take only one of these values. There- fore, if you attempt to change this object from the SNMP Manager, a badValue error is re- turned. forwarding (1) not-forwarding (2)	Support- ed	forwarding (1), not-forwarding (2) Depends on the settings in EtherNet/IP Port Settings - TCP/IP Settings - Port Forward on the Sysmac Studio.
IpDefaultTTL	[(2) RW] The default value set for the IP header TTL if no TTL value was given by the transport layer protocol.	Support- ed	64
IpInReceives	[(3) RO] The number of all IP datagrams that reached the interface, including errors.	Support- ed	According to the standard.
IpInHdrErrors	[(4) RO] The number of received datagrams that were discarded because of an IP header error (checksum error, version number error, format error, TTL error, IP option error, etc.).	Support- ed	According to the standard.
IpInAddrErrors	[(5) RO] The number of packets that were discarded because the destination address in the IP header was not valid.	Support- ed	According to the standard.

Subtree name	Standard [(identifier) attribute]	Support	Implementation spec- ifications
ipForwDatagrams	[(6) RO] The number of IP datagrams that were transferred to their final destination. If this node does not operate as an IP gateway, this is the number of datagrams that were successfully transferred through source routing.	Support- ed	According to the standard.
ipInUnknownProtos	[(7) RO] The number of IP datagrams that were received but discarded because they were of an unsupported or unrecognized protocol.	Support- ed	According to the standard.
ipInDiscards	[(8) RO] The number of IP datagrams that could have continued to be processed without any problems, but were discarded (for example, because of insufficient buffer space).	Support- ed	According to the standard.
ipInDelivers	[(9) RO] The number of datagrams delivered to an IP user protocol (any higher level protocol, including ICMP).	Support- ed	According to the standard.
ipOutRequests	[(10) RO] The number of times a send request was made for an IP datagram by a local IP user protocol (any higher level protocol, including ICMP). This counter does not include ipForw-Datagrams.	Support- ed	According to the standard.
ipOutDiscards	[(11) RO] The number of IP datagrams that could have been sent without any problems, but were discarded (for example, because of insufficient buffer space).	Support- ed	According to the standard.
ipOutNoRoutes	[(12) RO] The number of IP datagrams that were discarded because there was no transmission path. This counter includes datagrams that attempted to be sent through ipForwDatagrams, but were discarded because they were set with no-route. This value indicates the number of datagrams that could not be transferred because the default gateway was down.	Support- ed	According to the standard.
ipReasmTimeout	[(13) RO] The maximum number of seconds to wait to receive all IP datagrams for reassembly if a fragmented IP datagram is received.	Support- ed	60 s
ipReasmReqds	[(14) RO] The number of IP datagrams received that require reassembly. There is a flag in the IP header that indicates if the datagram is fragmented. You can use that flag to identify fragments.	Support- ed	According to the standard.

Subtree name	Standard [(identifier) attribute]	Support	Implementation specifications
ipReasmOKs	[(15) RO] The number of IP datagrams received that were successfully reassembled.	Support- ed	According to the standard.
ipReasmFails	[(16) RO] The number of IP datagrams received that were not successfully reassembled.	Support- ed	According to the standard.
ipFragOKs	[(17) RO] The number of IP datagrams that were successfully fragmented.	Support- ed	According to the standard.
ipFragFails	[(18) RO] The number of IP datagrams that were not successfully fragmented. (For example, because the Don't Fragment flag was set for the IP datagram.)	Support- ed	According to the standard.
ipFragCreates	[(19) RO] The number of IP datagrams created as a result of fragmentation.	Support- ed	According to the standard.
ipAddrTable	[(20) NA] An address information table for IP addresses.		
ipAddrEntry	[(1) NA] Row data of address information for IP addresses. The index is <i>ipAdEntAddr</i> .		
ipAdEntAddr	[(1) RO] The IP address.	Support- ed	According to the standard.
ipAdEntIfIndex	[(2) RO] The index value of the interface that this entry applies to. This is the same value as iflndex.	Support- ed	According to the standard.
ipAdEntNet- Mask	[(3) RO] The subnet mask for the IP address of this entry.	Support- ed	According to the standard.
ipAdEntBcas- tAddr	[(4) RO] The value of the least significant bit of the address when an IP broadcast is sent. An address represented by all 1 bits is used for broadcasting as an Internet standard. In that case, this value is always 1.	Support- ed	According to the standard.
ipAdEntReasm- MaxSize	[(5) RO] The maximum IP packet size that can be reassembled from IP fragmented input IP datagrams received through the interface.	Support- ed	According to the standard.
ipRouteTable	[(21) NA] The IP routing table for this entity.		

Subtree name	Standard [(identifier) attribute]	Support	Implementation spec- ifications
ipRouteEntry	[(1) NA] Route information for a specific destination. The index is <i>ipRouteDest</i> .		
ipRouteDest	[(1) RW] The destination IP address for this route. A value of 0.0.0.0 for this entry indicates the default route.	Support- ed	According to the standard.
ipRoutelfIndex	[(2) RW] The ID number of the interface required to send to the next destination host in this route. This ID number is the same number as ifIndex, which is used to identify the interface.	Support- ed	According to the standard.
ipRouteMetric1	[(3) RW] The primary routing metric for this route. This value is determined based on the protocol specified in ipRouteProto. Set to -1 if you do not want to use this metric (this is also the same for ipRouteMetric 2 through 4).	Support- ed	According to the standard.
ipRouteMetric2	[(4) RW] The alternative routing metric for this route.	Support- ed	According to the standard.
ipRouteMetric3	[(5) RW] The alternative routing metric for this route.	Support- ed	According to the standard.
ipRouteMetric4	[(6) RW] The alternative routing metric for this route.	Support- ed	According to the standard.
ipRouteNex- tHop	[(7) RW] The IP address of the next hop in this route (for routes connected by a broadcast or media, this is the agent address or address of that interface).	Support- ed	According to the standard.
ipRouteType	[(8) RW] The type of route. other (1): Not any of the following types. invalid (2): An invalid route. direct (3): A direct connection. indirect (4): An indirect connection (not connected to LOCAL).	Support- ed	According to the standard.

Subtree nan	ne	Standard [(identifier) attribute]	Support	Implementation spec- ifications
ipRoutePr	roto	[(9) RO] This is the routing mechanism used to determine routes. Some values correspond to gateway routing protocols, but be aware that the host may not support those protocols. other (1): Other than the following items. local (2): A route set on the local machine. netmgmt (3): A route set by network management. icmp (4): A route set by an ICMP redirect or some other ICMP function. egp (5): EGP The following are gateway protocols: ggp (6): GGP hello (7): HELLO rip (8): RIP is-is (9) es-is (10) ciscolgrp (11) bbnSpflgp (12) ospf (13): OSPF bgp (14)	Support- ed	According to the standard.
ipRouteAo	ge	[(10) RW] The elapsed time since this route was updated (in seconds).	Support- ed	Always 0.
ipRouteM	ask	[(11) RW] The subnet mask value in relation to ipRouteDest. On systems that do not support a custom subnet mask value, this value is based on the address class of the ipRouteDest field. If ipRouteDest is 0.0.0.0, this value is also 0.0.0.0.	Support- ed	According to the standard.
ipRouteM	etric5	[(12) RW] The alternative routing metric.	Support- ed	According to the standard.
ipRouteIn	fo	[(13) RO] The MIB object ID for the routing protocol used by this route. If not defined, set to {0.0}.	Support- ed	0.0
ipNetToMediaTab	ole	[(22) NA] The IP address conversion table used to map IP addresses to physical addresses.		

	Subtree name	Standard [(identifier) attribute]	Support	Implementation specifications
	ipNetToMediaEntry	[(1) NA] Row data for the conversion table. The indices are <code>ipNetToMedialfIndex</code> and <code>ipNetToMediaNetAddress</code> .		
	ipNetToMedial- fIndex	[(1) RW] The interface ID number for this entry. The value of ifIndex is used for this value.	Support- ed	According to the standard.
	ipNetToMedia- PhysAddress	[(2) RW] The media-dependent physical address.	Support- ed	According to the standard.
	ipNetToMedia- NetAddress	[(3) RW] The IP address that corresponds to the media-dependent physical address.	Support- ed	According to the standard.
	ipNetToMedia- Type	[(4) RW] The address conversion method. other (1): A method other than the following items. invalid (2): An invalid value. dynamic (3): Dynamic conversion. static (4): Static conversion.	Support- ed	According to the standard.
ipF	RoutingDiscards	[(23) RO] The number of routing entries that were valid but discarded. For example, if there was not enough buffer space because of other routing entries.	Support- ed	According to the standard.

# • Ip Group: Icmp

Name	Standard [(identifier) attribute]	Support	Implementation specifications
icmpInMsgs	[(1) RO]	Support-	According to the stand-
	The total number of received ICMP messag-	ed	ard.
	es. This includes messages counted by icm-		
	pInErrors.		
icmpInErrors	[(2) RO]	Support-	According to the stand-
	The number of received ICMP message er-	ed	ard.
	rors. (Checksum errors, frame length errors,		
	etc.)		
icmpInDestUnreachs	[(3) RO]	Support-	According to the stand-
	The number of Destination Unreachable	ed	ard.
	messages received.		
icmpInTimeExcds	[(4) RO]	Support-	According to the stand-
	The number of Time Exceed messages re-	ed	ard.
	ceived.		
icmpInParmProbs	[(5) RO]	Support-	According to the stand-
	The number of Parameter Problem messag-	ed	ard.
	es received.		
icmpInSrcQuenchs	[(6) RO]	Support-	According to the stand-
	The number of Source Quench messages re-	ed	ard.
	ceived.		
icmpInRedirects	[(7) RO]	Support-	According to the stand-
	The number of Redirect messages received.	ed	ard.

Name	Standard [(identifier) attribute]	Support	Implementation spec- ifications
icmpInEchos	[(8) RO] The number of Echo (request) messages received.	Support- ed	According to the standard.
icmpInEchoReps	[(9) RO] The number of Echo Reply messages received.	Support- ed	According to the standard.
icmpInTimestamps	[(10) RO] The number of Timestamp messages received.	Support- ed	According to the standard.
icmpInTimestampReps	[(11) RO] The number of Timestamp Reply messages received.	Support- ed	According to the standard.
icmpInAddrMasks	[(12) RO] The number of Address Mask Request messages received.	Support- ed	According to the standard.
icmpInAddrMaskReps	[(13) RO] The number of Address Mask Reply messages received.	Support- ed	According to the standard.
icmpOutMsgs	[(14) RO] The total number of ICMP messages sent. This includes messages counted by icmpOutErrors.	Support- ed	According to the standard.
icmpOutErrors	[(15) RO] The number of ICMP messages that could not be sent because of an error.	Support- ed	According to the standard.
icmpOutDestUnreachs	[(16) RO] The number of Destination Unreachable messages sent.	Support- ed	According to the standard.
icmpOutTimeExcds	[(17) RO] The number of Time Exceed messages sent.	Support- ed	According to the standard.
icmpOutParmProbs	[(18) RO] The number of Parameter Problem messages sent.	Support- ed	According to the standard.
icmpOutSrcQuenchs	[(19) RO] The number of Source Quench messages sent.	Support- ed	According to the standard.
icmpOutRedirects	[(20) RO] The number of Redirect messages sent.	Support- ed	According to the standard.
icmpOutEchos	[(21) RO] The number of Echo (request) messages sent.	Support- ed	According to the standard.
icmpOutEchoReps	[(22) RO] The number of Echo Reply messages sent.	Support- ed	According to the standard.
icmpOutTimestamps	[(23) RO] The number of Timestamp messages sent.	Support- ed	According to the standard.
icmpOutTimestam- pReps	[(24) RO] The number of Timestamp Reply messages sent.	Support- ed	According to the standard.
icmpOutAddrMasks	[(25) RO] The number of Address Mask Request messages sent.	Support- ed	According to the standard.

Name	Standard [(identifier) attribute]	Support	Implementation spec- ifications
icmpOutAddrMa-	[(26) RO]	Support-	According to the stand-
skReps	The number of Address Mask Reply messag-	ed	ard.
	es sent.		

# • Ip Group: Tcp

Name	Standard [(identifier) attribute]	Support	Implementation spec- ifications
tcpRtoAlgorithm	[(1) RO] The algorithm used to determine the timeout value for resending. other (1): Other than the following items. constant (2): A constant RTO value. rsre (3): The algorithm specified by the MIL-STD-1778 standard. vanj (4): The Van Jacobson algorithm.	Support- ed	According to the standard.
tcpRtoMin	[(2) RO] The minimum resend timeout value (in 0.01 s). This value depends on the algorithm used to determine the resend timeout value.	Support- ed	According to the standard.
tcpRtoMax	[(3) RO] The maximum resend timeout value (in 0.01 s). This value depends on the algorithm used to determine the resend timeout value.	Support- ed	According to the standard.
tcpMaxConn	[(4) RO] The total number of supported TCP connections. If the maximum number of connections is dynamic, this value is -1.	Support- ed	According to the standard.
tcpActiveOpens	[(5) RO] The number of times the TCP connection changed from the CLOSE state directly to the SYN-SENT state. (Active connection establishment.)	Support- ed	According to the standard.
tcpPassiveOpens	[(6) RO] The number of times the TCP connection changed from the LISTEN state directly to the SYN-RCVD state. (Passive connection establishment.)	Support- ed	According to the standard.
tcpAttemptFails	[(7) RO] The total number of times the TCP connection changed from the SYN-SENT or SYN-RCVD state directly to the CLOSE state and from the SYN-RCVD state directly to the LISTEN state.	Support- ed	According to the standard.
tcpEstabResets	[(8) RO] The number of times the TCP connection changed from the ESTABLISHED or the CLOSE-WAIT state directly to the CLOSE state.	Support- ed	According to the standard.

Name	Standard [(identifier) attribute]	Support	Implementation spec- ifications
tcpCurrEstab	[(9) RO] The total number of TCP connections currently in the ESTABLISHED or the CLOSE-WAIT state.	Support- ed	According to the standard.
tcpInSegs	[(10) RO] The total number of received segments. This includes the number of error segments.	Support- ed	According to the standard.
tcpOutSegs	[(11) RO] The total number of sent segments. This includes the number of segments for the current connection, but does not include the number of segments for resent data only.	Support- ed	According to the standard.
tcpRetransSegs	[(12) RO] The total number of resent segments.	Support- ed	According to the standard.
tcpConnTable	[(13) NA] The information table specific to the TCP connection.		
tcpConnEntry	[(1) NA] Entry information related to a specific TCP connection. This value is deleted if the connection changes to the CLOSE state. The indices are tcpConnLocalAddress, tcpConnLocalPort, tcpConnRemAddress, and tcpConnRemPort.		
tcpConnState	[(1) RW] The status of the TCP connection. closed (1) listen (2) synSent (3) synReceived (4) established (5) finWait1 (6) finWait2 (7) closeWait (8) lastAck (9) closing (10) timeWait (11)	Support- ed	According to the standard.
tcpConnLoca- IAddress	[(2) RO] The local IP address of this TCP connection. A value of 0.0.0.0 is used for connections in the LISTEN state that accept connections from any IP interface related to the node.	Support- ed	According to the standard.
tcpConnLocal- Port	[(3) RO] The local port number for this TCP connection.	Support- ed	According to the standard.
tcpConnRe- mAddress	[(4) RO] The remote IP address for this TCP connection.	Support- ed	According to the standard.
tcpConnRem- Port	[(5) RO] The remote port number for this TCP connection.	Support- ed	According to the standard.

Name	Standard [(identifier) attribute]	Support	Implementation spec- ifications
tcpInErrs	[(14) RO]	Support-	According to the stand-
	The total number of error segments received	ed	ard.
	(TCP checksum errors, etc.).		
tcpOutRsts	[(15) RO]	Support-	According to the stand-
	The number of segments sent with the RST	ed	ard.
	flag (the number of times the TCP connection		
	was reset).		

# • Ip Group: Udp

Name	Standard [(identifier) attribute]	Support	Implementation spec- ifications
udpInDatagrams	[(1) RO] The total number of UDP datagrams (i.e., the number of packets) sent to the UDP user.	Support- ed	According to the standard.
udpNoPorts	[(2) RO] The number of UDP datagrams that were received but did not start an application at the destination port.	Support- ed	According to the standard.
udplnErrors	[(3) RO] The number of UDP datagrams that were not sent to a higher level protocol for a reason other than udpNoPorts.	Support- ed	According to the standard.
udpOutDatagrams	[(4) RO] The total number of sent UDP datagrams.	Support- ed	According to the standard.
udpTable	[(5) NA] The information table for the UDP listener.		
udpEntry	[(1) NA] An entry related to a specific UDP listener. The indices are udpLocalAddress and udpLocalPort.		
udpLocalAd- dress	[(1) RO] The local IP address of this UDP listener. A value of 0.0.0.0 is used for UDP listeners that accept datagrams from any IP interface related to the node.	Support- ed	According to the standard.
udpLocalPort	[(2) RO] The local port number for this UDP listener.	Support- ed	According to the standard.

# • Ip Group: Snmp

Name	Standard [(identifier) attribute]	Sup- port	Implementation specifications
snmplnPkts	[(1) RO]	Sup-	According to the
	The total number of SNMP messages received.	ported	standard.
snmpOutPkts	[(2) RO]	Sup-	According to the
	The total number of SNMP messages sent.	ported	standard.
snmpInBadVersions	[(3) RO]	Sup-	According to the
	The total number of messages received of an	ported	standard.
	unsupported version.		

Name	Standard [(identifier) attribute]	Sup- port	Implementation specifications
snmpInBadCommunity- Names	[(4) RO] The total number of messages received from an unregistered community.	Sup- ported	According to the standard.
snmpInBadCommuni- tyUses	[(5) RO] The total number of messages received that specify an operation that is not allowed by that community.	Sup- ported	According to the standard.
snmpInASNParseErrs	[(6) RO] The total number of messages received that resulted in an ASN.1 error or BER error during decoding.	Sup- ported	According to the standard.
snmpInTooBigs	[(8) RO] The total number of PDUs received with an error status of tooBig.	Sup- ported	According to the standard.
snmpInNoSuchNames	[(9) RO] The total number of PDUs received with an error status of noSuchName.	Sup- ported	According to the standard.
snmpInBadValues	[(10) RO] The total number of PDUs received with an error status of badValue.	Sup- ported	According to the standard.
snmpInReadOnlys	[(11) RO] The total number of PDUs received with an error status of readOnly.	Sup- ported	According to the standard.
snmpInGenErrs	[(12) RO] The total number of PDUs received with an error status of genErr.	Sup- ported	According to the standard.
snmpInTotalReqVars	[(13) RO] The total number of MIB objects read normally after receiving GetRequest or GetNextRequest.	Sup- ported	According to the standard.
snmpInTotalSetVars	[(14) RO] The total number of MIB objects updated normally after receiving SetRequest.	Sup- ported	According to the standard.
snmpInGetRequests	[(15) RO] The total number of GetRequest PDUs received.	Sup- ported	According to the standard.
snmpInGetNexts	[(16) RO] The total number of GetNextRequest PDUs received.	Sup- ported	According to the standard.
snmpInSetRequests	[(17) RO] The total number of SetRequest PDUs received.	Sup- ported	According to the standard.
snmpInGetResponses	[(18) RO] The total number of GetResponse PDUs received.	Sup- ported	According to the standard.
snmpInTraps	[(19) RO] The total number of trap PDUs received.	Sup- ported	According to the standard.
snmpOutTooBigs	[(20) RO] The total number of PDUs sent with an error status of tooBig.	Sup- ported	According to the standard.

Name	Standard [(identifier) attribute]	Sup- port	Implementation specifications
snmpOutNoSuch-	[(21) RO]	Sup-	According to the
Names	The total number of PDUs sent with an error status of noSuchName.	ported	standard.
snmpOutBadValues	[(22) RO]	Sup-	According to the
	The total number of PDUs sent with an error status of badValue.	ported	standard.
snmpOutGenErrs	[(24) RO]	Sup-	According to the
	The total number of PDUs sent with an error status of genErr.	ported	standard.
snmpOutGetRequests	[(25) RO]	Sup-	According to the
	The total number of GetRequest PDUs sent.	ported	standard.
snmpOutGetNexts	[(26) RO]	Sup-	According to the
	The total number of GetNextRequest PDUs sent.	ported	standard.
snmpOutSetRequests	[(27) RO]	Sup-	According to the
	The total number of SetRequest PDUs sent.	ported	standard.
snmpOutGetResponses	[(28) RO]	Sup-	According to the
	The total number of GetResponse PDUs sent.	ported	standard.
snmpOutTraps	[(29) RO]	Sup-	According to the
	The total number of trap PDUs sent.	ported	standard.
snmpEnableAuthen-	[(30) RW]	Sup-	According to the
Traps	Determines if the agent generates verification	ported	standard.
	failed traps.		
	enabled (1)		
	disabled (2)		

## • Lldp Group

Name	Standard [(identifier) attribute]	Sup- port	Implementation specifications
IldpConfiguration	[(1) NA] The MIB for LLDP configuration.		
IldpMessageTxInterval	[(1) RW] The LLDP frame transmission interval. Default value: 30 (seconds)	Sup- ported	Variable value depending on setting: 5 to 32,768
IldpMessageTxHoldMultiplier	[(2) RW] The value to determine TTL of the LLDP frame, this is placed in the LLDP frame header. TTL (seconds) = IldpMessageTx-HoldMultipler × IldpMessageTxInterval However, the maximum value of TTL shall be 65,535 seconds. Default value: 4	Sup- ported	Variable value depending on setting: 1 to 100
IldpReinitDelay	[(3) RW] The time until re-initialization process is attempted when IldpPortConfigAdminStatus becomes "disabled". Default value: 2 (seconds)	Sup- ported	Always 2.

Name		Standard [(identifier) attribute]	Sup- port	Implementation specifications
IldpTxDelay		[(4) RW] The interval between successive LLDP frame transmissions. Default value: 2 (seconds)	Sup- ported	Always 2.
IldpNotificationInterval		[(5) RW] Indicates the transmission interval at which SNMP notifications are sent due to information updates from the remote system. Only one SNMP notification is sent even if multiple remote system information updates occur within the transmission interval.  Default value: 30 (seconds)	Sup- ported	Always 0.
pStatistics		[(2) NA] The MIB for LLDP statistics information.		
lldpStatsRemTablesLastChange- Time		[(1) RO] Last time when the addition/change/ deletion of neighbor information oc- curred.	Sup- ported	According to the standard.
IldpStatsRemTablesInserts		[(2) RO] Counts up when neighbor information increased.	Sup- ported	According to the standard.
IldpStatsRemTablesDeletes		[(3) RO] Counts up when neighbor information is deleted.	Sup- ported	According to the standard.
lldpStatsRemTab	lesDrops	[(4) RO] Counts up when neighbor information cannot be added due to lack of resources.	Sup- ported	According to the standard.
IldpStatsRemTablesAgeouts		[(5) RO] Counts up when the retention time expired and the neighbor information became invalid.	Sup- ported	According to the standard.
IldpStatsTxPortTable		[(6) NA] The table containing transmission frame statistics information for individual LLDP transmission ports.		
IldpStatsTxPortEntry		[(1) NA] The table entry of transmission frame statistics information for individual LLDP transmission ports.		
	IldpStatsTxPort- FramesTotal	[(2) RO] The number of LLDP frame transmissions on the LLDP transmission port.	Sup- ported	According to the standard.
IldpStatsRxPortTable		[(7) NA] The table containing reception frame statistics information for individual LLDP reception ports.		

	Name		Standard [(identifier) attribute]	Sup- port	Implementation specifications
	IIdpStatsRxPortEntry		[(1) NA] The table entry of reception frame statistics information for individual LLDP reception ports.		
		IldpStatsRx- PortFramesDis- cardedTotal	[(2) RO] The total number of discarded LLDP frames on the LLDP reception port.	Sup- ported	According to the standard.
		IldpStatsRx- PortFramesEr- rors	[(3) RO] The number of invalid LLDP frames received on the LLDP reception port.	Sup- ported	According to the standard.
		IldpStatsRx- PortFramesTo- tal	[(4) RO] The number of valid LLDP frames received on the LLDP reception port.	Sup- ported	According to the standard.
		IldpStatsRx- PortTLVsDis- cardedTotal	[(5) RO] The total number of discarded TLVs on the LLDP reception port.	Sup- ported	According to the standard.
		IldpStatsRx- PortTLVsUnre- cognizedTotal	[(6) RO] The number of TLVs received in the previous version on the LLDP reception port.	Sup- ported	According to the standard.
		IldpStatsRxPor- tAgeoutsTotal	[(7) RO] Counts up when the retention time expired and the neighbor information became invalid on the LLDP reception port.	Sup- ported	According to the standard.
lldpLc	ldpLocalSystemData		[(3) NA] The MIB for information regarding the LLDP local system.		
lld	pLocChassisId	Subtype	[(1) RO] The chassis type for the local system.	Sup- ported	macAddress(4)
lldı	IldpLocChassisId		[(2) RO] The identifier of the chassis component for the local system.	Sup- ported	Port 1 macAddress
lld	IldpLocSysName		[(3) RO] The system name for the local system.	Sup- ported	Outputs local host name. Same as sysName in the system group.
IId	IldpLocSysDesc		[(4) RO] The system information for the local system.	Sup- ported	"OMRON Corporation" + CPU Unit model + CPU Unit version • CPU Unit model (example): NX502-1300 • CPU Unit version (example): Version 1.0 Same as sysDescrin the system group.

Name	Standard [(identifier) attribute]	Sup- port	Implementation specifications
IldpLocSysCapSupported	[(5) RO] The bitmap representation of the list of functions supported by the local system.	Sup- ported	stationOnly(7)
IldpLocSysCapEnabled	[(6) RO] The bitmap representation of the list of functions running on the local system.	Sup- ported	stationOnly(7)
lldpLocPortTable	[(7) NA] The table of LLDP ports on the local system.		
IldpLocPortEntry	[(1) NA] The table entry of a LLDP port on the local system.		
IldpLocPortId- Subtype	[(2) RO] The type indicating the port ID of the local system.	Sup- ported	macAddress(3)
IldpLocPortId	[(3) RO] The port ID (string) for the local system port.	Sup- ported	Port 1: Port 1 mac- Address Port 2: Port 2 mac- Address
IldpLocPort- Desc	[(4) RO] The port information (string) for the local system port.	Sup- ported	Port 1: 10/100/1000M Gigabit Ethernet Port 1 Port 2: 10/100/1000M Gigabit Ethernet Port 2 Same as ifDescr in the interfaces group.
lldpLocManAddrTable	[(1) NA] The table of management address on the local system.		
IldpLocManAddrEntry	[(1) NA] The table entry of management address on the local system.		
IldpLocMa- nAddrLen	[(3) RO] The length of LLDP management address field transmitted from the local system.	Sup- ported	Always 5.
lldpLocManAd- drlfSubtype	[(4) RO] The type related to the numbering method for the local system interface.	Sup- ported	ifIndex(2)
lldpLocManAd- drlfld	[(5) RO] The interface number related to the local system management address.	Sup- ported	Always 2.

Name		Standard [(identifier) attribute]	Sup- port	Implementation specifications
dr	dpLocManAd- ·OID	[(6) RO] The ID that identifies the hardware component or protocol type of the local system.	Sup- ported	SNMPv2-SMI::zer- oDotZero
lldpV2RemoteSystemsData		[(4) NA] The MIB for information regarding the remote system that is connected to the LLDP local system.		
IldpRemTable		[(1) NA] The table of information from the remote system.		
IldpRemEntry		[(1) NA] The table entry of information from the remote system.		
	lpRemChassi- dSubtype	[(4) RO] The chassis type for the remote system.	Sup- ported	According to the standard.
llo sl	lpRemChassi- d	[(5) RO] The chassis ID for the remote system.	Sup- ported	According to the standard.
	dpRemPortId- ubtype	[(6) RO] The type indicating the port ID for the remote system.	Sup- ported	According to the standard.
llc	dpRemPortId	[(7) RO] The port ID for the remote system.	Sup- ported	According to the standard.
	lpRemPort- esc	[(8) RO] The description (string) to identify the port of remote system.	Sup- ported	According to the standard.
	lpRemSys- ame	[(9) RO] The system name for the remote system.	Sup- ported	According to the standard.
	dpRemSys- esc	[(10) RO] The description (string) to identify the remote system.	Sup- ported	According to the standard.
	dpRemSy- CapSupported	[(11) RO] The bitmap representation of the list of functions supported by the remote system.	Sup- ported	According to the standard.
	lpRemSysCa- Enabled	[(12) RO] The bitmap representation of the list of functions running on the remote system.	Sup- ported	According to the standard.
IldpRemManAddrTable		[(2) NA] The table of management address control on the remote system.		
IldpRemManAddrEntry		[(1) NA] The table entry of management address on the remote system.		

Name	Standard [(identifier) attribute]	Sup- port	Implementation specifications
lldpRemManAd- drlfSubtype	[(3) RO] The type related to the numbering method for the remote system interface.	Sup- ported	According to the standard.
lldpRemManAd- drlfld	[(4) RO] The interface number related to the management address of the remote system.	Sup- ported	According to the standard.
lldpRemManAd- drOID	[(5) RO] The ID indicating hardware configuration and protocols related to the management address of the remote system.	Sup- ported	According to the standard.

# 11-2 Procedure to Use the SNMP Agent

## 11-2-1 Procedures

1. Make the basic settings.

Refer to 2-2 EtherNet/IP Communications Procedures on page 2-7 for the basic operation flow.

2. Select Configurations and Setup - CPU/Expansion Racks - CPU Rack: X Bus - Unit No.: NX-EIP201 () - EtherNet/IP Port Settings on the Sysmac Studio.

Make the following settings on the **SNMP Settings** Display or the **SNMP Trap Settings** Display.

- SNMP Service
- · Recognition 1
- · Recognition 2
- 3. Select **Transfer to Controller** from the **Controller** Menu and click the **Yes** Button. The EtherNet/IP port settings are transferred to the Controller.



### **Precautions for Correct Use**

If the **Use** Option is selected for Packet Filter of the EtherNet/IP port, allow packets from the SNMP manager. If they are not permitted, communication with SNMP manager is not possible. For the details on the settings, refer to *Packet Filter* on page 7-7.

## 11-2-2 Settings Required for the SNMP Agent

Make the following EtherNet/IP Port Settings from the Sysmac Studio to use the SNMP agent.

Tab page	Setting	Setting conditions	Reference
SNMP Settings	SNMP service	Required	7-3 <b>SNMP</b>
	Port No.	Specified by user. Required to change from the default value of 161.	Settings Display on page 7-11
	Contact, location	Specified by user.	
	Send a recognition trap	Specified by user. Select this check box to send a recognition trap if there is access from an SNMP manager that is not specified (Access other than Recognition 1 and 2).	
	Recognition 1 and Recognition 2	Specified by user.  Make these settings to permit access by	Recognition 1 on page 7-12
	IP address Host name	only certain SNMP managers.	Recognition 2 on page 7-12
	Community name		

Tab page		Setting	Setting conditions	Reference
SNMP Trap Settings	SNMP trap		Required	7-4 <b>SNMP</b>
	Port N	No.	Specified by user. Required to change from the default value of 162.	Trap Settings Display on page 7-13
	Trap	1 and trap 2		Trap 1 on
		IP address	Required	page 7-13
		Host name	Set an IP address or a host name as the SNMP trap destination.	<i>Trap 2</i> on page 7-14
		Community name	Specified by user.	
		Version	Required Set the version of the SNMP manager.	



## **Additional Information**

Make the settings in the **SNMP Settings** Display and the **SNMP Trap Settings** Display if the SNMP agent is used.

Refer to 7-3 **SNMP Settings** Display on page 7-11 for information on the **SNMP Settings** Display. Refer to 7-4 **SNMP Trap Settings** Display on page 7-13 for information on the **SNMP Trap Settings** Display.



# **Communications Performance** and Communications Load

12-1 Comn	nunications System	12-2
12-1-1	Tag Data Link Communications Method	
12-1-2	Calculating the Number of Connections	
12-1-3	Packet Interval (RPI) Accuracy	
12-2 Adjus	ting the Communications Load	12-7
12-2-1	Checking Bandwidth Usage for Tag Data Links	
12-2-2	Tag Data Link Bandwidth Usage and RPI	12-9
12-2-3	Adjusting Device Bandwidth Usage	12-10
12-2-4	Changing the RPI	
12-2-5	RPI Setting Examples	
12-3 Tag D	ata Link I/O Response Time	12-23
12-3-1	Timing of Data Transmissions	
12-3-2	Maximum Tag Data Link I/O Response Time	
12-4 Mess	age Service Transmission Delay	12-27

## 12-1 Communications System

## 12-1-1 Tag Data Link Communications Method

## Requested Packet Interval (RPI) Settings

In tag data links for the EtherNet/IP port, the data transmission period is set for each connection as the RPI.

The target device sends data (i.e., output tags) based on the specified RPI, regardless of the number of nodes.

Also, the heartbeat frame is sent from the originator to the target device for each connection. The target device uses the heartbeat to check if any errors have occurred in the connection with the originator. The data transmission period of the heartbeat frame depends on the RPI settings.

#### **Heartbeat Frame Transmission Period**

- If packet interval is shorter than 100 ms, the heartbeat frame transmission period is 100 ms.
- If packet interval is equal to or larger than 100 ms, the heartbeat frame transmission period is the same as the RPI.

## Example)


In this example, two tag data link connections are set for node 2 (the originator) and node 1 (the target).

The RPI for output data 1 is set to 10 ms.

The RPI for output data 2 is set to 15 ms.

In this case, output data 1 is sent from node 1 to node 2 every 10 ms, and output data 2 is sent from node 1 to node 2 every 15 ms, as shown in the following diagram.

Also, data is sent from node 2 (the originator) to node 1 (the target) with a heartbeat of 100 ms for connection 1 and a heartbeat of 100 ms for connection 2.



## Requested Packet Interval (RPI) and Bandwidth Usage (PPS)

The number of packets transferred each second is called the used bandwidth, or PPS (packets per second).

The PPS is calculated from the RPI and heartbeat for each connection as follows:

PPS for a connection (pps)

= (1,000/RPI (ms)) + (1,000/Heartbeat transmission period (ms))

Use the following equation to calculate the total number of packets transferred by each EtherNet/IP port (Unit) in 1 second.

Total PPS for the EtherNet/IP port = Total PPS of originator connections + Total PPS of target connections (\*)

The following shows the maximum number of packets that each EtherNet/IP port can send and receive per second through tag data links (i.e., the allowed communications bandwidth per Unit). You need to consider these values when configuring connections.

• 40,000 pps

<sup>\*</sup> Connections set as target connections must be added, too.



#### **Precautions for Correct Use**

When the Unit is performing tag data link communications where the allowable communications bandwidth per Unit is close to or greater than 30,000 pps, the following functions may not be used properly. In that case, use the built-in EtherNet/IP port on the CPU Unit or an EtherNet/IP port of a different NX-series EtherNet/IP Unit.

- Connecting the Sysmac Studio online from the EtherNet/IP port of the NX-series EtherNet/IP Unit
- Connecting the Network Configurator online from the EtherNet/IP port of the NX-series Ether-Net/IP Unit
- Connecting the NA-series Programmable Terminal online from the EtherNet/IP port of the NX-series EtherNet/IP Unit
- · Port forward via the NX-series EtherNet/IP Unit
- CIP message communications
- · SNMP function


These functions of the NX-series EtherNet/IP Unit can be used via X Bus from the built-in EtherNet/IP port on the CPU Unit or an EtherNet/IP port of a different NX-series EtherNet/IP Unit.

#### Example)

Node 1 has an originator connection with the receive RPI of 500 ms, and two target connections with the send RPIs of 200 ms and 2 ms.

Node 2 has three originator connections with the receive RPIs of 200 ms, 2 ms, and 5 ms.

Node 3 has two target connections with the send RPIs of 5 ms and 1 ms.



The total PPS of each node is calculated as follows:

- · Total PPS of the Unit Node 1
  - = 1,000/200 ms + 1,000/2 ms + 1,000/500 ms (for data)
  - + 1,000/200 ms + 1,000/100 ms + 1,000/500 ms (for heartbeat)
  - = 524 pps
- Total PPS of the Unit Node 2
  - = 1,000/200 ms + 1,000/2 ms + 1,000/5 ms (for data)
  - + 1,000/200 ms + 1,000/100 ms + 1,000/100 ms (for heartbeat)
  - = 730 pps
- Total PPS of the Unit Node 3
  - = 1,000/5 ms + 1,000/500 ms (for data)
  - + 1,000/100 ms + 1,000/500 ms (for heartbeat)
  - = 214 pps

In this example, the total PPS of each Unit is below the maximum bandwidth allowed for the Unit, so data transmission can be successfully performed.

## 12-1-2 Calculating the Number of Connections

The maximum number of connections per EtherNet/IP port on a CPU Unit is as follows.

256


The maximum number of connections for a Unit should not be exceeded by the total number of originator connections, which the Unit opens, and target connections, which other nodes open to the Unit. Example)

Node 1 has two target connections with Node 2, and opens one originator connection to Node 3. So, Node 1 has three connections in total.

Node 2 opens two originator connections to Node 1, and one originator connection to Node 3. So, Node 2 has three connections in total.

Node 3 has one target connection with Node 1, and one target connection with Node 2. So, Node 3 has two connections in total.

In either case, the connections can be successfully opened since the total number of connections is below the maximum number for an EtherNet/IP port, as shown above.




If multicast is specified for data transmission and the node sends out just one multicast packet to other nodes, it requires respective connections for them.

## Example)

Node 3 sends out one multicast packet to Node 1 and Node 2. Node 3 has one target connection with Node 1, and one target connection with Node 2, requiring two connections in total.

You need to keep in mind that the number of required connections is the same, whether multicast or unitcast is specified for the communications.




## 12-1-3 Packet Interval (RPI) Accuracy

A send processing delay occurs in an EtherNet/IP port when data packets are sent based on a packet interval (RPI).

This delay varies within the RPI error margin as shown below, so the send processing may be delayed for the maximum value for each RPI.

Packet interval (RPI)	RPI error margin (±) (%)
1.0 to 1,000 ms	15 - (RPI [ms]/100)
1,000 to 10,000 ms	5% of the RPI



# 12-2 Adjusting the Communications Load

In an Ethernet network using an Ethernet switch, the network bandwidth is not shared by all of the nodes; independent transmission paths are established between individual nodes through the Ethernet switch.

A dedicated communications buffer is established in the Ethernet switch for communications between the nodes, and full-duplex communications (simultaneous transmission and reception) are performed asynchronously with other transmission paths. The communications load in other transmission paths does not affect communications, so packet collisions do not occur and stable, high-speed communications can be performed.

The Ethernet switch functions shown in the following table determine the performance of tag data links.

Item	Description
Buffer capacity	This is the amount of data that can be buffered when packets accumulate at the Ethernet switch.
Multicast filtering	This function transfers multicast packets to specific nodes only.
QoS function	This function performs priority control on packet transfers.

The following table shows the setting ranges of the tag data link settings that can be made for an EtherNet/IP port.

Item	Specification	NX-series EtherNet/IP Unit
Network bandwidth	Physical Ethernet baud rate	1,000 Mbps
Allowable tag data link communications bandwidth	Maximum number of tag data link packets that can be processed in 1 second (pps: packets per second)	40,000 pps max. (40,000 pps total for two ports)*1
Connection resources	Number of connections that can be established	256 max. (total of 512 with two ports)
Packet interval (RPI: Requested Packet Interval)	Refresh period for tag data	1.0 to 10,000 ms in 1.0-ms increments

- \*1. When the Unit is performing tag data link communications where the allowable communications bandwidth per Unit is close to or greater than 30,000 pps, the following functions may not be used properly. In that case, use the built-in EtherNet/IP port on the CPU Unit or an EtherNet/IP port of a different NX-series EtherNet/IP Unit.
  - Connecting the Sysmac Studio online from the EtherNet/IP port of the NX-series EtherNet/IP Unit
  - · Connecting the Network Configurator online from the EtherNet/IP port of the NX-series EtherNet/IP Unit
  - Connecting the NA-series Programmable Terminal online from the EtherNet/IP port of the NX-series EtherNet/IP Unit
  - · Port forward via the NX-series EtherNet/IP Unit
  - CIP message communications
  - SNMP function

These functions of the NX-series EtherNet/IP Unit can be used via X Bus from the built-in EtherNet/IP port on the CPU Unit or an EtherNet/IP port of a different NX-series EtherNet/IP Unit.

When the tag data link settings exceed the capabilities of the Ethernet switch to be used, increase the packet interval (RPI) value for adjustment.

Particularly when you configure the settings with an Ethernet switch that does not support multicast filtering, you need to consider that multicast packets will be sent to all the nodes on the network without setting the connections.



#### **Additional Information**

If you select **Multi-cast Connection** for the connection type in the connection settings on the Network Configurator, multicast packets are used. If the connection type is set to a **Point to Point Connection**, multicast packets are not used.


If required tag data link performance cannot be achieved with the Ethernet switch, re-evaluate the overall network configuration and take necessary measures such as selecting a different Ethernet switch or splitting the network.

The following sections show how to check the device bandwidth used by the tag data links in the designed network, and how to set appropriate values.

## 12-2-1 Checking Bandwidth Usage for Tag Data Links

The Network Configurator can display the bandwidth to be actually used for tag data links at each EtherNet/IP port, based on the connections set in the network configuration.

The device bandwidth used for tag data links can be checked by clicking the **Detail** Button in the **Usage of Device Bandwidth** Area at the bottom of the Network Configuration Window.



Item	Description	
#	The IP address of the device.	
Comment	A description of the device. The comment is displayed below the device icon.	
	The model number of the device is displayed by default.	
Usage of Capacity (without	The usage rate of allowable tag data link bandwidth for the device is given.	
Multicast Filter)	Bandwidth used/Allowable tag data link bandwidth	
	The values outside parentheses are for when multicast filtering is used.	
	The values inside parentheses are for when multicast filtering is not used.	
Mbit/s (without Multicast Fil-	The network bandwidth used by the device for tag data link communications is	
ter)	given.	
	The values outside parentheses are for when multicast filtering is used.	
	The values inside parentheses are for when multicast filtering is not used.	
Usage of IP multicast ad-	The number of multicast IP addresses actually used by the device for commu-	
dresses	nications is given.	
Total usage of IP multicast ad-	The number of multicast IP addresses used in the entire network is given. This	
dresses	value is used to estimate the number of multicast filters required for a switch.	

Item	Description
Network Total of Max. Mbit/s	The total bandwidth used for tag data link communications in the entire network
	is given.
	Tag data links will not normally operate if the bandwidth allowed for the network
	is exceeded.

## Checking the Usage of Capacity and Network Bandwidth for Tag Data Links

The usage rate of allowable tag data link bandwidth for each EtherNet/IP port is given in the **Usage** of Capacity (without Multicast Filter) column, and the network bandwidth usage for tag data link communications is given in the Mbit/s (without Multicast Filter) column.

The usage rate and the network bandwidth usage of tag data link communications for which multicast filtering is not supported by the Ethernet switch are given in parentheses in each corresponding column. These values include bandwidth usage for multicast packets since they are sent to all the nodes without connection settings.

These values can be adjusted as described in 12-2-4 Changing the RPI on page 12-11.

## Checking the Total Number of Multicast IP Addresses in the Network

When using an Ethernet switch that supports multicast filtering, there must be sufficient multicast filters for the network. Based on the setting of connections, the Network Configurator indicates the number of multicast IP addresses to be used in the entire network.

Make sure that the number of multicast IP addresses to be used in the entire network does not exceed the number of multicast filters supported by the Ethernet switch. If necessary, replace the Ethernet switch with another one with sufficient multicast filters, or adjust the usage rate and network bandwidth usage with the values given for an Ethernet switch without multicast filtering (i.e., the values in parentheses). These values can be adjusted as described in 12-2-4 Changing the RPI on page 12-11.

## Checking the Total Maximum Network Bandwidth

The Network Configurator displays the total maximum bandwidth to be used for the entire network. This value indicates the maximum possible bandwidth for a transmission path which connects Ethernet switches in cascade. If this value exceeds the bandwidth for each cascade connection in the actual network (1,000 Mbps), the bandwidth for some transmission paths may be exceeded depending on the network wiring, and the tag data links may not operate normally.

If this occurs, calculate the bandwidth usage of each transmission path and make sure that the bandwidth for any cascade connection is not exceeded, or adjust the bandwidth to ensure that the value of **Network Total of Max. Mbit/s** does not exceed the bandwidth for any cascade connection. These values can be adjusted as described in *12-2-4 Changing the RPI* on page 12-11.

## 12-2-2 Tag Data Link Bandwidth Usage and RPI

The usage rate of allowable tag data link bandwidth as given in the **Usage of Capacity (without Multicast Filter)** column can be adjusted by changing the packet interval (RPI) setting. If the RPI is set shorter, the **Usage of Capacity (without Multicast Filter)** will increase. If the RPI is set longer, the **Usage of Capacity (without Multicast Filter)** will decrease.

The RPI can be set in one of the following ways.

· Setting the same PRI for all the connections

- Setting a PRI for connections of a particular device
- · Setting a PRI for a particular connection

When the same RPI is set for all the connections, the **Usage of Capacity (without Multicast Filter)** will basically increase proportionally as the RPI is set shorter.

Example: If the **Usage of Capacity (without Multicast Filter)** is 40% with the PRI set to 50 ms for all the connections, the **Usage of Capacity (without Multicast Filter)** may increase to 80% when the RPI is changed to 25 ms for all the connections.



#### **Precautions for Correct Use**

If the **Usage of Capacity (without Multicast Filter)** is between 80% and 100%, some operation with the Network Configuator which may cause load on the network, such as monitoring, or message communications with some user application may temporarily cause excessive load on the network and result in timeouts. If timeouts occur, increase one or all of the RPI values and reduce the usage of capacity.

## 12-2-3 Adjusting Device Bandwidth Usage

This section provides methods for adjusting the device bandwidth usage for tag data links.



#### **Precautions for Correct Use**

The Ethernet switch should be able to support the maximum network bandwidth for each CPU Unit. The maximum network bandwidth is as follows.

1,000 Mbit/s

## **Ethernet Switches without Multicast Filtering**

• Is the **Mbit/s (without Multicast Filter)** value for each node below the maximum network bandwidth?

If any node exceeds the maximum network bandwidth, change the connection settings, such as the RPI.

- Is the value of **Usage of Capacity (without Multicast Filter)** for each node below 100%? If any node exceeds 100%, change the connections settings, such as the RPI.
- Is the value of **Network Total of Max. Mbit/s** below the maximum network bandwidth?

  If the value exceeds the maximum network bandwidth, the bandwidth for some transmission paths (e.g., an Ethernet switch or media converter) may be exceeded depending on the network wiring (e.g., cascade connection of Ethernet switches), and the tag data links may not operate normally. Check if the bandwidth of the transmission path in each cascade connection is not exceeded. If the bandwidth is exceeded, rewire the network or increase the bandwidth between Ethernet switches (e.g., increase to 1 Gbps). If these countermeasures are not possible, change the connection settings such as the RPI settings, and adjust the bandwidth to ensure that the value of **Network Total of Max. Mbit/s** does not exceed the bandwidth for any cascade connection..

## **Ethernet Switches with Multicast Filtering**

• Is the Mbit/s value for each node below the maximum network bandwidth?

If any node exceeds the maximum network bandwidth, change the connection settings, such as the RPI.

- Is the Usage of Capacity value for each node below 100%?
   If any node exceeds the maximum network bandwidth, change the connection settings, such as the RPI.
- Is the Network Total of Max. Mbit/s value below the maximum network bandwidth?

  If the value exceeds the maximum network bandwidth, the bandwidth for some transmission paths (e.g., an Ethernet switch or media converter) may be exceeded due to the network wiring (e.g., cascade connection of Ethernet switches), and the tag data links may not operate normally. Check if the bandwidth of the transmission path in each cascade connection is not exceeded. If the bandwidth is exceeded, rewire the network or increase the bandwidth between Ethernet switches (e.g., to 1 Gbps). If these countermeasures are not possible, change the connection settings such as the RPI settings, and adjust the bandwidth to ensure that the value of Network Total of Max. Mbit/s does not exceed the bandwidth for any cascade connection.
- Is the Mbit/s (without Multicast Filter) value for each node below the maximum network bandwidth? Or, is the value of Usage of Capacity (without Multicast Filter) for each node below 100%?

If any node exceeds either of them, check whether the multicast filtering on the relevant Ethernet switch is functioning correctly. If the number of multicast filters on the Ethernet switch is less than the number of **Total usage of IP multicast addresses**, the bandwidth for some transmission paths may be exceeded depending on the network wiring (e.g., cascade connection of Ethernet switches), and the tag data links may not operate normally. Calculate the number of multicast filters required for each Ethernet switch on the network, and check if the resulting number is below the number of multicast filters provided by the Ethernet switch. If the Ethernet switch does not have a sufficient number of multicast filters, replace it with another one which has sufficient multicast filters, or change the connection settings, such as the RPI settings.


## 12-2-4 Changing the RPI

You can check **Usage of Capacity (without Multicast Filter)** values offline for the usage rate of allowable tag data link bandwidth if you follow the procedure provided in *12-2-1 Checking Bandwidth Usage for Tag Data Links* on page 12-8.


You can adjust **Usage of Capacity (without Multicast Filter)** values by changing packet interval (RPI) values.

If required communications performance cannot be achieved after the adjustment, re-evaluate the network configuration.

- **1** Make required settings in the Network Configuration Window on the Network Configurator.
- 2 Click the Detail Button in the Usage of Device Bandwidth Area at the bottom of the Network Configuration Window.



The Usage of Device Bandwidth Dialog Box is displayed.



The **Usage of Capacity (without Multicast Filter)** column shows the usage rate of allowable tag data link bandwidth, and the **Mbit/s (without Multicast Filter)** column shows the network bandwidth usage.


You can adjust the Usage of Capacity (without Multicast Filter) value by changing the packet interval (RPI) for the relevant device.

There are three methods for changing the RPI as shown below.

- Method 1: Set the Same RPI for All the Connections
   You can adjust the Usage of Capacity (without Multicast Filter) value by changing the packet interval (RPI) values for all the connections at the same time.
  - Click the Set Packet Interval (RPI) Button in the Usage of Device Bandwidth Dialog Box.



2) The **Set Packet Interval (RPI)** Dialog Box is displayed. Input a new RPI value, and click the **OK** Button.



Method 2: Change the RPI for a Specific Device


You can adjust the **Usage of Capacity (without Multicast Filter)** value by changing the RPI for all the connections of a specific device.

Note that the **Usage of Capacity (without Multicast Filter)** values for the target devices of the connections are also changed.

 Click the Set Packet Interval (RPI) Button in the Usage of Device Bandwidth Dialog Box.



2) The **Set Packet Interval (RPI)** Dialog Box is displayed. In the **Target Device** Area, clear the check boxes for devices to which this RPI setting change is not applied.




- 3) Input a new RPI value, and click the **OK** Button.
- Method 3: Change the RPI for a Specific Connection


You can adjust the **Usage of Capacity (without Multicast Filter)** value by changing the RPI for a specific connection.

Note that the **Usage of Capacity (without Multicast Filter)** value for the target device of the connection are also changed.


- 1) Click the Close Button in the Usage of Device Bandwidth Dialog Box.
- Double-click the device that is set as the originator of the connection. The Edit Device Parameters Dialog Box is displayed.



3) In the **Register Device List** Area, select the connection for which you want to change the RPI, and click the **Edit** Button.



4) The Edit Connection Dialog Box for the device is displayed. Input a new packet interval (RPI) value, and click the **OK** Button.




- 4 If the bandwidth usage rate is not set as desired even after the above operation, re-evaluate the network configuration, considering the following points. (Refer to 12-2-3 Adjusting Device Bandwidth Usage on page 12-10.)
  - · Reduce the number of nodes and connections
  - Split the network
- Check the bandwidth usage rate again.
  After you change the connection settings, click the **Detail** Button in the **Usage of Device Bandwidth** Area at the bottom of the Network Configuration Window to check the bandwidth usage as described in 12-2-1 Checking Bandwidth Usage for Tag Data Links on page 12-8.
  It is important to check the bandwidth usage particularly after you change the RPI values for individual connections, instead of setting the same RPI for all the connections.
- **6** Run user tests to verify that there are no problems with the new values.

## 12-2-5 RPI Setting Examples

The following examples explain how to calculate the packet intervals (RPIs) in the following network configuration.

## **Conditions**




#### · Connections:

Example) Seventeen NJ501-1300 Units are connected to the network.

Each device has one 100-word tag for sending and sixteen 100-word tags for receiving, and exchanges data with each other.


The packet interval (RPI) for all the connections is set to 120 ms.

The IP addresses of the devices range from 192.168.250.1 to 192.168.250.17.



## **Checking the Device Bandwidth Usage**

When you click the **Detail** Button in the Usage of Device Bandwidth Area, the window shows that the usage rate of the tag data link bandwidth for each device is 40.83%, as given in the Usage of Capacity column in the following window.




## **Changing Settings**

## Method 1: Setting the Same RPI for All the Connections


In the previous example, the usage rate of allowable tag data link bandwidth is 40.83% for all the devices as given in the Usage of Capacity column, and the RPI is set to 120 ms for all the connections. In the next example, change the RPI to 40 ms so as to increase the usage rate of allowable tag data link bandwidth up to 80% or less.

Click the **Set Packet Interval (RPI)** Button in the **Usage of Device Bandwidth** Dialog Box to display the **Set Packet Interval (RPI)** Dialog Box.

Input 40 ms as the new RPI value, and click the **OK** Button.




If you set the same packet interval (RPI) for all the connections, the table shows that the usage rate of allowable tag data link bandwidth is 74.50% for all the device as shown in the Usage of Capacity column, and this indicates that the shortest packet interval is 40 ms.



Method 2: Changing the Packet Intervals (RPIs) of Specific Devices


In this example, set faster tag data links for specific two devices: 192.168.250.1 and 192.168.250.10. Click the **Set Packet Interval (RPI)** Button in the **Usage of Device Bandwidth** Dialog Box to display the **Set Packet Interval (RPI)** Dialog Box.

In the **Target Device** Area, clear the check boxes for devices to which this RPI change is not applied (all the devices except 192.168.250.1 and 192.168.250.10). Input 30 ms as the new RPI value, and click the **OK** Button.



The usage rate of allowable tag data link bandwidth for each of the two devices, 192.168.250.1 and 192.168.250.10, increases to 87.00% as shown in the Usage of Capacity column, and this indicates that the shorter RPI is set for the connections of these devices.


Note that the usage rate of allowable tag data link bandwidth for all the other devices is also increased from 40.83% to 44.50% since they are connected with the two devices, 192.168.250.1 and 192.168.250.10.




In this case, if the Ethernet switch has no multicast filter, the Usage of Capacity value would be 100.33% and communications errors might occur due to traffic overload at the EtherNet/IP port.

#### Method 3: Changing the Packet Interval (RPI) of a Specific Connection


In this example, set faster tag data links for a specific connection of a device, 192.168.250.1. Double-click the device, 192.168.250.1, in the Network Configuration Window.



Since the Register Device List shows a list of devices connected with 192.168.250.1, double-click a device, 192.168.250.10, in the list.



Input 10 ms as the new RPI value in the Edit Connection Dialog Box, and click the **OK** Button. The usage rate of allowable tag data link bandwidth for the device 192.168.250.1 increases to 50.17% as shown in the Usage of Capacity column, and this indicates that the RPI for the specific connection is set shorter.



Note that the usage rate of allowable tag data link bandwidth for the device, 192.168.250.10, is also increased from 40.83% to 51.00%.

# 12-3 Tag Data Link I/O Response Time

The following shows how to calculate the guideline for the tag data link I/O response time.

## 12-3-1 Timing of Data Transmissions

This section describes the timing of transmitting data for tag data link between an NX-series EtherNet/IP Unit and a CPU Unit.

The NX-series EtherNet/IP Unit and the CPU Unit transmit data during I/O refresh time.

Two types of tasks can be set to perform I/O refreshing, primary periodic task and priority-16 periodic task. Tasks to perform I/O refreshing of tag data links are specified for each tag set. Refer to I/O Refreshing of X Bus Function Module in the NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501) for details on the settings.

## 12-3-2 Maximum Tag Data Link I/O Response Time


The following shows how to calculate the guideline for the maximum tag data link I/O response time.



#### **Precautions for Correct Use**

The numerical values that are obtained by the calculation described here shall be used as a guideline for the maximum tag data link I/O response time. Always confirm the execution times with the physical Controller and study the designs before starting actual system operation.

You can calculate the maximum tag data link I/O response time by adding up the time of (1) to (5) in the following figure.



## 1. Input ON Response Time

The input ON response time contains the delay time for the external input device from when the input occurs until the switch actually changes to ON and the time until the input data is stored in the memory area of the CPU Unit. Refer to the input delay information of the device for input switch delay time.

One task period is required until the input data is stored in the memory area of the CPU Unit. Accordingly, the input ON response time is calculated as below.

Input ON response time = Input device delay time + Task period

### 2 Send Data Processing Time

This is the time required to transfer a variable from the CPU Unit to the EtherNet/IP port on the NX-series EtherNet/IP Unit.

The send data processing time is calculated using the task period of the task in which to perform I/O refreshing and to which the tag set is assigned in the CPU Unit that sends data. The calculation procedures is as follows.

#### Primary periodic task:

Maximum send data processing time = (the greater of the task period of the primary periodic task and the RPI of the tag set) + RPI of the tag set

#### Priority-16 periodic task

Maximum send data processing time = (the greater of the task period of the priority-16 periodic task and the RPI of the tag set)  $\times$  2 + RPI of the tag set

#### 3. Network Transmission Delay Time

The transmission delay on an Ethernet line is 50 µs or less. This delay time can be ignored.

#### 4 Receive Data Processing Time

This is the time required to transfer data that is received on the EtherNet/IP port on the NX-series EtherNet/IP Unit to a variable in the CPU Unit.

The receive data processing time is calculated using the task period of the task in which to perform I/O refreshing and to which the tag set is assigned in the CPU Unit that receives data. The calculation procedures is as follows.

#### Primary periodic task:

Maximum receive data processing time = (the greater of the task period of the primary periodic task and the RPI of the tag set ) + task period of the primary periodic task

#### Priority-16 periodic task

Maximum receive data processing time = (the greater of the task period of the priority-16 periodic task and the RPI of the tag set)  $\times$  2 + task period of the priority-16 periodic task

#### 5. Output ON Response Time

This is the delay time from when an output command is issued by the Controller until the output is executed on the external output device.

Output ON response time = Output device delay time + task period of the CPU Unit




#### **Additional Information**

The I/O response time may be longer due to noise, or other causes.




## **Precautions for Correct Use**


Set the number of tag data link connections so that it does not exceed the upper limit for the RPI shown in the figure below.



# 12-4 Message Service Transmission Delay

This section describes delay time in the service processing of a CIP communications instruction.





Processes with delay time are processed within the task period of each node as shown in the above diagram.

Delay time related to transmission lines is as below.

(Remote node task period)

## Transmission Delay

The transmission delay on an Ethernet line is 50 µs or less. This delay time can be ignored.

(Local node task period)



#### **Additional Information**

Depending on the actual operating environment, the transmission time may be longer than the one calculated with the equations given above.

The following factors can cause longer transmission time: the load rate of the network (the degree of network congestion), the window size of each network node, traffic load on the Ether-Net/IP port (e.g., simultaneous tag data link communications), and the system configuration.

CIP communications instructions are executed in the system service process.

If a timeout occurs for a CIP communications instruction, reconsider the execution time for the system service.



# Instructions Specific to NX-series EtherNet/IP Units

Commonly Used Structure Variables	13-2
TDLinkStartConnection	13-3
TDI inkStonConnection	13-8

# Commonly Used Structure Variables

The following gives the definition of structure variables commonly used in instructions specific to the NX-series EtherNet/IP Unit.

#### UnitProxy

	Variable name  Member name	Meaning Data type		Description
Į	JnitProxy	Specified Unit	_sXBU_ID	A structure that specifies the NX-series EtherNet/IP Unit to con-
				trol.
	UnitNo	Unit Number	UINT	Unit number

# **TDLinkStartConnection**

The TDLinkStartConnection instruction specifies the target node and starts the tag data link connection.

Instruction	Name	FB/FU N	Graphic expression			ST expression	
TDLinkStart-	Start Tag Da-	FB		TDLinkStartConne	ention_instance		TDLinkStartConnection_instance
Connection	ta Link Tar- get Connec-			IDEIIIKOtartooriiicctiori		(Execute, UnitProxy, PortNo. TargetNodelPAdr, Done, Busy, Error,	
	tion			Execute	Done		ErrorID);
				UnitProxy	Busy		
				PortNo	Error		
				TargetNodelPAdr	ErrorID -		

#### **Variables**

# **Input Variables**

Inpu	t variable	Meaning	Data type	Valid range	Unit	Initial val- ue	Description
Execute		Execute	BOOL	TRUE or FALSE		FALSE	TRUE: Instruction is executed.  FALSE: Instruction is not executed.
UnitF	Proxy	Specified Unit	_sXBU_ID	Depends on data type.		*1	Specifies the NX-series EtherNet/IP Unit to control.
	UnitNo	Unit Num- ber	UINT	1 to 4		0	Unit number of the NX-series EtherNet/IP Unit to access.
PortNo		Port Num- ber	USINT	1 or 2		1	Specifies the port number. 1: Port 1 2: Port 2
TargetNodel- PAdr		Target Node IP Address	ARRAY[03] OF BYTE	Depends on data type.		{0,0,0,0}	Specifies the target IP address to start the tag data link in big endian.

<sup>\*1.</sup> If you omit an initial value, a building error will occur.

# Output Variables

Output variable	Meaning	Data type	Valid range	Unit	Description
Done	Done	BOOL	TRUE or		TRUE: Normal end
			FALSE		FALSE: Error end, execution in progress, or execution condition not met.

Output variable	Meaning	Data type	Valid range	Unit	Description
Busy	Executing	BOOL	TRUE or		TRUE: Execution processing is in progress.
			FALSE		FALSE: Execution processing is not in progress.
Error	Error	BOOL	TRUE or		TRUE: Error end
			FALSE		FALSE: Normal end, execution in progress, or ex-
					ecution condition not met.
ErrorID	Error	WORD	16#0000 to		This is the error code for an error end.
	Code		16#FFFF		The value is WORD#16#0 for a normal end.

# **Related Device Variables**

Device variable	Meaning	Data type	Reference
EIP_Comm1Status.EstbTar-	CIP Communications1 Normal Target Node	ARRAY[0255]	page 6-26
getSta	Information	OF BOOL	
EIP_Comm2Status.EstbTar-	CIP Communications2 Normal Target Node	ARRAY[0255]	page 6-26
getSta	Information	OF BOOL	
EIP_Comm1Status.Target-	CIP Communications1 Target Node Error In-	ARRAY[0255]	page 6-28
NodeErr	formation	OF BOOL	
EIP_Comm2Status.Target-	CIP Communications2 Target Node Error In-	ARRAY[0255]	page 6-28
NodeErr	formation	OF BOOL	
EIP_Comm1Status.TDLin-	CIP Communications1 All Tag Data Link	BOOL	page 6-25
kAllRunSta	Communications Status		
EIP_Comm2Status.TDLin-	CIP Communications2 All Tag Data Link	BOOL	page 6-25
kAllRunSta	Communications Status		
EIP_Comm1Status.TDLink-	CIP Communications1 Tag Data Link Com-	BOOL	page 6-24
RunSta	munications Status		
EIP_Comm2Status.TDLink-	CIP Communications2 Tag Data Link Com-	BOOL	page 6-25
RunSta	munications Status		

# **Related Error Codes**

Error code	Name	Description
0400 hex	Input Value Out of Range	UnitProxy is out of range
		PortNo is out of range
5C00 hex	Cannot Execute at Specified	The EtherNet/IP port designated by the specified Unit and port number does
	Unit/Port	not exist.
		An instruction was executed when execution was not possible.
5C01 hex	Too Many Simultaneous In-	Tag data link control instructions (TDLinkStartConnection and TDLinkStop-
	struction Executions	Connection) were executed more than the number that can be executed at
		the same time.
5C03 hex	Target Node IP Address	Connection settings with the target node IP address do not exist on the
	Does Not Exist	Ethernet/IP port specified by the specified Unit and port number.
5C04 hex	Connection Communications	Communications can not be established with the target node specified by
	Error	target node IP address.
5C05 hex	Connection Setting Error	An abnormal response from the target node was received.

#### **Function**

The TDLinkStartConnection instruction starts all tag data link connections for the target specified with TargetNodelPAdr when Execute changes from FALSE to TRUE.

Busy changes to TRUE during execution and *Done* changes to TRUE after the start of all connections for the specified target. *Error* changes to TRUE if one of the specified targets cannot start the connection.

- Only one tag data link control instruction (TDLinkStartConnection and TDLinkStopConnection instructions) can be executed for each CPU Unit. Perform exclusive control processing if more than two instructions are written in the user program.
- Refer to the EIP\_Comm1Status.EstbTargetSta (CIP Communications1 Normal Target Node Information) device variable or the EIP\_Comm2Status.EstbTargetSta (CIP Communications2 Normal Target Node Information) device variable for the start and stop status of the connection.
- The settings changed by this instruction are saved in non-volatile memory and remain valid even after cycling the power supply.
- · You cannot use this instruction in the CIPSafety routing.

## **Differences When Executing This Instruction in the Simulator**

If this instruction is executed in the Simulator, when *Execute* changes from FALSE to TRUE, *Busy* changes to TRUE only in the first task period, and *Busy* changes to FALSE and *Done* changes to TRUE from the next task period.

The input parameters are discarded.

#### **Precautions for Correct Use**

- This instruction is executed over more than one task period. The execution continues even if Execute changes to FALSE once execution started.
- You cannot use this instruction in an event task. If you use this instruction in an event task, a building error will occur.

## Sample Programming

The following sample programming is given below.

• The tag data link connection is started for the IP address provided in advance when *ChangeTrigger* changes to TRUE.


# **Ladder Diagram**

#### Main Variables


Name	Data type	Initial value	Comment
TDLinkStartConnection_Instance	TDLinkStartConnection		Instance of TDLinkStartConnection instruction
ChangeTrigger	BOOL		Start condition


Name	Data type	Initial value	Comment
SettingTrigger	BOOL		Parameter setting trigger
Done	BOOL		Done
Busy	BOOL		Executing
Error	BOOL		Error
TargetNodeIPAdr	ARRAY[03] OF BYTE	{0,0,0,0}	Target node IP address

#### Algorithm









# **Structured Text (ST)**

#### Main Variables

Name	Data type	Initial value	Comment
TDLinkStartConnection_Instance	TDLinkStartConnection		Instance of TDLinkStartConnection instruction
ChangeTrigger	BOOL		Start condition
SettingTrigger	BOOL		Parameter setting trigger
Done	BOOL		Done
Busy	BOOL		Executing
Error	BOOL		Error
TargetNodelPAdr	ARRAY[03] OF BYTE	{0,0,0,0}	Target node IP address

#### Algorithm

```
(* Start condition ON check *)
         IF (ChangeTrigger = TRUE) AND (Busy = FALSE) THEN
         SettingTrigger := TRUE;
         END IF;
         (* Start condition OFF check *)
         IF (Done = TRUE) OR (Error = TRUE) THEN
         SettingTrigger := FALSE;
         END IF;
         (* Set parameters. *)
         IF SettingTrigger = TRUE THEN
         TargetNodeIPAdr[0]
         TargetNodeIPAdr[1]
                                        := 16#A8;
         TargetNodeIPAdr[2]
                                         := 16#FA;
         TargetNodeIPAdr[3]
         END_IF;
         (* Execute TDLinkStartConnection instruction. *)
         TDLinkStartConnection_Instance( Execute := SettingTrigger,
         UnitProxy
                                := UnitProxy,
         PortNo
                                 := 1,
         TargetNodeIPAdr
                                := TargetNodeIPAdr,
         Done
                 => Done,
         Busy
                  => Busy,
                 => Error);
         Error
```

# **TDLinkStopConnection**

The TDLinkStopConnection instruction specifies the target node and stops the tag data link connection.

Instruction	Name	FB/FU N	Graphic exp	pression		ST expression
TDLinkStop-	Stop Tag Da-	FB	TDLinkStopConne	ention_instance		TDLinkStopConnection_instance
Connection	ta Link Tar- get Connec-		TDLinkStopConnection		(Execute, UnitProxy, PortNo. TargetNodelPAdr, Done, Busy, Error,	
	tion		 Execute	Done		ErrorID);
			 UnitProxy	Busy		
			 PortNo	Error		
			 TargetNodelPAdr	ErrorID		

#### **Variables**

# **Input Variables**

Input variable		Meaning	Data type	Valid range	Unit	Initial val- ue	Description
Execute		Execute	BOOL	TRUE or FALSE		FALSE	TRUE: Instruction is executed.  FALSE: Instruction is not executed.
UnitF	Proxy	Specified Unit	_sXBU_ID	Depends on data type.		*1	Specifies the NX-series EtherNet/IP Unit to control.
	UnitNo	Unit Num- ber	UINT	1 to 4		0	Unit number of the NX-series EtherNet/IP Unit to access.
PortNo		Port Num- ber	USINT	1 or 2		1	Specifies the port number. 1: Port 1 2: Port 2
TargetNodel- PAdr		Target Node IP Address	ARRAY[03] OF BYTE	Depends on data type.		{0,0,0,0}	Specifies the target IP address to stop the tag data link in big endian.

<sup>\*1.</sup> If you omit an initial value, a building error will occur.

# Output Variables

Output variable	Meaning	Data type	Valid range	Unit	Description
Done	Done	BOOL	TRUE or		TRUE: Normal end
			FALSE		FALSE: Error end, execution in progress, or exe-
					cution condition not met.

Output variable	Meaning	Data type	Valid range	Unit	Description
Busy	Executing	BOOL	TRUE or FALSE		TRUE: Execution processing is in progress. FALSE: Execution processing is not in progress.
Error	Error	BOOL	TRUE or FALSE		TRUE: Error end FALSE: Normal end, execution in progress, or execution condition not met.
ErrorID	Error Code	WORD	16#0000 to 16#FFFF		This is the error code for an error end. The value is WORD#16#0 for a normal end.

# **Related Device Variables**

Device variable	Meaning	Data type	Reference
EIP_Comm1Status.EstbTar-	CIP Communications1 Normal Target Node	ARRAY[0255]	page 6-26
getSta	Information	OF BOOL	
EIP_Comm2Status.EstbTar-	CIP Communications2 Normal Target Node	ARRAY[0255]	page 6-26
getSta	Information	OF BOOL	
EIP_Comm1Status.Target-	CIP Communications1 Target Node Error In-	ARRAY[0255]	page 6-28
NodeErr	formation	OF BOOL	
EIP_Comm2Status.Target-	CIP Communications2 Target Node Error In-	ARRAY[0255]	page 6-28
NodeErr	formation	OF BOOL	
EIP_Comm1Status.TDLin-	CIP Communications1 All Tag Data Link	BOOL	page 6-25
kAllRunSta	Communications Status		
EIP_Comm2Status.TDLin-	CIP Communications2 All Tag Data Link	BOOL	page 6-25
kAllRunSta	Communications Status		
EIP_Comm1Status.TDLink-	CIP Communications1 Tag Data Link Com-	BOOL	page 6-24
RunSta	munications Status		
EIP_Comm2Status.TDLink-	CIP Communications2 Tag Data Link Com-	BOOL	page 6-25
RunSta	munications Status		

# **Related Error Codes**

Error code	Name	Description
0400 hex	Input Value Out of Range	UnitProxy is out of range
		PortNo is out of range
5C00 hex	Cannot Execute at Specified	The EtherNet/IP port designated by the specified Unit and port number does
	Unit/Port	not exist.
		An instruction was executed when execution was not possible.
5C01 hex	Too Many Simultaneous In-	Tag data link control instructions (TDLinkStartConnection and TDLinkStop-
	struction Executions	Connection) were executed more than the number that can be executed at
		the same time.
5C03 hex	Target Node IP Address	Connection settings with the target node IP address do not exist on the
	Does Not Exist	Ethernet/IP port specified by the specified Unit and port number.
5C04 hex	Connection Communications	Communications can not be established with the target node specified by
	Error	target node IP address.
5C05 hex	Connection Setting Error	An abnormal response from the target node was received.

#### **Function**

The TDLinkStopConnection instruction stops all tag data link connections for the target specified with TargetNodelPAdr when Execute changes from FALSE to TRUE.

Busy changes to TRUE during execution and *Done* changes to TRUE after all connections for the specified target stop. *Error* changes to TRUE if one of the specified targets cannot stop the connection.

- Only one tag data link control instruction (TDLinkStartConnection and TDLinkStopConnection instructions) can be executed for each CPU Unit. Perform exclusive control processing if more than two instructions are written in the user program.
- Refer to the EIP\_Comm1Status.EstbTargetSta (CIP Communications1 Normal Target Node Information) device variable or the EIP\_Comm2Status.EstbTargetSta (CIP Communications2 Normal Target Node Information) device variable for the start and stop status of the connection.
- The settings changed by this instruction are saved in non-volatile memory and remain valid even after cycling the power supply.
- · You cannot use this instruction in the CIPSafety routing.

## Differences When Executing This Instruction in the Simulator

If this instruction is executed in the Simulator, when *Execute* changes from FALSE to TRUE, *Busy* changes to TRUE only in the first task period, and *Busy* changes to FALSE and *Done* changes to TRUE from the next task period.

The input parameters are discarded.

#### **Precautions for Correct Use**

- This instruction is executed over more than one task period. The execution continues even if *Execute* changes to FALSE once execution started.
- You cannot use this instruction in an event task. If you use this instruction in an event task, a building error will occur.

## **Sample Programming**

The following sample programming is given below.

 The tag data link connection is stopped for the IP address provided in advance when ChangeTrigger changes to TRUE.


# **Ladder Diagram**


#### Main Variables


Name	Data type	Initial value	Comment
TDLinkStopConnection_Instance	TDLinkStopConnection		Instance of TDLinkStopConnection instruction
ChangeTrigger	BOOL		Start condition


Name	Data type	Initial value	Comment
SettingTrigger	BOOL		Parameter setting trigger
Done	BOOL		Done
Busy	BOOL		Executing
Error	BOOL		Error
TargetNodelPAdr	ARRAY[03] OF BYTE	{0,0,0,0}	Target node IP address

#### Algorithm









# **Structured Text (ST)**

#### Main Variables

Name	Data type	Initial value	Comment
TDLinkStopConnection_Instance	TDLinkStopConnection		Instance of TDLinkStopConnection instruction
ChangeTrigger	BOOL		Start condition
SettingTrigger	BOOL		Parameter setting trigger
Done	BOOL		Done
Busy	BOOL		Executing
Error	BOOL		Error
TargetNodeIPAdr	ARRAY[03] OF BYTE	{0,0,0,0}	Target node IP address

#### Algorithm

```
(* Start condition ON check *)
         IF (ChangeTrigger = TRUE) AND (Busy = FALSE) THEN
         SettingTrigger := TRUE;
         END IF;
         (* Start condition OFF check *)
         IF (Done = TRUE) OR (Error = TRUE) THEN
         SettingTrigger := FALSE;
         END IF;
         (* Set parameters. *)
         IF SettingTrigger = TRUE THEN
         TargetNodeIPAdr[0]
         TargetNodeIPAdr[1]
                                        := 16 # A8;
         TargetNodeIPAdr[2]
                                        := 16#FA;
         TargetNodeIPAdr[3]
         END_IF;
         (* Execute TDLinkStopConnection instruction. *)
         TDLinkStopConnection_Instance( Execute := SettingTrigger,
                                := UnitProxy,
         UnitProxy
         PortNo
                                 := 1,
         TargetNodeIPAdr
                                := TargetNodeIPAdr,
         Done
                => Done,
                 => Busy,
         Busy
                 => Error);
         Error
```



# **Troubleshooting**

This section explains how to check the errors that occur on an NX-series EtherNet/IP Unit and resolve them.

14-1	Check	ing Methods for Errors	14-2
14-2		ing with the Unit Status Indicators on the NX-series Ether- Jnit	14-3
14-3		ing with the EtherNet/IP Status Indicators on the NX-series et/IP Unit	14-5
14-4		ing with the Sysmac Studio, an HMI, and Instructions That rror Status	14-6
	14-4-1	Types of Communications Errors	14-6
	14-4-2	Source and Level of Communications Errors	14-7
	14-4-3	Error Tables	14-8
	14-4-4	Error Details	14-14
14-5	Check	ing with Device Variables	14-46
14-6	Check	ing with the Network Configurator	14-47
	14-6-1		14-47
	14-6-2		

# 14-1 Checking Methods for Errors

The following table shows the checking methods for errors that occur on an NX-series EtherNet/IP Unit and what you can check for.

Identify the errors that occur on the NX-series EtherNet/IP Unit by using these methods.

Checking method	What you can check	Reference
Checking with the Unit status indicators on the NX-series EtherNet/IP Unit	Level of current Controller error in the NX- series EtherNet/IP Unit and error state	14-2 Checking with the Unit Status Indicators on the NX-series EtherNet/IP Unit on page 14-3
Checking with the Ether- Net/IP status indicators on the NX-series Ether- Net/IP Unit	Current communications related error states in the NX-series EtherNet/IP Unit	14-3 Checking with the EtherNet/IP Status Indicators on the NX-series EtherNet/IP Unit on page 14-5
Checking with the troubleshooting function of Sysmac Studio	Current Controller errors in the NX-series EtherNet/IP Unit, a log of past errors, error sources, error causes, and corrections	14-4 Checking with the Sysmac Studio, an HMI, and Instructions That Read Error Status on page 14-6
Checking with the Troubleshooter of an HMI	Current Controller errors in the NX-series EtherNet/IP Unit, a log of past errors, error sources, error causes, and corrections	14-4 Checking with the Sysmac Studio, an HMI, and Instructions That Read Error Status on page 14-6
Checking with instructions that read error status	The highest level status and highest level event code of current Controller errors in the NX-series EtherNet/IP Unit	14-4 Checking with the Sysmac Studio, an HMI, and Instructions That Read Error Status on page 14-6
Checking with device variables	Status of current Controller errors in the X Bus Ethernet Function Module, X Bus EtherNet/IP Function Module, and X Bus Unit Common Function Module	14-5 Checking with Device Variables on page 14-46
Checking with the Net- work Configurator	Communications status of each device on the EtherNet/IP network (e.g. tag data link connection status)	14-6 Checking with the Network Configurator on page 14-47

# 14-2 Checking with the Unit Status Indicators on the NX-series EtherNet/IP Unit

You can check the operation status of the NX-series EtherNet/IP Unit by using the Unit status indicators on the NX-series EtherNet/IP Unit.

Refer to 3-2-1 Operation Status Indicators on page 3-3 for the location of the Unit status indicators. The status of Unit status indicators, operation status of an NX-series EtherNet/IP Unit, description of the operation status and correction are listed in the following table.

Indica	ators	Operation		
RUN (green)	ERR (red)	status of an NX-series EtherNet/IP Unit	Description	Correction
Lit	Not lit	Normal operation	Operating normally.	
Not lit	Not lit	Power Supply Error	The power supply to the NX-series Ether- Net/IP Unit is not turned ON.	Turn ON the power supply.
			The voltage is out of allowable power supply range.	Check the power supply system to the Controller and modify to fit within the allowable power supply range.
			The power supply part of the NX-series Ether-Net/IP Unit failed.	Replace the NX-series EtherNet/IP Unit.
		Hardware Initialization Error	A data error occurred in the firmware which is the minimum requirement to initialize the hardware of the NX-series EtherNet/IP Unit.	Cycle the power supply.  If the NX-series EtherNet/IP Unit does not start normally after cycling the power supply, replace the NX-series EtherNet/IP Unit.

Indica	itors	Operation			
RUN (green)	ERR (red)	status of an NX-series EtherNet/IP Unit	Description	Correction	
Not lit	Lit	X Bus Unit Hardware Er- ror	An error in the critical part occurred, i.e., the CPU of the NX-series EtherNet/IP Unit stopped, etc.	Cycle the power supply.  If the NX-series EtherNet/IP Unit does not start normally after cycling the power supply, replace the NX-series EtherNet/IP Unit.	
		X Bus Unit Common Function Processing Error	An error that causes all system control operations in the X Bus Unit to stop occurred.	Connect the Sysmac Studio and an HMI to the CPU Unit, refer to <i>Errors in the X Bus Unit Common Function Module</i> in the <i>NJ/NX-series Troubleshooting Manual (Cat. No. W503)</i> and troubleshoot the problem.	
		CPU Unit Error	The NX-series Ether- Net/IP Unit stopped operation due to an er- ror that occurred in the NX502 CPU Unit.	<ul> <li>If the Sysmac Studio and an HMI can be connected to the CPU Unit, refer to         <i>Troubleshooting Non-fatal Errors</i> in the         <i>NJ/NX-series Troubleshooting Manual (Cat. No. W503)</i> and troubleshoot the problem.</li> <li>If the Sysmac Studio and an HMI cannot be connected to the CPU Unit, cycle the power supply.         If the CPU Unit does not start normally after cycling the power supply, replace the CPU Unit.</li> </ul>	
Flashing status continues more than 30 seconds.	Not lit	System Initi- alization Error	A hardware failure or data error in the NX- series EtherNet/IP Unit that is not detected as a Hardware Initializa- tion Error or X Bus Unit Hardware Error occur- red.	Cycle the power supply.  If the NX-series EtherNet/IP Unit does not start normally after cycling the power supply, replace the NX-series EtherNet/IP Unit.	
Lit	Flash- ing	Errors in the X Bus Func- tion Module	An error in the X Bus Function Module oc- curred.	Refer to Errors in the X Bus Function Module in the NJ/NX-series Troubleshooting Manual (Cat. No. W503).	
		X Bus Ethe Net/IP Fund	Errors in the X Bus Ether- Net/IP Func- tion Module	An error in the X Bus EtherNet/IP Function Module occurred.	<ul> <li>14-3 Checking with the EtherNet/IP Status Indicators on the NX-series EtherNet/IP Unit on page 14-5</li> <li>14-4 Checking with the Sysmac Studio, an</li> </ul>
		Errors in the X Bus Ether- net Function Module	An error in the X Bus Ethernet Function Module occurred.	<ul> <li>HMI, and Instructions That Read Error Status on page 14-6</li> <li>14-5 Checking with Device Variables on page 14-46</li> <li>14-6 Checking with the Network Configurator on page 14-47</li> </ul>	

# 14-3 Checking with the EtherNet/IP Status Indicators on the NX-series EtherNet/IP Unit


You can check whether an error related to the communications port of the NX-series EtherNet/IP Unit occurred or not and the error state with the EtherNet/IP status indicators on the NX-series EtherNet/IP Unit.

Refer to 3-2-1 Operation Status Indicators on page 3-3 for the location of the EtherNet/IP status indicators.

The error state is checked for each communications port. The following flow diagram shows the procedure for checking the error state for a single communications port.

Refer to the *NJ/NX-series Troubleshooting Manual (Cat. No. W503)* for details on how to identify the cause of the error and resetting the error using the Sysmac Studio or an HMI.

In addition, refer to Section 6 Device Variables Related to the NX-series EtherNet/IP Unit on page 6-1 for details on device variables related to the NX-series EtherNet/IP Unit.



<sup>\*1.</sup> You can connect the Sysmac Studio or an HMI to the other port to confirm error details when Ethernet communications are possible for the other port.

# 14-4 Checking with the Sysmac Studio, an HMI, and Instructions That Read Error Status

You can check for current Controller errors in the NX-series EtherNet/IP Unit, a log of past errors, error sources, error causes, and corrections with the Sysmac Studio, HMI, and instructions that read error status.

Refer to Checking with the Troubleshooting Function of Sysmac Studio, Checking with the Troubleshooter of an HMI, and Checking with Instructions That Read Error Status in the NJ/NX-series Troubleshooting Manual (Cat. No. W503) for details on how to use each of the above.

The following describes the errors in the X Bus Ethernet Function Module and the X Bus EtherNet/IP Function Module, which are the communications errors that occur in the NX-series EtherNet/IP Unit. The definitions of the X Bus Ethernet Function Module and the X Bus EtherNet/IP Function Module are as follows.

Function module	Definition
X Bus Ethernet Func-	A function module that performs Ethernet functions of the X Bus Unit other than the
tion Module	EtherNet/IP function.
	With the NX-series EtherNet/IP Unit, a function module that performs TCP/IP or SNMP
	agent.
X Bus EtherNet/IP	A function module that performs EtherNet/IP function of the X Bus Unit.
Function Module	With the NX-series EtherNet/IP Unit, a function module that performs tag data links or
	CIP message communications.



#### **Additional Information**

The function modules related to the X Bus Unit other than the above include the X Bus Function Module and the X Bus Unit Common Function Module. The definitions of each module are given in the following table.

Function module	Definition
X Bus Function	A function module that manages the status of X Bus Unit which is connected to the
Module	X Bus of CPU Unit and also performs the processing of I/O refresh with the X Bus
	Unit, etc. as an X Bus master.
X Bus Unit Com-	A function module of the X Bus Unit that manages the X Bus Unit common informa-
mon Function	tion, i.e. total power ON time and unit version, etc., the event log of X Bus Unit, and
Module	the status, and also performs the processing of I/O refresh with the CPU Unit, etc.

Refer to *Errors in the X Bus Function Module* in the *NJ/NX-series Troubleshooting Manual (Cat. No. W503)* for details on errors in the X Bus Function Module.

Refer to *Errors in the X Bus Unit Common Function Module* in the *NJ/NX-series Troubleshooting Manual (Cat. No. W503)* for details on errors in the X Bus Unit Common Function Module.

## 14-4-1 Types of Communications Errors

The communications errors that occur in the NX-series EtherNet/IP Unit are classified by the source as follows.

Error source	Communica- tions port	Error source details	Description
X Bus Ether- net Function	Port 1	Communica- tions port 1	This is an error related to all communications using EtherNet/IP ports.
Module	Port 2	Communica- tions port 2	This includes BOOTP and DNS-related errors.
	Both ports	SNMP	This error is SNMP agent/trap related error.
X Bus Ether-	Port 1	CIP1	This is an error related to CIP communications.
Net/IP Func- tion Module	Port 2	CIP2	Other communication functions are not affected.

#### 14-4-2 Source and Level of Communications Errors

The relationship between the source and level of communications error that may occur in the NX-series EtherNet/IP Unit and examples of communications error are shown below.

For information about the meaning of error level, refer to the *NJ/NX-series Troubleshooting Manual (Cat. No. W503*).

Level	Erro	r source
Levei	X Bus Ethernet Function Module	X Bus EtherNet/IP Function Module
Major fault	None	None
Partial fault	None	None
Minor fault	<ul> <li>MAC Address Error</li> <li>Communications Controller Error</li> <li>Basic Ethernet Setting Error</li> <li>IP Address Setting Error</li> <li>IP Address Duplication Error</li> <li>BOOTP Server Connection Error</li> <li>DNS Setting Error</li> <li>IP Router Table Setting Error</li> <li>SNMP Setting Error</li> <li>Ethernet Processing Error</li> </ul>	<ul> <li>Identity Error</li> <li>Tag Data Link Setting Error</li> <li>Tag Data Link Connection Failed</li> <li>Tag Name Resolution Error</li> <li>Tag Data Link Timeout</li> <li>Tag Data Link Connection Timeout</li> <li>Allowed Communications Bandwidth per Unit Exceeded</li> <li>Number of Tag Sets for Tag Data Links Exceeded</li> </ul>
Observa- tion	Packet Discarded Due to Full Reception     Buffer     Link OFF Detected	<ul> <li>Unit Configuration Error, Combined Use of CIP Safety and Tag Data Link</li> <li>Access Detected Outside Range of Variable</li> </ul>
Informa- tion	<ul> <li>Link Detected</li> <li>IP Address Fixed</li> <li>BOOTP Client Started</li> <li>SNMP Started</li> <li>IP Address Changed</li> <li>SNMP Settings Changed</li> <li>Subnet Mask Changed</li> </ul>	<ul> <li>Tag Data Link Download Started</li> <li>Tag Data Link Download Finished</li> <li>Tag Data Link Stopped</li> <li>Tag Data Link Started</li> <li>Tag Data Link All Run</li> <li>Restarting Ethernet Port</li> </ul>

In addition, the behaviors of the NX-series EtherNet/IP Unit to the source of communications error when each level of error occurred are as shown below.

	Error source						
Level	X Bus Ethernet Function Module	X Bus EtherNet/IP Function Module					
Major fault	None	None					

	Error source	
Level	X Bus Ethernet Function Module	X Bus EtherNet/IP Function Module
Partial fault	None	None
Minor fault	<ul> <li>Ethernet communications stop (online connection with the Sysmac Studio and communication with an HMI are not possible).</li> <li>Ethernet communications partially stop (if the error is caused by communications other than connection with the Sysmac Studio or an HMI, online connection with the Sysmac Studio and communication with an HMI are possible).</li> </ul>	EtherNet/IP communications stop.     EtherNet/IP communications partially stop.
Observation	Ethernet communications continue.	EtherNet/IP communications continue.
Information	Ethernet communications continue.	EtherNet/IP communications continue.



#### **Additional Information**

For the behaviors of the X Bus Unit and the X Bus Unit Common Function Module for each level of error, refer to *Operation Related to the X Bus Unit* in the appendix of the *NJ/NX-series Troubleshooting Manual (Cat. No. W503*).

#### 14-4-3 Error Tables

This section provides tables of errors (events) that occur on the NX-series EtherNet/IP Unit. The following abbreviations and symbols are used for Level, which means the severity level of the event.

Abbreviation	Name
Min	Minor fault level
Obs	Observation
Info	Information

Symbol	Meaning
0	Event levels that are defined by the system.
8	Event levels that can be changed by the user. *1

<sup>\*1.</sup> This symbol is used only for the event whose level can be changed.

For all event codes of NJ/NX-series Controllers, refer to the *NJ/NX-series Troubleshooting Manual (Cat. No. W503*).

#### **X Bus Ethernet Function Module**

This section provides the list of errors (events) related to the X Bus Ethernet Function Module.

					L	_eve			
Event code	Event name	Meaning	Assumed cause	M a j	P rt	M i n	O b s	I n f o	Reference
04310000 hex	Communications Controller Error	A hardware error was detected in the Communications Controller of the EtherNet/IP port.	Hardware failure of Communi- cations Controller			0			page 14-16
14310000 hex	MAC Ad- dress Error	MAC address in non- volatile memory could not be read correctly.	Non-volatile memory failure			0			page 14-17
14340000 hex	Ethernet Processing Error	A fatal error was detected in the Ethernet Function Module.	Hardware failure			0			page 14-17
36010000 hex	Basic Ether- net Setting Error	An Ethernet setting error was detected.	<ul> <li>Parameter error</li> <li>Power interruption while downloading EtherNet/IP port settings</li> <li>Memory error</li> </ul>			0			page 14-18
36020000 hex	IP Address Setting Error	An IP address setting error was detected.	Parameter error Power interruption while downloading EtherNet/IP port settings The IP address obtained from the BOOTP server is invalid. Memory error			0			page 14-19
36030000 hex	IP Router Table Setting Error	An error was detected in the IP routing function settings.	Parameter error     Power interruption while downloading EtherNet/IP port settings     Memory error			0			page 14-20
36060000 hex	SNMP Set- ting Error	A setting error in SNMP agent/trap was detected.	<ul> <li>Parameter error</li> <li>Power interruption while downloading SNMP agent/trap settings</li> <li>Memory error</li> </ul>			0			page 14-21
36080000 hex	DNS Setting Error	Errors were detected in DNS setting and Hosts setting.	Parameter error     Power interruption while downloading EtherNet/IP port settings     Memory error			0			page 14-22
85D00000 hex	IP Address Duplication Error	The same IP address is used more than once.	The IP address of the Ether- Net/IP port is duplicated with the IP address of another node.			0			page 14-23
85D10000 hex	BOOTP Server Con- nection Error	Connection with the BOOTP server failed.	<ul> <li>The server is misconfigured.</li> <li>The server went down.</li> <li>An error occurred in the communications path.</li> </ul>			0			page 14-24

					L	_eve	el		
Event code	Event name	Meaning	Assumed cause	M a j	P rt	M i n	O b s	I n f o	Reference
85D40000 hex	Packet Discarded Due to Full Reception Buffer	A packet drop occurred.	Network congestion occurred.				0		page 14-25
85D50000 hex	Link OFF Detected	An Ethernet link OFF was detected.	An Ethernet cable is broken, disconnected, or loose.     The Ethernet switch's power supply is turned OFF.     Communications speed mismatched.     Noise     The identity object was reset.     Settings for EtherNet/IP were downloaded from the Network Configurator or Sysmac Studio, or the Clear All Memory operation was performed.     EtherNet/IP was restarted.				0		page 14-26
96440000 hex	Link Detect- ed	Establishment of an Ethernet link was detected.	Establishment of an Ethernet link was detected.					0	page 14-27
96470000 hex	IP Address Fixed	The correct IP address has been determined and Ethernet communications can start.	The correct IP address has been determined and Ethernet communications can start.					0	page 14-27
96480000 hex	BOOTP Cli- ent Started	The BOOTP client started requesting an IP address.	The BOOTP client started requesting an IP address.					0	page 14-28
964B0000 hex	SNMP Start- ed	The SNMP agent started normally.	The SNMP agent started nor- mally.					0	page 14-28
96500000 hex	IP Address Changed	The IP address was changed.	The IP address was changed.					0	page 14-29
96510000 hex	SNMP Set- tings Changed	The SNMP settings were changed.	The SNMP settings were changed.					0	page 14-30
96520000 hex	Subnet Mask Changed	The subnet mask setting was changed.	The subnet mask setting was changed.					0	page 14-31

# X Bus EtherNet/IP Function Module

This section provides the list of errors (events) related to the X Bus EtherNet/IP Function Module.

					ı	_eve	el		
Event code	Event name	Meaning	Assumed cause	M a j	P rt	M i n	O b s	I n f o	Reference
14210000 hex	Identity Error	The CIP identity information in non-volatile memory was not read correctly.	Non-volatile memory failure			0			page 14-32
34200000 hex	Tag Data Link Setting Error	An error was detected in the communications settings for tag data links.	Power was interrupted when a download was in progress for the tag data link settings.      Memory error			0			page 14-33
34270000 hex	Tag Name Resolution Error	Resolution of a tag used in a tag data link failed.	<ul> <li>The size of the network variable is different from the tag settings.</li> <li>The I/O direction that is set in the tag data link settings does not agree with the I/O direction of the variable in the Controller.</li> <li>There is no network variable in the Controller that corresponds to the tag settings.</li> <li>A variable in the Controller that is set for a tag data link has the Network Publish attribute set to Input but also has the Constant attribute.</li> </ul>			0			page 14-34
84070000 hex	Tag Data Link Con- nection Failed	Establishing a tag data link connection failed.	The tag data link connection information is not the same for the originator and target. Insufficient connections CIP message communications at the target node are stopped. Setting to use tag data link communications was made to the NX-series EtherNet/IP Unit that is included in the CIP Safety connection settings. The NX-series EtherNet/IP Unit with tag data link communications was added to the CIP Safety connection settings.			0			page 14-35

					L	_eve	el .		
Event code	Event name	Meaning	Assumed cause	M a j	P rt	M i n	O b s	I n f o	Reference
84080000 hex	Tag Data Link Timeout	A timeout occurred in a tag data link.	<ul> <li>The power supply to the target node is OFF.</li> <li>Communications with the target node stopped.</li> <li>The Ethernet cable connector for EtherNet/IP is disconnected.</li> <li>The Ethernet cable for EtherNet/IP is broken.</li> <li>The link to the EtherNet/IP port is OFF.</li> <li>CIP message communications at the target node are stopped.</li> <li>When the Packet Filter function is enabled in the EtherNet/IP Port Settings, packets from the target are not allowed.</li> <li>CIP communications are not allowed by the firewall function or Packet Filter function on the target node or the devices on the communication path.</li> <li>The packet loss occurred on the path due to the network communications load.</li> <li>Noise</li> </ul>			0			page 14-36
84090000 hex	Tag Data Link Con- nection Timeout	A timeout occurred while trying to establish a tag data link connection.	<ul> <li>The power supply to the target node is OFF.</li> <li>Communications with the target node stopped.</li> <li>CIP message communications stopped at the target node or the EtherNet/IP port.</li> <li>The Ethernet cable connector for EtherNet/IP is disconnected.</li> <li>The Ethernet cable for EtherNet/IP is broken.</li> <li>CIP communications are not allowed by the firewall function or Packet Filter function on the target node or the devices on the communication path.</li> <li>An error occurred in the communications path.</li> </ul>			0			page 14-38

					L	_eve	·I		
Event code	Event name	Meaning	Assumed cause	M a j	P rt	M i n	O b s	I n f o	Reference
840C0000 hex	Allowed Communica- tions Band- width per Unit Exceed- ed	The total bandwidth for the connections that are set or established for all of the EtherNet/IP ports exceeded the allowed communications bandwidth of tag data links and CIP Safety communications per Unit.	An attempt was made to establish a connection of communications bandwidth (PPS), which is the sum of the packet transmission rates of the tag data links and CIP Safety communications used for all Ether-Net/IP ports, and it exceeded the allowable communications bandwidth of the Unit.			0			page 14-39
840E0000 hex	Number of Tag Sets for Tag Data Links Ex- ceeded	The total number of tag sets for tag data links for all Ethernet/IP ports exceeds the upper limit.	The total number of tag sets for all ports that are set for tag data links in each Ethernet/IP port exceeded the maximum number the product allows.			0			page 14-40
342C0000 hex	Unit Configuration Error, Combined Use of CIP Safety and Tag Data Link	Tag data link commu- nications and CIP Safety communica- tions cannot be used together in one NX- series EtherNet/IP Unit.	Setting to use tag data link communications was made to the NX-series EtherNet/IP Unit that is included in the CIP Safety connection settings.     The NX-series EtherNet/IP Unit with tag data link communications was added to the CIP Safety connection settings.				0		page 14-41
54E00000 hex	Access Detected Outside Range of Variable	An access attempt to write a value out of range was detected for a tag variable that is used in a tag data link.	An out-of-range value was written by an EtherNet/IP tag data link to a variable with range specification. A value that does not specify an enumerator was written by an EtherNet/IP tag data link to an enumeration variable.				0		page 14-42
94010000 hex	Tag Data Link Down- load Started	Changing the tag data link settings started.	Changing the tag data link set- tings started.					0	page 14-42
94020000 hex	Tag Data Link Down- load Finish- ed	Changing the tag data link settings finished.	Changing the tag data link set- tings finished.					0	page 14-43
94030000 hex	Tag Data Link Stop- ped	Tag data links were stopped by the Network Configurator, Sysmac Studio, special instructions or manipulation of a system-defined variable. Or, the data link table was downloaded from Network Configurator or Sysmac Studio.	Tag data links were stopped by the Network Configurator, Sys- mac Studio, special instruc- tions or manipulation of a sys- tem-defined variable.					0	page 14-43

					L	eve	ı		
Event code	Event name	Meaning	Assumed cause	M a j	P rt	M i n	O b s	I n f o	Reference
94040000 hex	Tag Data Link Started	Tag data links were started by the Network Configurator, Sysmac Studio, special instructions or manipulation of a system-defined variable. Or, the data link table was downloaded from Network Configurator or Sysmac Studio.	Tag data links were started by the Network Configurator, Sys- mac Studio, special instruc- tions or manipulation of a sys- tem-defined variable.					0	page 14-44
94070000 hex	Tag Data Link All Run	Tag data link connections to all nodes have been normally established.	Tag data link connections to all target nodes have been nor- mally established.					0	page 14-45
96450000 hex	Restarting Ethernet Port	The EtherNet/IP port was restarted.	The EtherNet/IP port was restarted.					0	page 14-45

#### 14-4-4 Error Details

This section provides detailed information on errors (events) that occur on the NX-series EtherNet/IP Unit.

# **Interpreting Error Descriptions**

The items that are used to describe individual errors (events) are described in the following copy of an error table.

Event name	Gives the name	of the error.		Event code	Gives the code of	of the error.		
Meaning	Gives a short de	scription of the err	or.					
Source	Gives the source of the error.		Source details	Gives details on the source of the error.	Detection tim- ing	Tells when the error is detected.		
Error attrib- utes	Level	Tells the level of influence on control. *1	Recovery	Gives the method to return to normal state after eliminating the cause of the error.	Log category	Tells which log the error is saved in. *2		
Effects	User program	Tells what will happen to execution of the user program.	Operation	Provides special results from the	pecial information on the operation that n the error.			
Indicators	Gives the status	you can check wit	th the EtherNet/IP	port indicators.				

Device varia-	Variable	Data type	Name						
ble	Lists the variable names and data types for device variables that provide direct error notification, that are directly affected by the error, or that contain settings that cause the error.								
Cause and	Assumed cause Correction Prevention								
correction	Lists the possible causes, correction	Lists the possible causes, corrections, and preventive measures for the error.							
Attached in-	This is the attached information that is displayed by the Sysmac Studio or an HMI. *4								
formation									
Precautions/	Provides precautions, restrictions,	and supplemental information. If the	e user can set the event level, the						
Remarks	event levels that can be set, the re	covery method, operational informa	tion, and other information is also						
	provided.								
User name in	Provides the name of the user who performed the operation that generates the access log. This informa-								
the access log	tion is provided only for errors (eve	nts) for which the user name is reco	orded in the access log.						

\*1. One of the following:

Minor fault: Minor fault level

Observation Information

\*2. One of the following:

System: System event log Access: Access event log

\*3. One of the following:

Continues: Execution of the user program will continue.

Stops: Execution of the user program stops. Starts: Execution of the user program starts.

\*4. Refer to Applicable Range of the HMI Troubleshooter of the NJ/NX-series Troubleshooting Manual (Cat. No. W503) for the applicable range of the HMI Troubleshooter.

# **X** Bus Ethernet Function Module

This section provides detailed information on errors (events) related to the X Bus Ethernet Function Module.

Event name	Communications	Controller Error		Event code	04310000 hex		
Meaning	A hardware error	was detected in th	e Communications	Controller of the Et	hernet port.		
Source	X Bus Ethernet Function Module		Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and communications port 1/ communications port 2 are given in combination	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Cycle the power supply.	Log category	System	
Effects	User program	Continues.	Operation	Ethernet communications are not possible for the vant communications port.			
Indicators	Ethernet NET RU	JN	Ethernet NET EF	RR	Ethernet LINK/A	СТ	
	OFF		Lights.				
Device variable	Variable		Data type		Name		
	ETN_Port1Status	.LanHwErr	BOOL	BOOL		ations Controller	
	ETN_Port2Status	.LanHwErr	BOOL		Port2 Communications Controller Error		
Cause and cor-	Assumed cause		Correction		Prevention		
rection	Hardware failure of Communications Controller		Replace the Unit.		None		
Attached infor- mation	None						
Precautions/ Remarks		_	1Status.LanHwErr o	<del>-</del>		es TRUE, it will	

F	MAC Address 5			Frank and	44240000 5		
Event name	MAC Address Err			Event code	14310000 hex		
Meaning	MAC address in r	on-volatile memor	y could not be read	correctly.			
Source	X Bus Ethernet F	unction Module	Source details	1 to 4: Mounting	Detection tim-	At power ON or	
				position of the X	ing	Controller reset	
				Bus Unit (unit			
				<i>number)</i> and			
				communications			
				port 1/			
				communications			
				port 2 are given			
				in combination			
Error attributes	Level	Minor fault	Recovery	Cycle the power	Log category	System	
				supply.			
Effects	User program	Continues.	Operation		ications are not po	ssible for the rele-	
				vant communicati	ons port.		
Indicators	Ethernet NET RU	JN	Ethernet NET EF	RR	Ethernet LINK/ACT		
	OFF		Lights.				
Device variable	Variable		Data type		Name		
	ETN_Port1Status	.MacAdrErr	BOOL		Port1 MAC Addre	ess Error	
	ETN_Port2Status	.MacAdrErr	BOOL		Port2 MAC Addre	ess Error	
Cause and cor-	Assumed cause		Correction		Prevention		
rection	Non-volatile memory failure		Replace the Unit.		None		
Attached infor-	None						
mation							
Precautions/	Once the device	/ariable ETN_Port	1Status.MacAdrErr	or ETN_Port2Statu	s.MacAdrErr beco	mes TRUE, it will	
Remarks	not become FALS	E unless the Cont	roller power is turne	ed OFF and then O	N.		

Event name	Ethernet Process	ing Error		Event code	14340000 hex		
Meaning	A fatal error was	detected in the Eth	ernet Function Mod	lule.			
Source	X Bus Ethernet Function Module		position of the Bus Unit (unit number) and communication		communications port are given in	Detection timing	Continuously
Error attributes	Level	Minor fault	Recovery	Cycle the power supply.	Log category	System	
Effects	User program	Continues.	Operation	Ethernet communications are not possible.			
Indicators	Ethernet NET RU	JN	Ethernet NET EF	RR	Ethernet LINK/A	CT	
	OFF		Lights.				
Device variable	Variable		Data type		Name		
	None						
Cause and cor-	Assumed cause		Correction		Prevention		
rection	Hardware failure		Replace the Unit.		None		
Attached infor- mation	None						
Precautions/ Remarks	None						

Event name	Basic Ethernet Se	etting Error		Event code	36010000 hex			
Meaning	An Ethernet settir	ng error was detect	ed.					
Source	X Bus Ethernet Function Module		Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and communications port 1/ communications port 2 are given in combination	Detection timing	At power ON or Controller reset		
Error attributes	Level	Minor fault	Recovery	Automatic re- covery, cycle the power sup- ply, or Controller reset	Log category	System		
Effects	User program	Continues.	Operation	Ethernet communicati	ications are not possible for the rele- ons port.			
Indicators	Ethernet NET RU	JN	Ethernet NET EF	RR	Ethernet LINK/A	СТ		
	OFF Flashes at 1-s intervals.		ervals.					
Device variable	Variable		Data type		Name			
	ETN_Port1Status	.EtnCfgErr	BOOL	Port1 Basic Ethernet		rnet Setting Error		
	ETN_Port2Status	.EtnCfgErr	BOOL		Port2 Basic Ether	rnet Setting Error		
Cause and cor-	Assumed cause		Correction		Prevention			
rection	Parameter error	Parameter error		Identify the cause of the error from the attached information, correct the settings, and then download the settings again.				
	· ·	Power interruption while download- ing Ethernet port settings		Please clear all memory or download the settings.		Do not turn OFF the power supply to the Controller while downloading the Ethernet port settings.		
	Memory error		If the above measures do not work, replace the Unit.		None			
Attached information	Attached informat	tile Memory Access tion 2: Error Details tile memory access	;	ere is an inconsister	-			
Precautions/ Remarks	None	•						

Event name	IP Address Settin	g Error		Event code	36020000 hex			
Meaning		tting error was dete	ected.					
Source	X Bus Ethernet Function Module		Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and communications port 1/ communications port 2 are given in combination	Detection timing	At power ON or Controller reset		
Error attributes	Level	Minor fault	Recovery	Automatic re- covery (after downloading the settings), cycle the power sup- ply, or Controller reset	Log category	System		
Effects	User program	Continues.	Operation		nications are not possible for the rele-			
				vant communicat				
Indicators	Ethernet NET RU	JN	Ethernet NET ERR		Ethernet LINK/A	CT		
	OFF		Flashes at 1-s int	ervals.				
Device variable	Variable		Data type		Name			
	ETN_Port1Status.IPAdrCfgErr		BOOL		Port1 IP Address			
	ETN_Port2Status	.IPAdrCfgErr	BOOL		Port2 IP Address	Setting Error		
Cause and cor-	Assumed cause		Correction		Prevention			
rection	Parameter error		Identify the cause of the error from the attached information, correct the settings, and then download the settings again.		None			
	Power interruption ing Ethernet port		Clear all memory settings again.	or download the	Do not turn OFF the power supply to the Controller while downloading the Ethernet port settings.			
	The IP address of BOOTP server is		Correct the IP address setting provided by the BOOTP server to this port within the range specified for the NX-series Controller.		Set the IP address provided by the BOOTP server to this port within the range specified for the NX-series Controller.			
	Memory error		If the above meaning replace the Unit.	sures do not work,	None			
Attached infor-	Attached informat	tion 1: Error type						
mation	01 hex: Non-volat	tile Memory Access	Error, 02 hex: The	ere is an inconsiste	ncy in the set value	es.		
		tion 2: Error Details						
	00 hex: Non-volatile memory access error							
		nsistency in the set		40      -  -		Df		
	_		-	13 hex: Invalid defa				
Precautions/ Remarks	None							

Event name	IP Router Table S	etting Error		Event code	36030000 hex		
Meaning	An error was dete	cted in the IP routi	ng function settings	S.			
Source	X Bus Ethernet Function Module		Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and communications port are given in combination	Detection timing	At power ON or Controller reset	
Error attributes	Level	Minor fault	Recovery	Automatic re- covery (after downloading the settings), cycle the power sup- ply, or Controller reset	Log category	System	
Effects	User program	Continues.	Operation	Communications that use the relevant IP routir tings are not possible.			
Indicators	Ethernet NET RU	JN	Ethernet NET ERR		Ethernet LINK/A	СТ	
			Flashes at 1-s int	ervals.			
Device variable	Variable		Data type		Name		
	ETN_IPRTblErr		BOOL		IP Router Table Setting Error		
Cause and cor-	Assumed cause		Correction		Prevention		
rection	Parameter error		Identify the cause of the error from the attached information, correct the settings, and then download the settings again.		None		
	Power interruption	n while download-	Clear all memory	or download the	Do not turn OFF the power supply		
	ing EtherNet/IP po	ort settings	settings again.		to the Controller while downloading the EtherNet/IP port settings.		
	Memory error		If the above meas	sures do not work,	None		
Attached information	Attached information 1: Error type 01 hex: Non-volatile Memory Access Error, 02 hex: There is an inconsistency in the set values. Attached information 2: Error Details 00 hex: Non-volatile memory access error If there is an inconsistency in the set values: 11 hex: Illegal IP router table settings, 12 hex: Illegal hosts settings, 13 hex: Invalid default gateway, 14 Illegal IP Forward settings, 15 hex: Illegal NAT settings, 16 hex: Illegal Packet Filter settings, 17 hex: Ille TCP/UDP Port Transfer settings					ateway, 14 hex:	
Precautions/ Remarks	None	Ü					

Event name	SNMP Setting En	ror		Event code	36060000 hex			
Meaning	A setting error in	SNMP agent/trap w	vas detected.					
Source	X Bus Ethernet Function Module		Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and SNMP are given in combination	Detection timing	At power ON or Controller reset		
Error attributes	Level	Minor fault	Recovery	Automatic re- covery (after downloading the SNMP settings), cycle the power supply, or Con- troller reset	Log category	System		
Effects	User program	Continues.	Operation	SNMP operation	MP operation stops.			
Indicators	Ethernet NET RU	JN	Ethernet NET Ef	RR	Ethernet LINK/A	СТ		
			Flashes at 1-s int	ervals.				
Device variable	Variable		Data type	Name				
	None							
Cause and cor-	Assumed cause		Correction		Prevention			
rection	Parameter error		Identify the cause of the error from the attached information, correct the settings, and then download the settings again.		None			
	Power interruption while downloading SNMP agent/trap settings		Clear all memory or download the settings again.		Do not turn OFF the power supply to the Controller while the SNMP agent/trap settings are being down loaded.			
	Memory error		If the above measures do not work, replace the Unit.		None			
Attached information	Attached information 1: Error type 01 hex: Non-volatile Memory Access Error, 02 hex Attached information 2: Error Location If there is an inconsistency in the set values: 01 hex: SNMP agent settings, 02 hex: SNMP trap				ncy in the set value	es.		
Precautions/ Remarks	None	57.1. 30tting5, 52 no.	A. S. Will Hap South	90				

Event name	DNS Setting Erro	r		Event code	36080000 hex		
Meaning	Errors were detec	ted in DNS setting	and Hosts setting.				
Source	X Bus Ethernet Function Module		Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and communications port are given in combination	Detection timing	At power ON or Controller reset	
Error attributes	Level	Minor fault	Recovery	Automatic re- covery (after downloading the settings), cycle the power sup- ply, or Controller reset	Log category	System	
Effects	User program	Continues.	Operation	Ethernet commun	Ethernet communications are not possible.		
Indicators	Ethernet NET RUN Ethernet NET ERR		RR	Ethernet LINK/A	СТ		
	OFF		Flashes at 1-s into	ervals.			
Device variable	Variable		Data type		Name		
	ETN_DNSCfgErr		BOOL		DNS Setting Error		
Cause and cor-	Assumed cause		Correction		Prevention		
rection	Parameter error	Parameter error		Identify the cause of the error from the attached information, correct the settings, and then download the settings again.			
	Power interruption while downloading Ethernet port settings		Clear all memory or download the settings again.		Do not turn OFF the power supply to the Controller while downloading the Ethernet port settings.		
	Memory error		If the above meas replace the Unit.	sures do not work,	None		
Attached information	01 hex: Non-volat Attached informat 00 hex: Non-volat If there is an inco	Attached information 1: Error type  01 hex: Non-volatile Memory Access Error, 02 hex: There is an inconsistency in the set values.  Attached information 2: Error Details  00 hex: Non-volatile memory access error  If there is an inconsistency in the set values:  14 hex: Preferred DNS setting error, 15 hex: Alternate DNS setting error, 16 hex: Illegal domain name, 17 lillegal hosts settings					
Precautions/ Remarks	None						

Event name	IP Address Duplic	cation Error		Event code	85D00000 hex		
Meaning	The same IP address is used more than once.						
Source	X Bus Ethernet Function Module		Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and communications port 1/ communications port 2 are given in combination	Detection timing	Continuously af ter link estab- lishment	
Error attributes	Level	Minor fault	Recovery	Automatic re- covery (after downloading the IP address set- tings), cycle the power supply, or Controller reset	Log category	System	
Effects	User program	Continues.	Operation	vant communicati	nications are not possible for the rele- ions port. Packets addressed to the of the relevant communications port		
Indicators	Ethernet NET RUN		Ethernet NET ERR		Ethernet LINK/ACT		
	OFF		Flashes at 1-s intervals.				
Device variable	Variable		Data type		Name		
	ETN_Port1Status.IPAdrDupErr		BOOL		Port1 IP Address Duplication Error		
	ETN_Port2Status.IPAdrDupErr		BOOL		Port2 IP Address Duplication Error		
Cause and cor-	Assumed cause		5002				
	Assumed cause		Correction		Prevention	·	
rection		f the Ethernet port the IP address of	Perform either of rections.  Check the IP a nodes and condress settings address is not than one node Remove the ot the duplicate If the network and	addresses of other rect the IP adso that the same used by more. Ther node that has address from the cycle the othe Controller or		ns so that IP ad- on the network	
	The IP address o is duplicated with another node.	the IP address of	Perform either of rections.  Check the IP a nodes and condress settings address is not than one node. Remove the ot the duplicate If the network an power supply the reset the Control.	addresses of other rect the IP adso that the same used by more. Ther node that has address from the cycle the othe Controller or	Prevention  Perform allocation dresses of nodes are used for only	ns so that IP ad- on the network one node.	

Event name	BOOTP Server Connection Error			Event code	85D10000 hex		
Meaning	Connection with the BOOTP server failed.						
Source	X Bus Ethernet Function Module		Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and communications port 1/ communications port 2 are given in combination	Detection timing	During BOOTP operation	
Error attributes	Level	Minor fault	Recovery	Automatic re- covery	Log category	System	
Effects	User program	Continues.	Operation	vant communicat Requests to the E there is a respons freshing with the An IP address wa	nications are not possible for the rele- tions port. BOOTP server will continue until se from the BOOTP server. Data re- PLC Function Module will continue. as not set for the Ethernet port for P server attempted to set an IP ad-		
Indicators	Ethernet NET RUN		Ethernet NET El	RR	Ethernet LINK/ACT		
	OFF		Flashes at 1-s intervals.				
Device variable	Variable ETN_Port1Status.BootpErr		BOOL BOOL		Port1 BOOTP Server Error Port2 BOOTP Server Error		
Cause and cor-	ETN_Port2Status.BootpErr  Assumed cause		Correction		Prevention		
rection	The server is misconfigured.		Correct the server settings at the remote connection.		Check to make sure that the server settings at the remote connection are correct.		
	The server went down.		Check if the server at the remote connection is operating normally and set it to operate normally if it is not.		Check to make sure that the server at the remote connection is operating normally.		
	An error occurred in the communications path.		Check the communications path to the server and take corrective measures if there are any problems.		None		
Attached information	None						
Precautions/ Remarks	None						

Event name	Packet Discarded	Due to Full Rece	ntion Buffer	Event code	85D40000 hex	
			phon Bullet	Event code	00D40000 NCX	
Meaning	A packet drop occ				<b>5</b>	
Source	X Bus Ethernet F	unction Module	Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and communications port 1/ communications port 2 are given in combination	Detection timing	After link is established
Error attributes	Level	Observation	Recovery		Log category	System
Effects	User program	Continues.	Operation	Not affected.		
Indicators	Ethernet NET RU	JN	Ethernet NET El	Ethernet NET ERR		CT
Device variable	Variable		Data type		Name	
	None					
Cause and cor-	Assumed cause		Correction		Prevention	
rection	Network congesti	on occurred.	cast frames on the	ther there are no- necessary broad- ne network and re- that, check that aber of frames has	Make sure that u broadcast frames the network. Do not connect the in a loop.	•
Attached infor- mation	None					
Precautions/ Remarks	None					

Event name	Link OFF Detecte	d		Event code	85D50000 hex	
Meaning	An Ethernet link (	OFF was detected.				
Source	X Bus Ethernet F	et Function Module  Source details  1 to 4: Mounting position of the X Bus Unit (unit number) and communications port 1/ communications port 2 are given in combination		Detection timing	Continuously	
Error attributes	Level	Observation	Recovery		Log category	System
Effects	User program	Continues.	Operation	Ethernet commur	nications are not po	ssible.
Indicators	Ethernet NET RU	JN	Ethernet NET EF	RR	Ethernet LINK/A	СТ
					OFF	
Device variable	Variable		Data type		Name	
	None					
Cause and cor-	Assumed cause		Correction		Prevention	
rection	An Ethernet cable connected, or loo	,	Firmly connect the Replace the cable		Firmly connect the Ethernet cable. Also, make sure that the cable to be used is not disconnected.	
	The Ethernet swit ply is turned OFF.		Turn ON the pow Ethernet switch. Replace the Ethe fails.		Do not turn OFF switch.	the Ethernet
	Communications ed.	speed mismatch-	Please modify the the communication same as that of the	on speed is the	Set the same con speed as that on	
	Noise		Implement noise if there is excessi	countermeasures ve noise.	Implement the no ures.	ise countermeas-
	Configurator or	ject was reset. nernet were om the Network Sysmac Studio, Memory opera- med.	None. This error operations on the formed.		None. This error operations on the formed.	
Attached infor- mation	None					
Precautions/ Remarks	None					

Event name	Link Detected			Event code	96440000 hex	
Meaning	Establishment of	an Ethernet link wa	as detected.			
Source	X Bus Ethernet F	unction Module	Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and communications port 1/ communications port 2 are given in combination	Detection timing	When a link is established
Error attributes	Level	Information	Recovery		Log category	System
Effects	User program	Continues.	Operation	Not affected.		
Indicators	Ethernet NET RU	JN	Ethernet NET EF	RR	Ethernet LINK/A	СТ
					Lights.	
Device variable	Variable		Data type		Name	
	None					
Cause and cor-	Assumed cause		Correction		Prevention	
rection	Establishment of was detected.	an Ethernet link				
Attached infor- mation	None					
Precautions/ Remarks	None					

Event name	IP Address Fixed			Event code	96470000 hex	
Meaning	The correct IP ad	dress has been de	termined and Ether	net communication	s can start.	
Source	X Bus Ethernet F	unction Module	Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and communications port 1/ communications port 2 are given in combination	Detection timing	At power ON or Controller reset
Error attributes	Level	Information	Recovery		Log category	System
Effects	User program	Continues.	Operation	Not affected.		•
Indicators	Ethernet NET RU	JN	Ethernet NET EF	RR	Ethernet LINK/A	СТ
	Lights.					
Device variable	Variable		Data type		Name	
	None					
Cause and cor-	Assumed cause		Correction		Prevention	
rection	The correct IP ad	dress has been				
	determined and E	thernet commu-				
	nications can star	t.				
Attached information	Attached informa	tion 1: IP address (	example: C0A8FA0	)1 hex = address 19	92.168.250.1)	
Precautions/	None					
Remarks						

Event name	BOOTP Client St	arted		Event code	96480000 hex	
Meaning	The BOOTP clier	nt started requesting	g an IP address.			
Source	X Bus Ethernet F	unction Module	Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and communications port 1/ communications port 2 are given in combination	Detection timing	At power ON or Controller reset
Error attributes	Level	Information	Recovery		Log category	System
Effects	User program	Continues.	Operation	Not affected.		
Indicators	Ethernet NET RI	N	Ethernet NET EF	RR	Ethernet LINK/A	СТ
Device variable	Variable		Data type		Name	
	None					
Cause and cor-	Assumed cause		Correction		Prevention	
rection	The BOOTP clier ing an IP address	nt started request-				
Attached infor-	None					
mation						
Precautions/	None					
Remarks						

Event name	SNMP Started			Event code	964B0000 hex	
Meaning	The SNMP agent	started normally.			•	
Source	X Bus Ethernet F	unction Module	Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and SNMP are given in combination	Detection timing	At power ON or Controller reset
Error attributes	Level	Information	Recovery		Log category	System
Effects	User program	Continues.	Operation	Not affected.		
Indicators	Ethernet NET RU	JN	Ethernet NET ERR		Ethernet LINK/A	CT
Device variable	Variable		Data type		Name	
	None					
Cause and cor-	Assumed cause		Correction		Prevention	
rection	The SNMP agent	started normally.				
Attached infor- mation	None					
Precautions/	None					
Remarks						

_						
Event name	IP Address Chan	ged		Event code	96500000 hex	
Meaning	The IP address w	as changed.				_
Source	X Bus Ethernet F	unction Module	Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and communications port 1/ communications port 2 are given in combination	Detection timing	When down- loaded
Error attributes	Level	Information	Recovery		Log category	System
Effects	User program	Continues.	Operation	Not affected.		
Indicators	Ethernet NET RU	JN	Ethernet NET EF	R Ethernet LINK/ACT		ст
Device variable	Variable		Data type		Name	
	None					
Cause and cor-	Assumed cause		Correction		Prevention	
rection	The IP address w	as changed.				
Attached infor- mation	Attached information	tion 1: IP address a	after change, e.g. 1	92.168.250.1		
Precautions/ Remarks	None					

Event name	SNMP Settings C	hanged		Event code	96510000 hex	
Meaning	The SNMP setting	gs were changed.				
Source	X Bus Ethernet F	unction Module	Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and SNMP are given in combination	Detection timing	When down- loaded
Error attributes	Level	Information	Recovery		Log category	System
Effects	User program	Continues.	Operation	Not affected.		
Indicators	Ethernet NET RU	N	Ethernet NET ER	RR	Ethernet LINK/A	СТ
Device variable	Variable		Data type		Name	
	None					
Cause and cor-	Assumed cause		Correction		Prevention	
rection	The SNMP setting	gs were changed.				
Attached information	<ul> <li>1: SNMP service</li> <li>2: SNMP service</li> <li>3: SNMP service</li> <li>4: No change (Attached informate</li> <li>1: Recognition</li> <li>2: Recognition</li> <li>3: Recognition</li> <li>4: No change (Attached informate</li> <li>1: Recognition</li> <li>2: Recognition</li> </ul>	ce disabled ce settings change Not 1, 2, or 3) tion 2: Changes in 1 enabled 1 disabled 1 settings change Not 1, 2, or 3) tion 3: Changes in 2 enabled 2 disabled 2 settings change	d Recognition 1 d Recognition 2			
Precautions/	None	•				
Remarks						

Event name	Subnet Mask Cha	anged		Event code	96520000 hex	
				Event code	00020000 110X	
Meaning	The subnet mask			I		
Source	X Bus Ethernet F	unction Module	Source details	1 to 4: Mounting	Detection tim-	When down-
				position of the X	ing	loaded
				Bus Unit (unit		
				<i>number</i> ) and		
				communications		
				port 1/		
				communications		
				port 2 are given		
				in combination		
Error attributes	Level	Information	Recovery		Log category	System
Effects	User program	Continues.	Operation	Not affected.		
Indicators	Ethernet NET RU	JN	Ethernet NET EF	RR	Ethernet LINK/A	СТ
Device variable	Variable		Data type		Name	
	None					
Cause and cor-	Assumed cause		Correction		Prevention	
rection	The subnet mask	was changed.				
Attached infor-	Attached informa	tion 1: Subnet mas	k after change, e.g.	255.255.255.0		
mation						
Precautions/	None					
Remarks						

### X Bus EtherNet/IP Function Module

This section provides detailed information on errors (events) related to the X Bus EtherNet/IP Function Module.

Event name	Identity Error			Event code	14210000 hex	
Meaning	The CIP identity i	nformation in non-v	olatile memory wa	s not read correctly		
Source	X Bus EtherNet/IF ule	P Function Mod-	Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and CIP1/CIP2 are given in combination	Detection timing	At power ON or Controller reset
Error attributes	Level	Minor fault	Recovery	Cycle the power supply.	Log category	System
Effects	User program	Continues.	Operation	EtherNet/IP commun	nunications are not ications port.	possible for the
Indicators	EtherNet/IP NET	RUN	EtherNet/IP NET	ERR	EtherNet/IP LINK	(/ACT
			Lights.			
Device variable	Variable		Data type		Name	
	EIP_Comm1Statu	us.IdentityErr	BOOL		CIP Communicati	ons1 Identity Er-
	EIP_Comm2Statu	ıs.ldentityErr	BOOL		CIP Communicati	ons2 Identity Er-
Cause and cor-	Assumed cause		Correction		Prevention	
rection	Non-volatile mem	ory failure	Replace the CPU	Unit.	None	
Attached infor- mation	None					
Precautions/ Remarks	None					

Event name	Tag Data Link Se	tting Error		Event code	34200000 hex	
Meaning	An error was dete	ected in the commu	unications settings	for tag data links.		
Source	X Bus EtherNet/II ule	P Function Mod-	Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and CIP1/CIP2 are given in combination	Detection timing	At power ON or Controller reset
Error attributes	Level	Minor fault	Recovery	Automatic re- covery (after downloading the tag data link set- tings), cycle the power supply, or Controller reset	Log category	System
Effects	User program	Continues.	Operation	Tag data link com	munications are no	ot possible.
Indicators	EtherNet/IP NET	RUN	EtherNet/IP NET	T ERR	EtherNet/IP LINI	K/ACT
	Flashes at 1-s int	ervals.	Flashes at 1-s in	tervals.		
Device variable	Variable		Data type		Name	
	EIP_Comm1State	us.TDLinkCfgErr	BOOL		CIP Communicat	_
	EIP_Comm2State	us.TDLinkCfgErr	BOOL		CIP Communicat	•
Cause and cor-	Assumed cause		Correction		Prevention	
rection	Power was interru	upted when a	Please perform of	one of the follow-	Do not turn OFF	the power supply
	download was in	-	ing corrections.			while downloading
	tag data link settii	ngs.	Execute Clear	All Memory oper-	the tag data link	settings.
			ation.			
			Download the	tag data link set-		
			tings.			
			Clear the tag of	data link settings.		
	Memory error			sures do not work,	None	
	I		replace the CPU	Unit.		
Attached infor-	Attached informa	• •				
Attached infor- mation	l	• •	s Error, 02 hex: The	ere is an inconsiste	ncy in the set value	9S.
	l	• •	s Error, 02 hex: The	ere is an inconsiste	ncy in the set value	es.

Resolution of a tag used in a tag data link failed.   Source details   S	Event name	Tag Name Resolu	ution Error		Event code	34270000 hex	
User program   Continues.   Continues.   Continues.   Controller reset, changing variable with the Sysmac Studies from the Network Variable	Meaning			a link failed.			
Effects User program Continues. Operation The data link does not operate for the tag whose errors were not resolved. Data links for other tags operate.  EtherNet/IP NET RUN Flashes at 1-s intervals. Flashes at 1-s intervals.  Device variable EIP_Comm1Status.TagAdrErr BOL EIP_Comm2Status.TagAdrErr BOL CIP Communications 1 Tag Name Resolution Error CIP Cause and correction The size of the network variable is different from the tag settings. The I/O direction that is set in the tag data link settings does not agree with the I/O direction of the variable in the Controller.  There is no network variable in the Controller. Modify the tag settings or controller variable in the Controller that corresponds to the tag settings or the tag data link settings and the Controller variable in the Lag settings. A variable in the Controller that is set for a tag data link has the Network Publish attribute set to Input but also has the Constant attribute.  Attached information  Precautions/ None	Source		P Function Mod-	Source details	position of the X Bus Unit (unit number) and CIP1/CIP2 are given in combi-		Controller reset, changing varia- ble values from the Sysmac Stu- dio, or changing data link table from the Net- work Configura-
Indicators   EtherNet/IP NET RUN   Flashes at 1-s intervals.   Flashes at 1-s interv	Error attributes	Level	Minor fault	Recovery	covery (after downloading tag	Log category	System
Flashes at 1-s intervals.	Effects	User program	Continues.	Operation	rors were not reso	•	-
Device variable   EIP_Comm1Status.TagAdrErr   BOOL   CIP Communications1 Tag Name Resolution Error	Indicators	EtherNet/IP NET	RUN	EtherNet/IP NET	ERR	EtherNet/IP LINE	(/ACT
EIP_Comm1Status.TagAdrErr  EIP_Comm2Status.TagAdrErr  EIP_Comm2Status.TagAdrErr  EIP_Comm2Status.TagAdrErr  BOOL  CIP Communications2 Tag Name Resolution Error  Cause and correction  Assumed cause  The size of the network variable is different from the tag settings.  The I/O direction that is set in the tag data link settings does not agree with the I/O direction of the variable in the Controller.  There is no network variable in the Controller that corresponds to the tag settings.  A variable in the Controller that is set for a tag data link has the Notwork Publish attribute set to Input but also has the Constant attribute.  Attached information  Precautions/  None		Flashes at 1-s into	ervals.	Flashes at 1-s int	ervals.		
EIP_Comm2Status.TagAdrErr  EIP_Comm2Status.TagAdrErr  BOOL  Cause and correction  The size of the network variable is different from the tag settings.  The I/O direction that is set in the tag data link settings does not agree with the I/O direction of the variable in the Controller.  There is no network variable in the Controller that corresponds to the tag settings to the tag settings to specify existing network variable in the Controller that corresponds to the tag settings to specify existing network variable work Publish attribute set to Input but also has the Constant attribute.  Resolution Error  CIP Communications2 Tag Name Resolution Error  Prevention  Set the size of the tag settings to match the network variable.  Set the tag data link setting agree with the I/O direction of the tag data link setting agree with the I/O direction of the Controller variable.  Set the tag data link setting so that the I/O direction of the tag data link setting agree with the I/O direction of the Controller variable.  Set the tag settings to specify existing network variable in the tag.  Set the tag settings to specify existing network variable in the tag.  Set the tag settings to specify existing network variable in the tag.  Set the tag settings to specify existing network variable in the tag.  Set the tag settings to specify existing network variable.  Set the tag settings to specify existing network variable whose Network Publish attribute in the Controller variab	Device variable	Variable		Data type		Name	
Cause and correction  The size of the network variable is different from the tag settings.  The I/O direction that is set in the tag data link settings does not agree with the I/O direction of the variable in the Controller.  There is no network variable in the Controller that settings.  A variable in the Controller that is set for a tag data link has the Network Publish attribute set to Input.  Attached information  The size of the network variable is different from the tag settings.  Assumed cause  Correction  Modify the size of the tag settings or match the network variable.  Modify the tag settings or Controller variable so that the I/O direction of the tag data link setting agree with the I/O direction of the tag data link setting agree with the I/O direction of the tag data link setting agree with the I/O direction of the tag settings to specify existing network variable in the tag.  Resolution Error  Prevention  Set the size of the tag settings to match the network variable.  Set the tag settings or Controller variable so that the I/O direction of the tag data link setting agree with the I/O direction of the tag settings to specify existing network variable in the tag.  Remove the Constant attribute of the Controller variable whose Network Publish attribute is set to Input.  Attached information  None		EIP_Comm1Statu	us.TagAdrErr	BOOL			ions1 Tag Name
The size of the network variable is different from the tag settings.  The I/O direction that is set in the tag data link settings does not agree with the I/O direction of the variable in the Controller.  There is no network variable in the tag settings.  A variable in the Controller that corresponds to the tag settings.  A variable in the Controller that is set for a tag data link has the Network Publish attribute set to Input but also has the Constant attribute.  Attached information  The size of the tag settings to match the network variable.  Modify the size of the tag settings or controller wariable.  Modify the tag settings or Controller variable settings so that the I/O direction of the tag data link setting agree with the I/O direction of the Controller variable.  Modify the tag settings so that the I/O direction of the tag data link setting agree with the I/O direction of the Controller variable.  Set the tag to specify existing network variable in the tag.  Set the tag data link setting agree with the I/O direction of the Controller variable.  Set the tag data link setting agree with the I/O direction of the tag data link settings so that the I/O direction of the tag data link setting agree with the I/O direction of the tag data link setting agree with the I/O direction of the Controller variable.  Set the tag to specify existing network variable in the tag.  Set the tag to specify on the I/O direction of the tag data link set in the I/O direction of the tag data link set in the I/O direction of the tag data link set in the I/O direction of the tag data link set in the I/O direction of the tag data link set in the I/O direction of the tag data link set in the I/O direction of the tag data link set in the I/O direction of the tag data link set in the I/O direction of the tag data link set in the I/O direction of the tag data link set in the I/O direction of the tag data link set in the I/O direction of the tag data link set in the I/O direction of the tag data link set in the I/O direction of the tag da		EIP_Comm2Statu	us.TagAdrErr	BOOL			ions2 Tag Name
different from the tag settings.  The I/O direction that is set in the tag data link settings dead at link settings dead at link settings does not agree with the I/O direction of the variable in the Controller.  There is no network variable in the Controller that corresponds to the tag settings.  A variable in the Controller that is set for a tag data link has the Network Publish attribute set to Input but also has the Constant attribute.  Attached information  Precautions/  Modify the tag settings or Control-ler variable.  Modify the tag settings or Control-ler variable.  Modify the tag settings or Control-variable so that the I/O direction of the tag data link setting agree with the l/O direction of the tag data link set ing data link setting agree with the l/O direction of the tag data link set ing data l	Cause and cor-	Assumed cause		Correction		Prevention	
The I/O direction that is set in the tag data link settings does not agree with the I/O direction of the variable in the Controller.  There is no network variable in the Controller that corresponds to the tag settings.  A variable in the Controller that is set for a tag data link has the Network Publish attribute set to Input but also has the Constant attribute.  Attached information  The I/O direction of the tag settings or Controller variable so that the I/O direction of the tag data link setting agree with the I/O direction of th	rection			· ·			
agree with the I/O direction of the variable in the Controller.  There is no network variable in the Controller that corresponds to the tag settings.  A variable in the Controller that is set for a tag data link has the Network Publish attribute set to Input but also has the Constant attribute.  Attached information  Precautions/  Agree with the I/O direction of the tag data link setting agree with the I/O direction of the Controller variable the tag data link setting agree with the I/O direction of the Controller variable.  Set the tag to specify an existing network variable.  Do not set the Constant attribute in the Controller variable whose Network Publish attribute is set to Input.  Input.			iay seilings.	I to match the netw	vork variable.	match the networ	k variable.
variable in the Controller.  There is no network variable in the Controller that corresponds to the tag settings.  A variable in the Controller that is set for a tag data link has the Network Publish attribute set to Input but also has the Constant attribute.  Attached information  Variable in the Controller.  Itings and the Controller variable tag settings to specify existing network variable in the tag.  Modify the tag settings to specify existing network variable in the tag.  Remove the Constant attribute of the Controller variable whose Network Publish attribute is set to Input.  Remove the Constant attribute of the Controller variable whose Network Publish attribute is set to Input.  None							
There is no network variable in the Controller that corresponds to the tag settings.  A variable in the Controller that is set for a tag data link has the Network Publish attribute set to Input but also has the Constant attribute.  Attached information  There is no network variable in the Controller that is set for a tag data link has the Network Publish attribute set to Input but also has the Constant attribute.  Modify the tag settings to specify existing network variable in the tag.  Remove the Constant attribute of the Controller variable whose Network Publish attribute is set to Input.  None  Attached information  None		The I/O direction	that is set in the	Modify the tag se	ttings or Control-	Set the tag setting	gs or Controller
Controller that corresponds to the tag settings.  A variable in the Controller that is set for a tag data link has the Network Publish attribute set to Input but also has the Constant attribute.  Attached information  Controller that corresponds to the existing network variable in the tag.  Remove the Constant attribute of the Controller variable whose Network Publish attribute is set to Input.  Do not set the Constant attribute in the Controller variable whose Network Publish attribute is set to Input.  Input.  Attached information  None		The I/O direction tag data link setting agree with the I/O	that is set in the ngs does not direction of the	Modify the tag se ler variable setting direction of the ta	ttings or Control- gs so that the I/O g data link set-	Set the tag setting variable so that the tag data link s	gs or Controller ne I/O direction of setting agree with
set for a tag data link has the Network Publish attribute set to Input but also has the Constant attribute.  Attached information  Precautions/  Set for a tag data link has the Network Publish attribute set to Input work Publish attribute is set to Input.  the Controller variable whose Network Publish attribute is set to Input.  Input.  the Controller variable whose Network Publish attribute is set to Input.		The I/O direction tag data link setting agree with the I/O	that is set in the ngs does not direction of the	Modify the tag se ler variable setting direction of the ta tings and the Cor	ttings or Control- gs so that the I/O g data link set-	Set the tag setting variable so that the tag data link set the I/O direction of	gs or Controller ne I/O direction of setting agree with
work Publish attribute set to Input but also has the Constant attribute.  Attached information  Precautions/  None  work Publish attribute is set to Input.  work Publish attribute is set to Input.  None		The I/O direction tag data link settir agree with the I/O variable in the Co  There is no netwo Controller that con	that is set in the ngs does not 0 direction of the entroller.	Modify the tag se ler variable setting direction of the ta tings and the Cormatch.  Modify the tag se	ttings or Control- gs so that the I/O g data link set- ntroller variable ttings to specify	Set the tag setting variable so that the tag data link set the I/O direction of variable.  Set the tag to specific set the tag	gs or Controller ne I/O direction of setting agree with of the Controller ecify an existing
but also has the Constant attribute. Input. Input.  Attached information  Precautions/ None		The I/O direction tag data link settir agree with the I/O variable in the Co  There is no network Controller that contag settings.	that is set in the ngs does not direction of the introller.  Ork variable in the rresponds to the	Modify the tag se ler variable setting direction of the ta tings and the Cormatch.  Modify the tag se existing network variable.	ttings or Control- gs so that the I/O g data link set- ntroller variable ttings to specify variable in the tag.	Set the tag setting variable so that the tag data link is the I/O direction of variable.  Set the tag to spenetwork variable.	gs or Controller ne I/O direction of setting agree with of the Controller ecify an existing
Attached information  Precautions/ None		The I/O direction tag data link settir agree with the I/O variable in the Co  There is no network Controller that contag settings.  A variable in the O set for a tag data	that is set in the ngs does not 0 direction of the entroller.  Ork variable in the rresponds to the Controller that is link has the Net-	Modify the tag se ler variable setting direction of the ta tings and the Cormatch.  Modify the tag se existing network of the Controller variable.	ttings or Control- gs so that the I/O g data link set- ntroller variable ttings to specify variable in the tag.	Set the tag setting variable so that the tag data link is the I/O direction of variable.  Set the tag to spenetwork variable.  Do not set the Cothe Controller variable variable.	gs or Controller ne I/O direction of setting agree with of the Controller ecify an existing onstant attribute in itable whose Net-
Precautions/ None		The I/O direction tag data link settir agree with the I/O variable in the Co  There is no network Controller that coutag settings.  A variable in the Coset for a tag data work Publish attributes.	that is set in the ngs does not 0 direction of the entroller.  Ork variable in the rresponds to the Controller that is link has the Netbute set to Input	Modify the tag se ler variable setting direction of the tatings and the Cormatch.  Modify the tag se existing network of the Controller var work Publish attri	ttings or Control- gs so that the I/O g data link set- ntroller variable ttings to specify variable in the tag.	Set the tag setting variable so that the tag data link is the I/O direction of variable.  Set the tag to spenetwork variable.  Do not set the Cothe Controller varwork Publish attri	gs or Controller ne I/O direction of setting agree with of the Controller ecify an existing onstant attribute in itable whose Net-
		The I/O direction tag data link settir agree with the I/O variable in the Co  There is no network Controller that contag settings.  A variable in the O set for a tag data work Publish attril but also has the O	that is set in the ngs does not 0 direction of the entroller.  Ork variable in the rresponds to the Controller that is link has the Netbute set to Input	Modify the tag se ler variable setting direction of the tatings and the Cormatch.  Modify the tag se existing network of the Controller var work Publish attri	ttings or Control- gs so that the I/O g data link set- ntroller variable ttings to specify variable in the tag.	Set the tag setting variable so that the tag data link is the I/O direction of variable.  Set the tag to spenetwork variable.  Do not set the Cothe Controller varwork Publish attri	gs or Controller ne I/O direction of setting agree with of the Controller ecify an existing onstant attribute in itable whose Net-
INGIII IN DE LA COMPANIA DEL COMPANIA DEL COMPANIA DE LA COMPANIA	mation	The I/O direction tag data link settir agree with the I/O variable in the Co  There is no network Controller that contag settings.  A variable in the Coset for a tag data work Publish attril but also has the Controller	that is set in the ngs does not 0 direction of the entroller.  Ork variable in the rresponds to the Controller that is link has the Netbute set to Input	Modify the tag se ler variable setting direction of the tatings and the Cormatch.  Modify the tag se existing network of the Controller var work Publish attri	ttings or Control- gs so that the I/O g data link set- ntroller variable ttings to specify variable in the tag.	Set the tag setting variable so that the tag data link is the I/O direction of variable.  Set the tag to spenetwork variable.  Do not set the Cothe Controller varwork Publish attri	gs or Controller ne I/O direction of setting agree with of the Controller ecify an existing onstant attribute in itable whose Net-

	<u> </u>				ı		
Event name	Tag Data Link Co			Event code	84070000 hex		
Meaning	Establishing a tag	data link connection	on failed.				
Source	X Bus EtherNet/IF ule	P Function Mod-	Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and CIP1/CIP2 are given in combination	Detection timing	When establishing a tag data link connection	
Error attributes	Level	Minor fault	Recovery Automatic recovery		Log category	System	
Effects	User program	Continues.	Operation	Operation The data link does failed to establish connection operat			
Indicators	EtherNet/IP NET	RUN	EtherNet/IP NET	ERR	EtherNet/IP LINE	(/ACT	
	Flashes at 1-s into	ervals.	Flashes at 1-s int	ervals.			
Device variable	Variable		Data type		Name		
	EIP_Comm1Status.TDLinkOpnErr		BOOL		CIP Communication I	· ·	
	EIP_Comm2Statu	ıs.TDLinkOpnErr	BOOL		CIP Communications2 Tag Data Link Connection Failed		
Cause and cor-	Assumed cause		Correction		Prevention		
rection	The tag data link mation is not the snator and target.		Modify connection information of the tag data link and download the device parameter or connection settings from Network Configurator or Sysmac Studio.  Please reduce class-3 messages.		Before starting the tag data link, match the connection information for the tag data link in the originator and target.		
	Insufficient conne	ctions			Please reduce the number of data link and class-3 messages used.		
	CIP message communications at the target node are stopped.		Make the device start normal CIP message communications.		Start CIP message communications successfully and then perform tag data links.		
	Setting to use tag munications was series EtherNet/IF cluded in the CIP tion settings.	made to the NX- P Unit that is in-	EtherNet/IP Unit, in the CIP Safety	o not configure the NX-series herNet/IP Unit, which is included the CIP Safety connection set- gs, to use tag data link commu- cations.		Do not configure the NX-series EtherNet/IP Unit, which is included in the CIP Safety connection set- tings, to use tag data link commu- nications.	
	The NX-series Etl with tag data link was added to the nection settings.	communications	Do not add the NX-series Ether- Net/IP Unit, for which tag data link communications are set to use, to the CIP Safety connection settings.		Do not add the NX-series Ether- Net/IP Unit, for which tag data link communications are set to use, to the CIP Safety connection settings.		
Attached information	192.168.250.1) Attached informat	ion 2: Connection i	of the target node (example: C0A8FA01 hex for IP address of instance No. 0 to 255 a status (example: 010000117 hex for General Status 01 and Additional Status				
Precautions/ Remarks	Refer to 14-6-2	Connection Status for multiple connec		<i>leshooting</i> on page	14-55. istered only for one	connection	

Event name	Tag Data Link Tin	neout		Event code	84080000 hex	
Meaning	A timeout occurre	ed in a tag data link				
Source	X Bus EtherNet/IF ule	P Function Mod-	Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and CIP1/CIP2 are given in combination	position of the X Bus Unit (unit number) and CIP1/CIP2 are given in combination ter the stag data communication ter the stag data communication.	
Error attributes	Level	Minor fault	Recovery	Automatic recovery Log category System		System
Effects	User program	Continues.	Operation		link connection sto ular basis continue ata link error.	
Indicators	EtherNet/IP NET	RUN	EtherNet/IP NET	ERR	EtherNet/IP LINE	K/ACT
	Flashes at 1-s into	ervals.	Flashes at 1-s int	ervals.		
Device variable	Variable		Data type		Name	
	EIP_Comm1Statu	us.TDLinkErr	BOOL		CIP Communicat	ions1 Tag Data
					Link Communicat	
	EIP_Comm2Status.TDLinkErr		BOOL	BOOL		ions2 Tag Data
					Link Communicat	tions Error
Cause and cor-	Assumed cause				Prevention	
rection	The power supply to the target node is OFF.  Communications with the target		Check the status of the target node and start it up normally.		Check that the target node is operating properly and start the tag data link.	
	node stopped.					
	The Ethernet cab EtherNet/IP is dis		Check that the cocorrectly and reconnector.		Connect the conr	nector properly.
	The Ethernet cable for EtherNet/IP is broken.		Replace the Ethernet cable.		None	
	The link to the EtherNet/IP port is OFF.		Refer to the Link OFF Detected error (85D50000Hex) for the assumed causes and other information on link OFF.		Refer to the Link OFF Detected error (85D50000Hex) for the assumed causes and other information on link OFF.	
	CIP message communications at the target node are stopped.		Make the device start normal CIP message communications.		Start CIP message communications successfully and then perform tag data links.	
	When the Packet Filter function is enabled in the EtherNet/IP Port Settings, packets from the target are not allowed.		Allow packets from the target in the Packet Filter settings of the Ether-Net/IP Port Settings.		Make sure that packets from the target are allowed in the Packet Filter settings of the Ethernet/IP Port Settings and perform a tag data link.	
	CIP communications are not allowed by the firewall function or Packet Filter function on the target node or the devices on the communication path.		Allow CIP communications in the firewall function or Packet Filter functions on the target node and the devices on the communication path.		Make sure that CIP communications are allowed in the firewall function or Packet Filter functions on the target node or the devices on the communication path, and then perform a tag data link.	
	The packet loss of path due to the necessions load.		Increase the connection timeout value or RPI. Or, review the network environment and network devices.		Design the network so that there is not too much load on the network.	
	Noise			countermeasures	Implement noise countermeasure if there is excessive noise.	

Attached information	Attached information 1: Connection instance No. 0 to 255 Attached information 2: IP address of the target node (example: C0A8FA01 hex for IP address of 192.168.250.1)
Precautions/ Remarks	<ul> <li>This event des not occur for the following cases. The Controller is connected as a target. A connection timeout is occurring due to a Link OFF Error with an Ethernet switch.</li> <li>If errors occur for multiple connections in one node, the event log is registered only for one connection where an error is occurring.</li> </ul>

Event name	Tag Data Link Co	nnection Timeout		Event code	84090000 hex		
Meaning	A timeout occurre	ed while trying to es	stablish a tag data li	ink connection.			
Source	X Bus EtherNet/IF ule	P Function Mod-	Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and CIP1/CIP2 are given in combination	Detection timing	When establishing a tag data link connection	
Error attributes	Level	Minor fault	Recovery	Automatic re- covery	Log category	System	
Effects	User program	Continues.	to establish a conr		nection does not o	a timeout error occurred while trying nection does not operate. Reconna regular basis continues for the	
Indicators	EtherNet/IP NET	RUN	EtherNet/IP NET	ERR	EtherNet/IP LINE	(/ACT	
	Flashes at 1-s into	ervals.	Flashes at 1-s int	ervals.			
Device variable	Variable		Data type		Name		
			BOOL		CIP Communications1 Tag Data Link Connection Failed		
	EIP_Comm2Statu	us.TDLinkOpnErr	BOOL		CIP Communications2 Tag Data Link Connection Failed		
Cause and cor-	Assumed cause		Correction		Prevention		
rection	The power supply to the target node is OFF.  Communications with the target		Check the status of the target node and start it up normally.		Check that the target node is operating properly and start the tag data link.		
	node stopped.						
	CIP message communications stopped at the target node or the EtherNet/IP port.		Make the device start normal CIP message communications.		Start CIP message communications successfully and then perform tag data links.		
	The Ethernet cable connector for EtherNet/IP is disconnected.		Check that the connector is fitted correctly and reconnect the connector.		Connect the connector properly.		
	The Ethernet cab is broken.	le for EtherNet/IP	Replace the Ethernet cable.		None		
	CIP communications are not allowed by the firewall function or Packet Filter function on the target node or the devices on the communication path.		Allow CIP communications in the firewall function or Packet Filter functions on the target node and the devices on the communication path.		Make sure that CIP communications are allowed in the firewall function or Packet Filter functions on the target node or the devices on the communication path, and then perform a tag data link.		
	An error occurred cations path.	in the communi-	Check the common and take corrective there are any pro	e measures if	None		
Attached information	Attached informat 192.168.250.1)	tion 1: IP address o	of the target node (e		1 hex for IP addres	ss of	
Precautions/ Remarks	The Controller A connection ti	for multiple connec	=			e connection	

Event name	Allowed Commun	ications Bandwidth	per Unit Exceed-	Event code	840C0000 hex		
Meaning			ons that are set or e of tag data links an				
Source	X Bus EtherNet/IP Function Module  Source details  1 to 4: Mounting position of the X Bus Unit (unit number) and CIP1/CIP2 are given in combination						
Error attributes	Level	Minor fault	Recovery	Automatic re- covery (after downloading the settings), cycle the power sup- ply, or Controller reset	Log category	System	
Effects	User program	Continues.	Operation	_	nd CIP Safety communications that sallowable communication bandwidth		
Indicators	EtherNet/IP NET	RUN	EtherNet/IP NET	ERR	EtherNet/IP LINK/ACT		
	Flashes at 1-s into	ervals.	Flashes at 1-s into	ervals.			
Device variable	Variable		Data type		Name		
	EIP_Comm1Status.TDLinkOpnErr		BOOL		CIP Communications1 Tag Data Link Connection Failed		
	EIP_Comm2Statu	ıs.TDLinkOpnErr	BOOL		CIP Communicat Link Connection	=	
Cause and cor-	Assumed cause		Correction		Prevention		
rection	An attempt was man connection of connection of content of the packet transition the tag data links communications of the ports, and allowable communication width of the Unit.	ommunications which is the sum smission rates of and CIP Safety used for all Ether- it exceeded the	Change the settings of the originator node for tag data links and CIP Safety communications so that PPS for all port of the Ethernet/IP port is within the allowable communications bandwidth per Unit, and cycle the power supply to the Controller or reset the Controller.		Set tag data links and CIP Safety communications so that PPS for all ports of the Ethernet/IP port is smaller than the allowable communications bandwidth per Unit.		
Attached infor- mation	None						
Precautions/ Remarks	The bandwidth usage (PPS) for tag data links on the EtherNet/IP port is shown on the <b>Ethernet Inform</b> tab page of the Network Configurator.  For the procedure to check the bandwidth usage (PPS), refer to the description on <b>Ethernet Informatic</b> Page in Checking Communications Status with the Sysmac Studio and Troubleshooting on the NJ/NX-s CPU Unit Built-in EtherNet/IP Port User's Manual (Cat. No. W506).					<b>Information</b> Tab	

Event name	Number of Tag Se	ets for Tag Data Lir	nks Exceeded	Event code	840E0000 hex		
Meaning	The total number	of tag sets for tag	data links for all Eth	ernet/IP ports exce	eds the upper limit	t.	
Source	X Bus EtherNet/IF ule	P Function Mod-	Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and CIP1/CIP2 are given in combination	Detection timing	At power ON, Controller reset, download from the Sysmac Stu- dio, or download from the Net- work Configura- tor	
Error attributes	Level	Minor fault	Recovery	Automatic re- covery	Log category	System	
Effects	User program	Continues.	Operation	Tag data link com were stopped.	munications for the relevant port		
Indicators	EtherNet/IP NET	RUN	EtherNet/IP NET	ERR	EtherNet/IP LINK/ACT		
	Flashes at 1-s into	ervals.	Flashes at 1-s intervals.				
Device variable	Variable		Data type BOOL		Name		
	EIP_Comm1Statu	us.TDLinkCfgErr			CIP Communications1 Tag Data Link Setting Error		
	EIP_Comm2Statu	us.TDLinkCfgErr	BOOL		CIP Communications2 Tag Data Link Setting Error		
Cause and cor-	Assumed cause		Correction		Prevention		
rection	The total number ports that are set in each Ethernet/l the maximum nur allows.	for tag data links P port exceeded	Change the number of tag sets so that the total number of tag sets for all ports that are set for tag data		When you change the number of tag sets for tag data links in each Ethernet/IP port, make sure that the total number of tag sets for all ports does not exceed the maximum number.		
Attached information				e set for the produc			
Precautions/ Remarks	None			p. 2 2 2 2 2 2 2 2 2 2 2 2			

Event name	Unit Configuration and Tag Data Link	n Error, Combined l k	Use of CIP Safety	Event code	342C0000 hex		
Meaning	Tag data link com EtherNet/IP Unit.	Tag data link communications and CIP Safety communications cannot be used together in one NX-series  EtherNet/IP Unit.					
Source	ule		Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and CIP1/CIP2 are given in combination	Detection timing	Continuously	
Error attributes	Level	Observation	Recovery		Log category	System	
Effects	User program	Continues.	Operation	Not affected.			
Indicators	EtherNet/IP NET	RUN	EtherNet/IP NET	EtherNet/IP NET ERR		K/ACT	
Device variable	Variable		Data type		Name		
	None						
Cause and cor-	Assumed cause		Correction	Correction		Prevention	
rection	Setting to use tag munications was series EtherNet/If cluded in the CIP tion settings.	made to the NX- P Unit that is in-	EtherNet/IP Unit, in the CIP Safety	Do not configure the NX-series EtherNet/IP Unit, which is included in the CIP Safety connection set- tings, to use tag data link commu- nications	Do not configure the NX-series EtherNet/IP Unit, which is included in the CIP Safety connection set- tings, to use tag data link commu- nications.		
	The NX-series Et with tag data link was added to the nection settings.	communications	Do not add the NX-series Ether- Net/IP Unit, for which tag data link communications are set to use, to the CIP Safety connection settings.		communications	hich tag data link	
Attached information	None						
Precautions/ Remarks	None						

Event name	Access Detected Outside Range of Variable Event code			Event code	54E00000 hex	
Meaning	An access attemp	ot to write a value o	ut of range was det	tected for a tag var	iable that is used in	a tag data link.
Source	X Bus EtherNet/IP Function Mod- ule		Source details	CIP1 or CIP2	Detection tim- ing	When writing a value to a variable
Error attributes	Level	Observation	Recovery		Log category	System
Effects	User program	Continues.	Operation	Not affected.		
Indicators	EtherNet/IP NET	RUN	EtherNet/IP NET	ERR	EtherNet/IP LINK	(/ACT
Device variable	Variable		Data type		Name	
	None					
Cause and cor-	Assumed cause		Correction		Prevention	
rection	by an EtherNet/IP tag data link to a transfer wariable with range specification. A value that does not specify an enumerator was written by an EtherNet/IP tag data link to an enutton.		Correct the value the variable with r		Write values that a variables with spe	O
	A value that does enumerator was v	not specify an written by an ata link to an enu-	tion so that the varange.  Correct the value the enumeration value specifie	that is written to variable so that	Write values that tors to enumeration	
Attached information	A value that does enumerator was v EtherNet/IP tag d	not specify an written by an ata link to an enu-	range. Correct the value the enumeration v	that is written to variable so that		
	A value that does enumerator was v EtherNet/IP tag d meration variable None	not specify an written by an ata link to an enu-	range. Correct the value the enumeration value specifie	that is written to variable so that is an enumerator.		on variables.

Event name	Tag Data Link Do	wnload Started		Event code	94010000 hex	
Meaning	Changing the tag	data link settings s	tarted.			
Source	X Bus EtherNet/IF ule	P Function Mod-	Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and CIP1/CIP2 are given in combination	Detection timing	At user operation
Error attributes	Level	Information	Recovery		Log category	Access
Effects	User program	Continues.	Operation	Not affected.		
Indicators	EtherNet/IP NET RUN		EtherNet/IP NET ERR		EtherNet/IP LINI	K/ACT
	Flashes at 1-s into	ervals.				
Device variable	Variable		Data type		Name	
	None					
Cause and cor-	Assumed cause		Correction		Prevention	
rection	Changing the tag started.	data link settings				
Attached infor-	Attached informat	ion 1: Controller sta	atus (01 hex: PRO	GRAM mode, 02 he	ex: RUN mode)	
mation						
Precautions/	None					
Remarks						

Event name	Tag Data Link Do	wnload Finished		Event code	94020000 hex	
Meaning	Changing the tag	data link settings fi	nished.			
Source	X Bus EtherNet/IP Function Module  Source details		Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and CIP1/CIP2 are given in combination	Detection timing	At user operation
Error attributes	Level	Information	Recovery		Log category	Access
Effects	User program	Continues.	Operation	Not affected.		
Indicators	EtherNet/IP NET RUN		EtherNet/IP NET	EtherNet/IP NET ERR		(/ACT
	Flashes at 1-s int	ervals.				
Device variable	Variable		Data type		Name	
	None					
Cause and cor-	Assumed cause		Correction		Prevention	
rection	Changing the tag finished.	data link settings				
Attached infor- mation	Attached information 1: Controller status (01 hex: PROGRAM mode, 02 hex: RUN mode)					
Precautions/ Remarks	None					

Event name	Tag Data Link Sto	pped		Event code	94030000 hex		
Meaning	•	Tag data links were stopped by the Network Configurator, Sysmac Studio, special instructions or manipulation of a system-defined variable. Or, the data link table was downloaded from Network Configurator or Sysmac Studio.					
Source	X Bus EtherNet/IF ule	P Function Mod-			Detection timing	At user operation	
Error attributes	Level	Information	Recovery		Log category	Access	
Effects	User program	Continues.	Operation	Not affected.			
Indicators	EtherNet/IP NET RUN		EtherNet/IP NET	therNet/IP NET ERR Eth		(/ACT	
	Flashes at 1-s intervals			<del></del>			
Device variable	Variable		Data type		Name		
	None						
Cause and cor-	Assumed cause		Correction		Prevention		
rection	Tag data links well Network Configur dio, special instru lation of a system	ator, Sysmac Stuctions or manipu-					
Attached information	Attached information 1: Controller status (01 hex: PROGRAM mode, 02 hex: RUN mode) Attached information 2: Operation method (01 hex: Operation by Network Configurator or Sysmac Studio, 02 hex: Manipulation by a device variable, 03 hex: Manipulation by special instructions) Attached information 3:  • When attached information 2 is 03 hex: IP address of the target node  • Other than the above: 0						
Precautions/ Remarks	None						

Event name	Tag Data Link Sta	arted		Event code	94040000 hex	
Meaning	Tag data links were started by the Network Configurator, Sysmac Studio, special instructions or manipulation of a system-defined variable. Or, the data link table was downloaded from Network Configurator or Sysmac Studio.					
Source	X Bus EtherNet/IP Function Module		Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and CIP1/CIP2 are given in combination	Detection timing	At user operation
Error attributes	Level	Information	Recovery		Log category	Access
Effects	User program	Continues.	Operation	Not affected.		
Indicators	EtherNet/IP NET RUN		EtherNet/IP NET ERR		EtherNet/IP LINE	K/ACT
	Flashes at 1-s into	ervals.				
Device variable	Variable		Data type		Name	
	None					
Cause and cor-	Assumed cause		Correction		Prevention	
rection	Tag data links we	•				
	_	Network Configurator, Sysmac Stu- dio, special instructions or manipu-				
	lation of a system	-				
Attached infor-	Attached informat	tion 1: Controller st	•	GRAM mode, 02 he	•	smac Studio 02
mation		•		lation by special in	,	siriac Otadio, 02
	Attached informat	•	,	, ,	,	
	When attached	l information 2 is 03	B hex: IP address o	of the target node		
	Other than the	above: 0				
Precautions/	None					
Remarks						

Event name	Tag Data Link All	Run		Event code	94070000 hex		
Meaning	Tag data link con	nections to all targe	et nodes have been	normally establish	ed.		
Source	X Bus EtherNet/IP Function Module		Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and CIP1/CIP2 are given in combination	ing When establi ing a tag data link connection		
Error attributes	Level	Information	Recovery		Log category	System	
Effects	User program	Continues.	Operation	Not affected.			
Indicators	EtherNet/IP NET RUN		EtherNet/IP NET ERR		EtherNet/IP LINK/ACT		
	Lights						
Device variable	Variable		Data type		Name		
	EIP_Comm1Status.TDLinkAllRun-Sta		BOOL		CIP Communications1 All Tag Data Link Communications Status		
	EIP_Comm2Status.TDLinkAllRun- Sta		BOOL	CIP Communications2 All Tag Data Link Communications Status			
Cause and cor-	Assumed cause		Correction		Prevention		
rection	Tag data link connections to all target nodes have been normally established.						
Attached infor- mation	None	'					
Precautions/ Remarks	None						

Event name	Restarting Ethern	et Port		Event code	96450000 hex		
Meaning	The EtherNet/IP p	oort was restarted.					
Source	X Bus EtherNet/IP Function Module		Source details	1 to 4: Mounting position of the X Bus Unit (unit number) and CIP1/CIP2 are given in combination	Detection timing	At user operation	
Error attributes	Level	Information	Recovery		Log category	Access	
Effects	User program	Continues.	Operation	Not affected.	ected.		
Indicators	EtherNet/IP NET RUN		EtherNet/IP NET ERR		EtherNet/IP LINK/ACT		
Device variable	Variable		Data type		Name		
	None						
Cause and cor-	Assumed cause		Correction	Prevention			
rection	The EtherNet/IP port was restarted.						
Attached infor- mation	None						
Precautions/ Remarks	None						

## 14-5 Checking with Device Variables

You can check the status of current Controller errors in the X Bus Ethernet Function Module, X Bus EtherNet/IP Function Module, and X Bus Unit Common Function Module with the device variables. Refer to Section 6 Device Variables Related to the NX-series EtherNet/IP Unit on page 6-1 for details on the device variables of the X Bus Ethernet Function Module and X Bus EtherNet/IP Function Module.


Refer to Specifications for Individual Device Variables in the NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501) for details on the device variables of the X Bus Unit Common Function Module.

# 14-6 Checking with the Network Configurator

You can check the communications status of each device on the EtherNet/IP network (e.g. tag data link connection status) with the Network Configurator.

#### 14-6-1 The Network Configurator's Device Monitor Function

Connect the Network Configurator online, select the device to be checked, right-click to display the pop-up menu, and select **Monitor**.



The Monitor Device Dialog Box will be displayed.



#### **Precautions for Correct Use**

Monitoring may not be performed if the following settings are configured on the NJ/NX-series Controller on the connection route or on the destination NJ/NX-series Controller. If monitoring is not performed, check the following settings. Refer to *CIP Message Server* on page 7-15, and *Packet Filter* on page 7-7 for details on the settings.

- The Do not use Option is selected for the CIP message server.
- The Use Option is selected for Packet Filter.



#### **Additional Information**

If a communications error occurs during monitoring, the dialog box will continue to show the last information that was collected.

To start monitoring again, close the **Monitor Device** Dialog Box, and then open the **Monitor Device** Dialog Box again.


#### Status 1 Tab Page

The following check boxes are displayed for the status. If a check box is checked with ✓, the status is TRUE.

Classification	Item	TRUE status description
Ethernet Status	Com. Controller Error	An error occurred in the Communications Controller.
	IP Address Duplicated	The same IP address is assigned to more than one node.
	On-Line	The Unit is online. (The EtherNet/IP Unit can perform communications processing.)
	Multiple Switch ON	More than one data link start/stop switch changed to TRUE at the same time.
Data Link Status	Comparison Error	The remote node information in the tag data link parameters was different from the actual node information.  Main causes:  The specified target does not exist.  The variable name does not match.  The connection size is different.  Connection resources are not sufficient.
Data Link Status	Tag Data Link Error	There were two or more errors in a connection as an originator.
	Invalid Parameter	An error was found in the parameters for tag data links that are saved in non-volatile memory.
	All Tag Data Link	Tag data links are communicating in all connections as the originator.
	Tag Data Link	Tag data links are communicating in one or more connections as the originator.
Configuration Er-	Ethernet Link Status	A link is established with the Ethernet switch.
ror Status	Ethernet Basic Settings Logic Error	The following settings are incorrect: TCP/IP settings (IP address, subnet mask, or link settings)
	IP Router Table Error	There is a mistake in the IP router table information.
	Ethernet Ext Config Logical Error	Always FALSE.
	BOOTP Server Error	One of the following errors occurred when using the BOOTP server:  The IP address received from the BOOTP server is incorrect.  A communications timeout occurred with the server.


In the **Target Node Status**, information about the target node that acts as the originator is displayed.

If all tag data link connections to the node are established and normal, this information is displayed in blue. However, if any connection is broken it is displayed in red.



#### Status 2 Tab Page

This tab page displays information on nodes with tag data link originator settings. This information is in blue if the connection is normal, or red if an error occurred.





#### **Additional Information**


The target Controller status can be used when the Controller status is set to **Included** for all the target sets for both originator and target connections.

If it is set to **Not included**, it is grayed out on the display.

#### Connection Tab Page


- Target Node Status
   Information about the target node that acts as the originator is displayed.
   If all tag data link connections to the node are established and normal, this information is displayed in blue. However, if any connection is broken it is displayed in red.


   However, this information is displayed in gray if the connection to the node is stopped.
- Connection Status
   The Status Column of the connection status shows the status of each connection that is set as the originator. The connection status can be used to identify the cause of tag data link errors.
   Refer to 14-6-2 Connection Status Codes and Troubleshooting on page 14-55 for details on the



#### Controller Log Tab Page

This tab page displays the Controller event log that is stored in the NX-series EtherNet/IP Unit. The error history shows errors that have occurred. It can be saved in a file in the computer.





#### Tag Status Tab Page

Attribute error:

This tab page displays if the tag settings for each tag for tag data links are set so that data can be exchanged with the NX-series EtherNet/IP Unit.

The following status is displayed depending on the status that is set.

Normally resolved: Normal data exchange is possible.

Resolving: The variables with tags are being resolved.

When the resolution is completed normally, a connection will be established and the data ex-

change will start.

Different sizes: Different sizes are set for the network variables and the tag settings.

A connection will not be established for a tag for which this error occurs.

No tag: A network variable is not set in the variable table in the NX-series EtherNet/IP Unit for the speci-

fied tag setting. Or, instead of a member of union variable, unions are specified.

A connection will not be established for a tag for which this error occurs.


1. Writing is not possible for Read Only and Constant attributes.

2. The I/O direction that is set in the tag data link settings does not agree with the I/O direction of the variable in the NX-series EtherNet/IP Unit. There is an error in the setting of a Net-

work Publish attribute for a NX-series EtherNet/IP Unit variable.

A connection will not be established for a tag for which this error occurs.

If the status is not "Normally resolved", check the tag data link settings or the network variable settings in the variable table in the NX-series EtherNet/IP Unit.




#### Ethernet Information Tab Page

This tab page displays the communications status at the communications driver level of the Ether-Net/IP port.

The error counter information can be used to confirm whether communications problems have occurred.

The tag data link information can be used to confirm characteristics such as the Bandwidth (pps).



#### 14-6-2 Connection Status Codes and Troubleshooting

This section explains how to identify and correct errors based on the tag data link's connection status. The connection status can be read using the **Connection** Tab Page of Monitor Device Window with the Network Configurator. Refer to *14-6-1 The Network Configurator's Device Monitor Function* on page 14-47 for details.



#### **Additional Information**

The connection status has the same meaning as the Connection Manager's General and Additional error response codes, as defined in the CIP specifications.

The following table shows the likely causes of the errors causes for each configuration and connection status (code).

	Originator	Target
Configuration 1		
Configuration 2		Products from other manufacturers
Configuration 3	Products from other manufacturers	

Connect	ion status			Handling	
General Status (hex)	Additional Status (hex)	Source of error	Configuration	Configuration 2	Configuration 3
00	0000	Normal status code: The connection has been opened and the tag data link is communicating normally.			
01	0100	Error code returned from target: Attempted to open multiple connections for the same connection.	This error does not occur.	Depends on the target's specifications. (This error should not oc- cur. If it does, contact the tar- get device's manufacturer.)	Depends on the originator's specifications. (This error should not oc- cur. If it does, contact the originator devi- ce's manufac- turer.)
01	0103	Error code returned from target: Attempted to open a connection with an unsupported transport class.	This error does not occur.	Confirm that the target supports Class 1.	Confirm that the originator supports Class 1.
01	0106	Duplicate consumers: Attempted to open multiple connections for single-consumer data.	If the tag data link is stopped or started, this error may occur according to the timing, but the system will recover automatically.	Depends on the target's specifications. (Contact the target device's manufacturer.)	If the tag data link is stopped or started, this error may occur according to the timing, but the system will recover automatically.

Connecti	on status			Handling	
General Status (hex)	Additional Status (hex)	Source of error	Configuration	Configuration 2	Configuration 3
01	0107	Error code returned from target: Attempted to close a connection, but that connection was already closed.	This error does not occur.	This error does not occur.	This is not an error because the connection is already closed.
01	0108	Error code returned from target: Attempted to open a connection with an unsupported connection type.	This error does not occur.	Check which connection types can be used by the target. (Contact the manufacturer.) Only multicast and point-topoint connections can be set.	Check which connection types can be used by the originator. (An error will occur if a connection other than a multicast or point-to-point connection is set.)
01	0109	Error code returned from target: The connection size settings are different in the originator and target.	Check the conne and target.	ection (sizes) set i	n the originator
01	0110	Error code returned from target: The target was unable to open the connection, because of its operating status, such as downloading settings.	Check whether the tag data link is stopped at the target. (Restart the tag data link communications with the software switch.)	Depends on the target's specifications. (Contact the target device's manufacturer.)	Check whether the tag data link is stopped at the target. (Restart the tag data link communications with the software switch.)
01	0111	Error code returned from target: The RPI was set to a value that exceeds the specifications.	This error does not occur.	Check the target's RPI setting specifications.	Set the originator's RPI setting to 10 seconds or less.

Connecti	on status			Handling	
General Status (hex)	Additional Status (hex)	Source of error	Configuration	Configuration 2	Configuration 3
01	0113	Error code generated by originator or returned from target: Attempted to open more connections than allowed by the specifications. Connections of tag data link communications and CIP Safety communications are used together.	Check the connection settings (number of connections) at the originator and target. Check whether a Unit Configuration Error, Combined Use of CIP Safety and Tag Data Link (342C0000 hex) observation level event occurred in the NX-series EtherNet/IP Unit which is on the path of tag data link communications.	Check the connection settings (number of connections) at the originator and target. Check the connection specifications for devices from other manufacturers. Check whether a Unit Configuration Error, Combined Use of CIP Safety and Tag Data Link (342C0000 hex) observation level event occurred in the NX-series EtherNet/IP Unit which is on the path of tag data link communications.	Check the connection settings (number of connections) at the originator and target. Check the connection specifications for devices from other manufacturers. Check whether a Unit Configuration Error, Combined Use of CIP Safety and Tag Data Link (342C0000 hex) observation level event occurred in the NX-series EtherNet/IP Unit which is on the path of tag data link communications.
01	0114	Error code returned from target: The Vendor ID and Product Code did not match when opening connection.	This error does not occur.	Depends on the target's specifications. (Contact the target device's manufacturer.) Check that the target device's EDS file is cor- rect.	Check the originator's connection settings.
01	0115	Error code returned from target: The Product Type did not match when opening connection.	This error does not occur.	Depends on the target's specifications. (Contact the target device's manufacturer.) Check that the target device's EDS file is cor- rect.	Check the originator's connection settings.

Connecti	on status			Handling	
General Status (hex)	Additional Status (hex)	Source of error	Configuration	Configuration 2	Configuration 3
01	0116	Error code returned from target: The Major/Minor Revisions did not match when opening connection.	Check the major and minor revisions set for the target device and connection. If necessary, obtain the most recent EDS file and set it again.	Depends on the target's specifications. (Contact the target device's manufacturer.) Check that the target device's EDS file is cor- rect.	Check the originator's connection settings.
01	0117	Error code returned from target: The tag set specified in the connection's target variables does not exist.	Check whether the originator and target tag sets and tags are set correct- ly.	Depends on the target's specifications. (Contact the target device's manufacturer.)	Check the originator's connection settings. Check whether the target tag sets and tags are set correctly.
01	011A	Error code generated by originator: Connection could not be established because the buffer was full due to high traffic.	Unexpected network traffic may have been received. If there are pla- ces where broadcast storms occur, such as loop connections in the network connection for- mat, then cor- rect them.	Unexpected network traffic may have been received. If there are places where broadcast storms occur, such as loop connections in the network connection for- mat, then cor- rect them.	Depends on the target's specifications. (Contact the target device's manufacturer.)
01	011B	Error code returned from target: The RPI was set to a value that is below the specifications.	This error does not occur.	Depends on the target's specifications. (Contact the target device's manufacturer.)	Set the originator's RPI setting to 1 ms or greater.
01	0203	Error code generated by originator: The connection timed out.	Tag data link communications from the target timed out. Check the power supply and cable wiring of the devices in the communications path, including the target and switches. If performance has dropped due to heavy traffic, change the performance settings. For example, increase the timeout time or RPI setting.  Also, check whether the CIP message communications of the target are stopped and whether the CIP communications are permitted by Packet Filter function of the originator or the device on the route.		

Connecti	on status			Handling	
General Status (hex)	Additional Status (hex)	Source of error	Configuration	Configuration 2	Configuration 3
01	0204	Error code generated by originator: The connection open process timed out.	There was no response from the target. Check the power supply and cable wiring of the devices in the communications path, including the target and switches.  Also, check whether the CIP message communications of the target or originator are stopped and whether the CIP communications are permitted by Packet Filter function of the target device or the device on the route.		
01	0205	Error code returned from target: There was a parameter error in the frame used to open the connection.	This error does not occur.	Depends on the target's specifications. (Contact the target device's manufacturer.)	Depends on the originator's specifications. (Contact the originator devi- ce's manufac- turer.)
01	0301	Error code generated by originator or returned from target: Total number of tag sets that are set to the product was exceeded.	Check the total number of the tag sets that are set to the product and set the tag sets so that the total number does not exceed the maximum of the allowable number.	Check the total number of the tag sets that are set to the product and set the tag sets so that the total number does not exceed the maximum of the allowable number.	Check the total number of the tag sets that are set to the product and set the tag sets so that the total number does not exceed the maximum of the allowable number.
01	0302	Error code generated by originator or returned from target: The tag data link's allowable bandwidth (pps) was exceeded.	Check the connection settings (number of connections and RPI) at the originator and target.	Check the target's connection settings (number of connections and RPI). Check the connection settings (number of connections and RPI) at the originator and target.	Check the connection settings (number of connections and RPI) at the originator and target.
01	0311	Error code returned from target: There was a parameter error in the frame used to open the connection.	This error does not occur.	Depends on the target's specifications. (Contact the target device's manufacturer.)	Depends on the originator's specifications. (Contact the originator devi- ce's manufac- turer.)

Connecti	on status			Handling	
General Status (hex)	Additional Status (hex)	Source of error	Configuration	Configuration 2	Configuration 3
01	0312	Error code returned from target: There was a parameter error in the frame used to open the connection.	This error does not occur.	Depends on the target's specifications. (Contact the target device's manufacturer.)	Depends on the originator's specifications. (Contact the originator devi- ce's manufac- turer.)
01	0315	Error code returned from target: There was a parameter error in the frame used to open the connection.	This error does not occur.	Depends on the target's specifications. (Contact the target device's manufacturer.)	Depends on the originator's specifications. (Contact the originator devi- ce's manufac- turer.)
01	0316	Error code returned from target: There was a parameter error in the frame used to close the connection.	This error does not occur.	Depends on the target's specifications. (Contact the target device's manufacturer.)	Depends on the originator's specifications. (Contact the originator devi- ce's manufac- turer.)
01	031C	Error code generated by originator: Some other error occurred.	This error does not occur.	The originator generates this code when an unsupported response code is returned from the target in reply to an open request.	Depends on the originator's specifications. (Contact the originator devi- ce's manufac- turer.)
08		Error code returned from target: There is no Forward Open or Large Forward Open service in the target device.	This error does not occur.	Depends on the target's specifications. (Contact the target device's manufacturer.)	Depends on the originator's specifications. (Contact the originator devi- ce's manufac- turer.)

Connecti	on status		Handling		
General Status (hex)	Additional Status (hex)	Source of error	Configuration	Configuration 2	Configuration 3
DO	0001	Error code generated by originator: The connection operation is stopped.	The connection was stopped because the Tag Data Link Stop Bit was turned ON, or the settings data is being downloaded. Either turn ON the Tag Data Link Start Switch, or wait until the settings data has been downloaded. This code includes fatal Controller errors and Unit failure. To handle these errors, refer to the NJ/NX-series Troubleshootin g Manual (Cat. No. W503).	The meaning of this error code is defined by each vendor, so it depends on the target's specifications. (Contact the target device's manufacturer.)	Depends on the originator's specifications. (Contact the originator device's manufacturer.)
DO	0002	Error code generated by originator: The connection is being opened (opening processing in progress).	Wait until the opening processing is completed.	The meaning of this error code is defined by each vendor, so it depends on the target's specifications.  (Contact the target device's manufacturer.)	Depends on the originator's specifications. (Contact the originator devi- ce's manufac- turer.)

Connecti	on status			Handling	
General Status (hex)	Additional Status (hex)	Source of error	Configuration	Configuration 2	Configuration 3
OMRON erro	or code				
01	0810	Error code returned from target:		The meaning of this error code is defined by each vendor, so it depends on the target's specifications. (Contact the target device's manufacturer.)	The meaning of this error code is defined by each vendor, so it depends on the originator's specifications. (Contact the originator device's manufacturer.)
01	0811	Error code generated by originator:	The error will be recovered automatically.	The meaning of this error code is defined by each vendor, so it depends on the target's specifications. (Contact the target device's manufacturer.)	The meaning of this error code is defined by each vendor, so it depends on the originator's specifications. (Contact the originator device's manufacturer.)



# **Maintenance and Inspection**

This section describes cleaning and inspection methods and maintenance procedures.

# 15-1 Maintenance and Inspection

Refer to *Maintenance and Inspection* in the *NX-series NX502 CPU Unit Hardware User's Manual (Cat. No. W629)* for information on cleaning and inspection methods and maintenance procedures of the NX-series EtherNet/IP Unit.




# **Appendices**


The appendices provide datasheets for the NX-series EtherNet/IP Unit, dimensions, and other information.

<b>A-1</b>	Dimen	nsions	A-2
A-2		ional Comparison of EtherNet/IP Ports on NJ/NX-series nits and Other Series	A-4
A-3	Use th	ne Sysmac Studio to Set the Tag Data Links (EtherNet/IP	
	Conne	ctions)	A-6
	A-3-1	Overview of the Tag Data Links (EtherNet/IP Connections) Settings with the Sysmac Studio	A-6
	A-3-2	Procedure to Make the EtherNet/IP Connection Settings with the Sysmac Studio	A-7
	A-3-3	EtherNet/IP Connection Settings	
	A-3-4	Making the EtherNet/IP Connection Settings with the Sysmac Studio	A-12
	A-3-5	Checking Communications Status with the Sysmac Studio and Trou-	
		bleshooting	A-32
	A-3-6	Troubleshooting	A-37
A-4	EDS F	ile Management	A-43
	A-4-1	Installing EDS Files	
	A-4-2	Creating EDS Files	A-44
	A-4-3	Deleting EDS Files	A-44
	A-4-4	Saving EDS Files	A-45
	A-4-5	Searching EDS Files	
	A-4-6	Displaying EDS File Properties	
	A-4-7	Creating EDS Index Files	A-46
A-5	Preca	utions for Using the Network Configurator on Windows XP,	
		ws Vista, or Windows 7 or Higher	A-47
	A-5-1	Changing Windows Firewall Settings	A-47
A-6	Tag Da	ata Link Settings with Generic Devices	A-50
•	A-6-1		
	A-6-2	Creating a Tag or Tag Set for Generic Device	
<b>A-7</b>	TCP/U	IDP Port Numbers Used for the NX-series EtherNet/IP Unit	A-55

# **A-1 Dimensions**



# **Installation Height**



(Unit: mm)

The dimension from the back of the Unit to the communications cable varies depending on the cable connector. Use the following dimensions as a guide.

Cable conn	ector	Dimension from the back of the Unit to the cab		
Manufacturer	Model			
Panduit Corporation	MPS588-C	Approx. 150 mm		
OMRON	XS6G-T421-1	Approx. 175 mm		

# A-2 Functional Comparison of EtherNet/IP Ports on NJ/NX-series CPU Units and Other Series

OK: Supported, ---: Not supported

	Built-in Ether-	Built-in Ether-	Built-in Ether-	Built-in Ether-	Built-in Ether-	NX-ser-	CJ-ser-		et/IP Unit on CJ2 CPI	•
Item	Net/IP port on NX701 CPU Unit	Net/IP port on NX502 CPU Unit	Net/IP port on NX102 CPU Unit	Net/IP port on NX1P2 CPU Unit	Net/IP port on NJ-ser- ies CPU Unit	ies Ether- Net/IP Unit	ies Ether- net Unit	Unit version 1.0	Unit version 2.0	Unit version 2.1
Tag data link com- munications serv- ice	OK	OK	OK	OK	OK	OK		OK	OK	OK
CIP message communications service	OK	OK	OK	OK	OK	OK		OK	OK	OK
IP routing	OK	OK	OK			OK				
Socket service	OK	OK	OK	OK	OK		OK			
FTP server	OK	OK	OK	OK	OK		OK		OK	OK
FTP client	OK	OK	OK	OK	OK					
Mail send/receive							OK			
Web functions							OK			
Automatic adjust- ment of PLC/ Controller's inter- nal clock	ОК	ОК	ОК	ОК	ОК		ОК		ОК	ОК
Error history	OK*1	OK*1	OK*1	OK*1	OK*1	OK*1	OK	OK	OK	OK
Response to PING command	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
SNMP/SNMP trap	OK	OK	OK	OK	OK	OK			OK	OK
CIDR function for IP addresses	OK	OK	OK	OK	OK	OK			OK	OK
DHCP client		OK								
Online connection via EtherNet/IP using CX-One							OK		OK	OK
Online connection via EtherNet/IP using Network Configurator	ОК	ОК	ОК	OK	OK	OK		OK	ОК	OK
Mounting in an NJ-series CPU Unit										OK*2

ltem	Built-in Ether- Net/IP port on NX701 CPU Unit	Built-in Ether- Net/IP port on NX502 CPU Unit	Built-in Ether- Net/IP port on NX102 CPU Unit	Built-in Ether- Net/IP port on NX1P2 CPU Unit	Built-in Ether- Net/IP port on NJ-ser- ies CPU Unit	NX-ser- ies Ether- Net/IP Unit	CJ-ser- ies Ether- net Unit	Unit version	•
Connection set- tings using the Sysmac Studio	OK	OK	OK	OK	OK	OK		 	OK

<sup>\*1.</sup> This is equivalent to the event log in the EtherNet/IP of an NJ-series Controller.

- Placing the Sysmac Studio online with the CPU Unit (However, you can place the Network Configurator online)
- Using the Troubleshooter of an NS-series PT

<sup>\*2.</sup> You cannot use the following functions if you connect to the CPU Unit through an EtherNet/IP Unit.

# A-3 Use the Sysmac Studio to Set the Tag Data Links (EtherNet/IP Connections)

# A-3-1 Overview of the Tag Data Links (EtherNet/IP Connections) Settings with the Sysmac Studio


You can use the Sysmac Studio to set the settings required for creating tag data links (EtherNet/IP connections)\*1 on the NX-series EtherNet/IP Units.

\*1. The tag data links and EtherNet/IP connections enable cyclic tag data exchanges on an EtherNet/IP network between Controllers or between Controllers and other devices. Here, "EtherNet/IP connection" refers to both the tag data links and the EtherNet/IP connections.


### Acceptable System Configuration Conditions for Setting the Ether-Net/IP Connection Settings on the Sysmac Studio

If an NX-series EtherNet/IP Unit operates as the originator device, you can use the Sysmac Studio to set the originator device settings for the EtherNet/IP connections.

Similarly, if an NX-series EtherNet/IP Unit operates as the target device, you can use the Sysmac Studio to set the tags and tag sets of the target device.



Use the Network Configurator if a CS/CJ-series PLC operates as the originator device.



# A-3-2 Procedure to Make the EtherNet/IP Connection Settings with the Sysmac Studio

#### 1 Registering devices

· Main Window

Register devices with which the EtherNet/IP connections are established to the project.

Setup Window Global Variable Table on the Sysmac Studio

2 Creating network variables\*1

--- Refer to Registering the Network Variable for the Originator Device on page A-13.

$\downarrow$			
3 Registering tags and tag sets		Refer to <i>Registering the Tag</i> and Tag Set on page A-14.	EtherNet/IP Connection Set- tings (Tag Set Display)
↓ Register the network tags and tag sets.	varia	ables that are set in step 2 as	
4 Setting connections		Refer to Setting Connections for the Originator Device on page A-17.	EtherNet/IP Connection Settings (Connection Display)
		et devices and originator devi- nunicate with using the Ether-	
5 Going online from the Sysmac Studio		Refer to <i>Transferring the Connection Settings Data</i> on page A-28.	Main Window
<u> </u>			
6 Downloading EtherNet/IP connection settings		Refer to <i>Transferring the</i> Connection Settings Data on	<ul> <li>Synchronization Window/ Transfer to Controller Dia-</li> </ul>
Note Connections automatically start after the download.		page A-28.	log Box • EtherNet/IP Connection Settings
↓			
7 Checking operation		Refer to A-3-5 Checking	EtherNet/IP Connection Moni-
Stopping and starting connections		Communications Status with the Sysmac Studio and Trou- bleshooting on page A-32.	tor Tab Page
*1. Variables with its Network Publish attrib	ute s	set to <b>Output</b> or <b>Input</b> in the Glo	bal Variable Table are called

Variables with its Network Publish attribute set to **Output** or **Input** in the Global Variable Table are called network variables.


# A-3-3 EtherNet/IP Connection Settings

This section describes the screen configuration for EtherNet/IP connection settings.


# Screen Transitions in the EtherNet/IP Connection Settings

Connection Settings

Select EtherNet/IP Connection Settings from the Tools Menu.



· Transferring connection settings to the Controller from the computer





#### **Precautions for Correct Use**


To transfer only the connection settings, execute Transfer from the EtherNet/IP Connection Setting Tab Page.

Even if you clear the **Do not transfer the connection setting** Check Box, the connection settings are not transferred from the Synchronization Window, the **Transfer to the Controller** Dialog Box, or the **Transfer from the Controller** Dialog Box as long as the data in the computer is synchronized with the data in the Controller.

## **EtherNet/IP Device List Tab Page**

The list indicates the devices to which EtherNet/IP connections can be set.

For information on how to access this tab page, refer to *Registering the Tag and Tag Set* on page A-14.



## **EtherNet/IP Connection Settings (Tag Set Display)**


Register tag sets required to create connections.

Each tag set represents the data that is sent and received through a connection. You can register up to eight tags in one tag set.

The name and size of the tag must be the same as those of the network variable \*1. Set whether to include the Controller status information in tags for the tag sets. You can also set the data output operation at a fatal error occurrence for output tags.

Refer to *Registering the Tag and Tag Set* on page A-14 for information on how to register tags and tag sets.

\*1. A variable with its Network Publish attribute set to Output or Input in the Global Variable Table is called a network variable.



# **EtherNet/IP Connection Settings (Connection Display)**

Specify the target devices and set their connections.


For each connection, set the following information: Connection Name, Connection I/O Type, I/O, target device tag set (target variable), originator device tag set (originator variable), Packet Interval (RPI), and Timeout Value.

Refer to *Setting Connections for the Originator Device* on page A-17 for information on how to make connection settings.



#### **Precautions for Correct Use**


If you changed the IP address, model, or revision of the target device after making the connection settings, change the connection settings entirely.



## **EtherNet/IP Connection Monitor Tab Page**

You can check the EtherNet/IP connection setting status offline and communications status online. When online, you can start and stop connections.

Refer to A-3-5 Checking Communications Status with the Sysmac Studio and Troubleshooting on page A-32 for information on how to check the EtherNet/IP connection setting status and communications status.




# A-3-4 Making the EtherNet/IP Connection Settings with the Sysmac Studio

This section describes the procedure to make the EtherNet/IP connection settings with the Sysmac Studio.

Here, we take the following system configuration as an example to describe how to set the EtherNet/IP connection settings.


Example: System that connects the EtherNet/IP port on Controller 1 and the EtherNet/IP port on Controller 2 via Ethernet

- Set the settings so that values in the network variable Net\_Out1 allocated for Controller 2 are sent to the network variable Net\_In1 allocated for Controller 1 at the set RPI of 50 ms cycle.
- This example assumes the programs for both Controllers 1 and 2 are registered in the same project.



Follow the flow below to set the settings to Controllers 1 and 2 for which to establish EtherNet/IP connections.

The required settings for the originator device and the target device are shown below.



Settings for the originator device (Controller 1) Settings for the target device (Controller 2)

# Registering the Network Variable for the Originator Device

Register the network variable that is sent and received using the EtherNet/IP connections.

Refer to the *Sysmac Studio Version 1 Operation Manual (Cat. No. W504)* for the operations for registering variables.

Assign the network variable to the tag used for the EtherNet/IP connection for Controller 1 (originator device).

This network variable receives data from Controller 2 (target device).

Select **Input** or **Output** for **Network Publish** of a variable in the Global Variable Table so that the variable can serve as a network variable, i.e. the variable can be used for the EtherNet/IP connections.

In this example, set the network variable for Controller 1 as shown below.



Variable name: Net\_In1

· Data type: WORD

· Network Publish attribute: Input

#### Network Variables Used for EtherNet/IP Connections

· Network variable name

You cannot specify an I/O memory address for a tag name in the EtherNet/IP connection settings. Thus, do not specify an I/O memory address for the network variable name that is to be assigned to a tag.


The following text strings are recognized as the I/O memory address names.

- 1. Variable names that contain only single-byte numerals from 0000 to 6143
- 2. Variable names with the following single-byte letters (uppercase or lowercase) followed by single-byte numerals
  - H (H000 to H511)
  - W (W000 to W511)
  - D (D00000 to D32767)
  - E0\_ to E18\_(E0\_00000 ... E0\_32767 to E18\_00000 ... E18\_32767)

To specify an I/O memory address for tag, do not specify I/O memory the address directly. Instead, create a variable with an AT specification of the I/O memory address on the Sysmac Studio, and then specify the variable for the tag.

#### · Size of variables

To use an EtherNet/IP Unit as an EtherNet/IP device, set an even number of bytes for the size of the network variable used for the EtherNet/IP connections regardless of an odd number of bytes for the tag size.



The CPU Unit memory is consumed in units of two bytes. To assign tags of odd numbers of bytes to network variables, specify even byte numbers (i.e., sizes of the tags + 1) to the network variables.

#### Data concurrency

To maintain concurrency in the values of network variables that are assigned to tags, you must set refreshing tasks.

Refer to 9-1-7 Concurrency of Tag Data Link Data on page 9-12 for details.

## Registering the Tag and Tag Set

Register the required tag and tag set for the EtherNet/IP connections.

You can register tags and tag sets in the EtherNet/IP Connection Setting Tab Page.




#### **Precautions for Correct Use**

Make the following settings to refresh all of the tag data in the same tag set at the same time.

- Use the Sysmac Studio, in advance, to specify the same refreshing task for all of the variables that are assigned to tags in the tag set.
- Do not place tag variables that have AT specifications in I/O memory and tag variables that do not have AT specifications in the same tag set.
- 1 Select EtherNet/IP Connection Settings from the Tools Menu.

The EtherNet/IP Device List Tab Page is displayed.

2 In this example, right-click EtherNet/IP Port Settings for the originator device and select Edit from the menu to open the EtherNet/IP Connection Setting Tab Page.



- 3 Click the (Show Tag Set Display) icon in the EtherNet/IP Connection Setting Tab Page.
- 4 Click the **Input** tab to switch to the **Input** Tab Page. Register the tag set and the tag. Use one of the following methods to register the tag set and the tag.
  - Independ 
     Manually registers network variables in the Controller as tags.
     ent registration
  - Batch regis- : Registers all network variables in the Controller as tags at the same time.
     tration
- **5** Register tags and tag sets independently.
  - 1) Right-click anywhere in the Input Tab Page of the EtherNet/IP Connection Setting Tab Page and select **Create New Tag Set** from the menu.
  - 2) Enter the tag set name, Net\_In1, directly into the list in the Input Tab Page.
  - 3) Right-click anywhere in the Input Tab Page and select Create New Tag from the menu.
  - 4) Enter tag name Net\_In1.





#### **Precautions for Correct Use**

Any name can be specified for the tag set if the name matches one of the registered network variable names in the Controller.

As you enter characters (or immediately after you press the Ctrl + Space Keys), the Sysmac Studio Entry Assistance provides a list of variable names registered in the Controller. Select the variable name from the list.



#### **Additional Information**


You can register up to 8 tags in a tag set. Set as shown below to register multiple tags. Examples:

	Tag set name	
▼	Network_Input_Value	(Tag set name)
	Net_In1	(Tag name)
	Net_In2	(Tag name)

**6** Register all tags and tag sets at the same time.

 Right-click anywhere on the Input Tab Page of the EtherNet/IP Connection Settings Tab Page and select Register All Tag Sets or click the Registration All Button to display the Tag Set Registration Setting Dialog Box.

This dialog box lists the variables that are registered in the Global Variable Table and also have the **Network Publish** attribute set to **Input** or **Output**.




- 2) Select the variable to register as a tag, and then click the **Register** Button.
- 3) The automatically registered tag is added to the list in the EtherNet/IP Connection Setting Tab Page.

With automatic registration, the tag is registered under a tag set having the same name as the tag, i.e., a single tag is registered in a single tag set.



**7** Set the following settings for the registered tag and tag set.



#### Setting for Tag Sets

Name	Item
Tag Set Name	Enter the tag set name.
	You can change the names as required.
Size (Byte)	Gives the total size of the tag in bytes.
Instance ID	Gives the instance ID.
	• Auto
	• IN_{min}IN_{max}
	{min} represents the minimum number of Produced Assembly identifica-
	tion numbers recorded in the EDS files for the relevant devices.
	{max} represents the maximum number of Produced Assembly identifica-
	tion numbers recorded in the EDS files for the relevant devices.
Controller Status	Specify whether to include the Controller status in the tag set.

#### · Setting for Tags

Name	ltem
Tag Name	Enter the tag name.
	Specify the tag name that matches one of the registered network variable
	names in the Controller.
Bit Selection	Specify whether to set the tag data size in bits.
	Selected: Set the size in bits.
	Not selected: Set the size in bytes.
Size (Byte)	Gives the size of the tag in bytes.
Size (Bit)	Gives the size of the tag in bits.
Output at Fatal Error	Specify whether to clear the output data or continue to send it when a ma-
	jor fault level Controller error occurs in the Controller.
	Retained
	Cleared

# **Setting Connections for the Originator Device**

After the tag set registration, set the connection settings for transferring data using the EtherNet/IP connections.

Make the connection settings in the originator device (i.e., Controller 1 in this example) only.

Register the tag and tag set for Controller 2 (Target device) before setting the connection settings as described in this example.

Refer to *Registering the Tag and Tag Set for the Target Device* on page A-25 for the operations for registering tags and tag sets.



#### **Precautions for Correct Use**


If you change the IP address, model, or revision of the target device after making the connection settings, you must also change the target device settings that are included in the connection settings.

For information on how to change the target device settings in the connection settings, refer to Changing the Target Device Settings after Making Connection Settings on page A-23.

- Select EtherNet/IP Connection Settings from the Tools Menu to display the EtherNet/IP Device List Tab Page.
- 2 Right-click EtherNet/IP Port Settings for Controller 1 (originator device in this example), and select Edit from the menu.


The EtherNet/IP Connection Settings Tab Page is displayed.

in the Variable Name column in the Toolbox.



- 3 Click the (Show Connection Display) icon in the EtherNet/IP Connection Setting Tab Page.
- Select NX-EIP201 from Target Device in the Toolbox on the right side of the EtherNet/IP Connection Settings Tab Page.
  When you select NX-EIP201, the target device tag set (Net\_Out1) for Controller 2 is displayed
- **5** Drag the target device tag set Net\_Out1 from the **Variable Name** column in the Toolbox to the Connection List.

As you enter characters (or immediately after you press the Ctrl + Space Keys), a list of target device variables that can be set for the connection is provided. Select the value from the list.



Specify Originator Variable and its Size [Byte] for the tag set Net\_Out1 added in step 5. Here, specify Net\_In1 for Originator Variable and 2 for its Size [Byte]. Change the other settings as required.

You can set the following items in the connection settings.

Name	Setting Methods
Target Device	Select the target device.
Connection Name	Any name can be given to the connection (32 single-byte characters max.).
Connection I/O Type	Input Only (Tag type) is selected if the EtherNet/IP connection is established on an NX-EIP201, CS1W-EIP21, CJ1W-EIP21, CJ2B-EIP21, CJ2M-EIP21, CJ1W-EIP21(CJ2), CJ1W-EIP21(NJ), NX701, NX102-□□□, NX1P2, NJ501-□□□, NJ301-□□□, or NJ101. When you create EtherNet/IP connection for another target device, select the connection I/O type specified in the device's EDS file. Use the Input Only (ID type) setting when the originator is a node from another manufacturer and does not support connection settings with a Tag type setting.
Input/Output	The connection's input/output is automatically displayed based on the selected connection.  Input Only: Just Input is displayed.
Target Variable	Select the target node's tag set to assign it.  Input is specified for Input/Output: Select the target's output (produce) tag set.  Output is specified for Input/Output: Select the target's input (consume) tag set.
Size [Byte]	The data sizes of the target variables are displayed.

Name	Setting Methods
Originator Variable	Select the originator node's tag set to assign it.  Input is specified for Input/Output: Select the originator's input (consume) tag set.  Output is specified for Input/Output: Select the originator's output (produce) tag set.
Size [Byte]	Enter the data sizes of the originator variables.
Connection Type	<ul> <li>Select whether the data is to be sent in the multicast or unicast (point-to-point) form. The default setting is multicast.</li> <li>Multi-cast connection: Select when the same data is to be shared by multiple nodes. This setting is usually used.</li> <li>Point-to-point connection: Select when the same data is not to be shared by multiple nodes.</li> <li>Since the data is sent in unicast transmission, other nodes are not burdened with unnecessary load.</li> <li>Note Refer to 9-1-4 Overview of Operation on page 9-7 for details on how to use multi-cast and unicast connections, and how to count the number of connections.</li> </ul>
RPI [ms]	Set the data update cycle (i.e., the packet interval) of each connection between the originator and target.  The default setting is 50 ms (i.e., data is updated once every 50 ms).
Timeout Value	Set the time until a connection timeout is detected.  The timeout value is set as a multiple of the packet interval (RPI) and can be set to 4, 8, 16, 32, 64, 128, 256, or 512 times the packet interval.  The default setting is RPI x 4.  The timeout value must be at least 10 ms.

The Toolbox displays the target devices if the devices are registered in the same Sysmac Studio project as where the originator devices are registered.

You can use one of the following methods to add unregistered devices in the same Sysmac Studio project as where the originator devices are registered to the Target Device List.

- Importing devices that are registered in another project
   You can import NJ/NX-series Controllers registered in another project data and add them to the Device List.
- Registering devices using user-specified settings
   You can manually add target devices to the device list.




#### **Additional Information**

You can add target devices to the Device List by installing EDS files that include connection information for the devices in the Sysmac Studio and register the devices to the project. Refer to *Adding EDS Files* on page A-22 for details.

- 8 Import devices that are registered in another project.
  - 1) Click the [IIII] (Import a device from another project) Button in the Toolbox on the right of the EtherNet/IP Connection Setting Tab Page.




2) The Import from Another Project Dialog Box is displayed. Click the **Project** Button, select a project to import and click the **Open** Button.



- 3) The list of EtherNet/IP devices registered in the selected project will be displayed. Select the target devices to import, and click the **Import** Button.
  - **Note** Only the project for which the EtherNet/IP connection settings are set will be displayed. The imported EtherNet/IP devices are added to the Target Device List in the Toolbox.



- **9** Register devices as required.
  - Click the + Button under the Target Device List in the Toolbox.
     The Add Target Device Pane is displayed.
  - 2) Enter relevant items for the target devices to add.



Menu	Description
Node address	Enter the target device IP address.
Model name	Select the target device model.
Revision	Select the revision of the target device.

3) Here, set the following items for Controller 3 and click the **Add** Button.

The target device is added to the Target Device List in the Toolbox.

Node address: 192.168.250.3 Model name: NX-EIP201


Revision: 2

4) You can click the **Import Tag Set** Button to import the tag sets that are set in the Network Configurator to the target devices.


Select **To/From File - Export to File** in the **Tag Sets** Tab Page of the **Edit Device Parameters** Dialog Box, and generate CSV files to import.

#### Adding EDS Files

1 Right-click anywhere in the Target Device List in the Toolbox of the EtherNet/IP Connection Setting Tab Page and select **Display EDS Library** from the menu.



**2** The EDS Library Dialog Box is displayed. Click the **Install** Button.



- **3** Select the EDS file to add, and then click the **Open** Button. The EDS file is added.
- 4 The EtherNet/IP device with the EDS file installed is added to the EDS Library.


  Devices listed in the EDS Library are used as a candidate device list when adding devices to the Target Device List in the Toolbox of the EtherNet/IP Connection Setting Tab Page.

# **Changing the Target Device Settings after Making Connection Settings**

If you change the IP address, model, or revision of the target device after making the connection settings, you must also change the target device settings that are included in the connection settings. You can change the target device settings entirely.


#### Changing the IP Addresses for All Target Devices

1 Right-click one of the connection lines and select **Change Node Address** from the menu.




The Node Address Change Dialog Box is displayed. Enter a new IP address in New IP address.

To apply the same change to other connections, select the **Apply the change to other connections** Check Box.



- To apply the same change to other connections, select the Apply the change to other connections Check Box.
- 4 Click the **OK** Button.
- Changing All Target Device Information including Model Names and Revisions
  - 1 Right-click one of the connection lines and select **Change Target Device** from the menu.
  - **2** The **Target Device Change** Dialog Box is displayed. Select a target device from **New device**.





#### **Precautions for Correct Use**

- Changeable target devices are limited to ones that have "OMRON" in the Vendor ID and is an EDS device of the Communications Adapter in the Device Type.
- To display a device in the list of selectable new target devices, the device must be registered as the target device in the Toolbox.


- 3 To apply the same change to other connections, select the Apply the change to other connections Check Box.
- 4 Click the **OK** Button.

## Registering the Network Variable for the Target Device

**1** Assign the network variable to the tag used for the EtherNet/IP connection for Controller 2 (target device).

This network variable stores data to send to Controller 1 (originator device).

Set the **Network Publish** attribute to **Input** or **Output** in the Global Variable Table for the variable so that the variable serves as a network variable, i.e., the variable can be used for the EtherNet/IP connections. In this example, set the network variable for Controller 1 as shown below.



Name: Net\_Out1Data type: WORD

· Network Publish attribute: Output


## Registering the Tag and Tag Set for the Target Device

Set the tag and tag set for the target device.


- 1 Select EtherNet/IP Connection Settings from the Tools Menu. The EtherNet/IP Device List Tab Page is displayed.
- Right-click NX-EIP201, the NX-series EtherNet/IP Unit connected to the Controller 2 (originator device in this example), and select Edit from the menu.

  The EtherNet/IB Connection Settings Teh Bage is displayed.

The EtherNet/IP Connection Settings Tab Page is displayed.



- 3 Click the (Show Tag Set Display) icon in the EtherNet/IP Connection Setting Tab Page.
- 4 Click the **Output** tab to switch to the **Output** Tab Page. Register the following tag and tag set. The tag and tag set can be registered in the same way as for the target device. (Refer to *Registering the Tag and Tag Set* on page A-14.)



## **Checking the Device Bandwidth Usage**

The bandwidth usage for the device can be displayed from the EtherNet/IP Connection Setting Tab Page.

This value is for when multicast filtering is used.




#### **Precautions for Correct Use**

In the Device Bandwidth Dialog Box, you can only check the bandwidth being used for the EtherNet/IP connections from one originator device to its target devices.

The actual bandwidth used for the EtherNet/IP network must be calculated by taking into account of all bandwidths used on the EtherNet/IP network (i.e., bandwidths used for connections for the other devices in the EtherNet/IP network than the one given on the dialog box must be included into the calculation).

#### Procedure

Click the **Device Bandwidth** Button in the EtherNet/IP Connection Setting Tab Page for the target device.



Menu	Description		
PPS	Gives the bandwidth used for each target device and total bandwidth used		
	for all target devices.		
Set Packet Interval (RPI) for	Changes all Packet Interval (RPI) values for all target devices.		
All Connections			




#### **Additional Information**

You can specify a value in **Set Packet Interval (RPI) for All Connections** and click the **Update** Button to change packet interval (RPI) values set in the connection settings for all target devices to the specified value.


#### Calculation Example for Bandwidth Used (PPS) for Each Device by the EtherNet/IP Connections


This section describes the case where the following three EtherNet/IP connections are established between NJ-series Controller 1 to 3, as an example of calculating the bandwidth used for each device by the EtherNet/IP connections.

Connection type	Relevant devices in the EtherNet/IP connections	Device bandwidth usage (PPS)
Connection (1)	NJ-series Controller 2 (target device)	50 pps
	to NJ-series Controller 1 (originator device)	
Connection (2)	NJ-series Controller 1 (target device)	10 pps
	to NJ-series Controller 2 (originator device)	
Connection (3)	NJ-series Controller 3 (target device)	210 pps
	to NJ-series Controller 1 (originator device)	



Bandwidth used (PPS) for each EtherNet/IP device is as given below.





#### EtherNet/IP connection settings for Controller 1

EtherNet/IP connection settings for Controller 2

In this example, the PPS for Connection (1) is 50 pps, the PPS for Connection (2) is 10 pps, and the PPS for Connection (3) is 210 pps. Therefore, bandwidth used (PPS) for each EtherNet/IP device is as given below.

192.168.250.1: 270 pps = 50 pps (for Connection (1)) + 10 pps (for Connection (2)) + 210 pps (for Connection (3))

192.168.250.2: 60 pps = 50 pps (for Connection (1)) + 10 pps (for Connection (2))

192.168.250.3: 210 pps = 210 pps (for Connection (3))

#### Adjusting Method

If the calculation result value exceeds the values in the specifications of the devices used in the EtherNet/IP connections, re-evaluate the overall network configuration and correct it by taking steps such as selecting a different Ethernet switch or splitting the network.

If the RPI is made longer, the PPS for the EtherNet/IP connections will decrease.

You can change the RPI values in the connection settings for all the target devices by specifying a value in **Set Packet Interval (RPI) for All Connections** in this dialog box.

Refer to 12-2-2 Tag Data Link Bandwidth Usage and RPI on page 12-9 for the relationship between the PPS for the device and the RPI.

# **Transferring the Connection Settings Data**

You can synchronize and transfer EtherNet/IP connection settings along with the program data. You can also transfer all the EtherNet/IP connection settings along with the program data.




#### **Precautions for Correct Use**

- If the node addresses (IP addresses) are not set correctly, you may connect to the wrong Controller and set incorrect device parameters. Download data only after you confirm that you are connected to the correct Controller.
- If incorrect connection settings are set, it may cause equipment to operate unpredictably.
   Even when the correct connection settings are set, make sure that there will be no effect on equipment before you transfer the data.
- A connection error will result if the network variables that are used in the tag settings are not set in the Controller. Before downloading the connection settings, check to confirm that the network variables used in the tag settings are set in the Controller.
- If a communications error occurs, the output status depends on the specifications of the device being used. When a communications error occurs for a device that is used along with output devices, check the operating specifications and implement safety countermeasures.
- The EtherNet/IP port and the port on the EtherNet/IP Unit are automatically restarted after the
  parameters are downloaded. This restart is required to enable the tag set and connection information. Before you download the parameters, check to confirm that problems will not occur
  with the equipment when the port is restarted.
- Do not disconnect the Ethernet cable or reset or turn OFF the power to the EtherNet/IP Unit during the parameter download.
- The EtherNet/IP connections between relevant nodes is stopped during a download. Before
  you download data in RUN mode, make sure that it will not affect the controlled system.
  Also implement interlocks on data processing in ladder programming that uses EtherNet/IP
  connections when the connections are stopped or a connection error occurs.
- In the EtherNet/IP network, if the device bandwidth usage (PPS) exceeds the unit's allowable bandwidth (PPS), the EtherNet/IP connection operations may not agree with the settings.
   If you increase the RPI value in such a case, there are cases when the problem can be resolved (i.e., the operations agree the settings).


#### Synchronizing/Transferring a Whole Project

1 Establish an online connection between the computer and the Controller, and then select Synchronization from the Controller Menu. (Or, click the Button on the Toolbar.)



The Synchronization Window is displayed, and comparison of the user program and parameter settings between the Sysmac Studio and the Controller is started.

**2** The following Uploading and Downloading Data Window is displayed after the automatic comparison.



3 Clear the Do not transfer the EtherNet/IP connection settings (i.e., tag data link settings)
Check Box and then click the Transfer To Controller Button.
Then the EtherNet/IP connection settings are transferred along with the not-synchronized data.
If no EtherNet/IP connection settings are set in the Sysmac Studio, no data will be sent.

#### Transferring all data

- 1 Establish an online connection between the computer and the Controller and then select

  Transfer To Controller from the Controller Menu. (Or, click the Button on the Toolbar.)
- 2 The Transfer to Controller Dialog Box is displayed.

  Clear the selection of the Do not transfer the EtherNet/IP connection settings (i.e., tag data link settings) Check Box, and then click the Execute Button.



#### **Precautions for Correct Use**

To transfer only the connection settings, execute Transfer from the EtherNet/IP Connection Setting Tab Page.

Even if you clear the **Do not transfer the connection setting** Check Box, the connection settings are not transferred from the Synchronization Window, the **Transfer to Controller** Dialog Box, or the **Transfer from Controller** Dialog Box as long as the data in the computer is synchronized with the data in the Controller.




#### Transferring Only the EtherNet/IP Connection Settings

You can transfer tag sets and connections to the EtherNet/IP devices.

- **1** Establish an online connection with the Controller.
- Click the Transfer to Controller or Transfer from Controller Button in the EtherNet/IP Connection Setting Tab Page.

The tag settings and connection settings set at that time are transferred to the Controller connected online.


**3** If the Controller connected online is in RUN mode, the dialog box to confirm whether to switch to PROGRAM mode before transferring the settings is displayed.



#### Comparison

The differences in the tag set and connection settings between the project and the EtherNet/IP devices can be displayed.

1 Click the Compare Button in the EtherNet/IP Connection Setting Tab Page.



### Starting and Stopping EtherNet/IP Connections

#### Automatically Starting EtherNet/IP Connections

The EtherNet/IP device is automatically restarted and EtherNet/IP connections are automatically started immediately after the connection settings are downloaded from the Sysmac Studio.



#### **Precautions for Correct Use**

Connections are adversely cut off if any of the following errors occurs in the CPU Unit that is the originator while EtherNet/IP connections are active.

- · Major fault level Controller error
- · Partial fault level Controller error

#### Starting and Stopping the EtherNet/IP Connections for the Entire Network

You can start and stop EtherNet/IP connections from the user program or from the Sysmac Studio.



#### **Precautions for Correct Use**

Use the same method (i.e., either the user program or the tool software) to both start and stop EtherNet/IP connections.

For example, if you use the *\_EIP\_TDLinkStopCmd* (Tag Data Link Communications Stop Switch) system-defined variable to stop EtherNet/IP connections, you cannot start them from the Sysmac Studio and the Network Configurator.

# A-3-5 Checking Communications Status with the Sysmac Studio and Troubleshooting

You can monitor the communications status of the EtherNet/IP connections after their settings are set. You can also check errors.



#### **Precautions for Correct Use**


Make sure that the connection settings in both the Sysmac Studio and the Controller are consistent before using the monitor functions. You can use the *Comparison* on page A-31 to see if they are the same.

#### **Checking Communications Status with the Sysmac Studio**

You can check the communications status on the EtherNet/IP connections in the EtherNet/IP Connection Monitor Tab Page.

- 1 Select EtherNet/IP Connection Settings from the Tools Menu to display the EtherNet/IP Device List Tab Page.
- 2 Right-click the Controller for which you want to check the communications status, and select **Monitor** from the menu.


The EtherNet/IP Connection Monitor Tab Page is displayed. In the EtherNet/IP Connection Monitor Tab Page, each communications status is displayed in six tabs.



- **3** Select one of the six tabs for which you want to confirm the communications status.
- · Status Tab Page


This tab page gives the TRUE/FALSE status of the system-defined variables that monitors the tag data link status and communication status for errors. If any of the variables is TRUE, its checkbox is marked with ...

Refer to 14-6-1 The Network Configurator's Device Monitor Function on page 14-47 for details on each status item.



#### • Connection Status Tab Page


Current status of each connection is given.



Name	Description
Connection Name	Gives the current status of each connection with the following text colors.
	Blue: Normal
	Red: There is at least one connection that has not been established.
	Gray: There are no connections or the connection operation is stopped.
Туре	Gives the connection type.
Status	Gives the current status on each connection with codes.
	Normal operation: 00:0000
	Abnormal operation: Gives an error code.
	This information can be used to identify the cause of EtherNet/IP connec-
	tion errors. Refer to 14-6-2 Connection Status Codes and Troubleshooting
	on page 14-55 for details on the connection status.

#### Tag Status Tab Page

This tab page gives if the tag settings for each tag for EtherNet/IP connections are set so that data can be exchanged with target devices.




Name	Description
Tag Name	The current status of each tag is indicated by its color.
	Red: Tag name resolution error
	Blue: Tag name resolution normal
	Gray: Not yet transferred (no information in device).

Name	Description
Input/Output	Gives the type of the tag.
Status	<ul> <li>The following status is displayed depending on the status that is set.</li> <li>Normally resolved: Normal data exchange is possible.</li> <li>Different sizes: Different sizes are set for the network variables and the tag settings.</li> </ul>
	<ul> <li>A connection will not be established for a tag for which this error occurs.</li> <li>No tag: A network variable is not set in the variable table in the CPU Unit for the specified tag setting. Or, instead of a member of union variable, unions are specified.</li> <li>A connection will not be established for a tag for which this error occurs.</li> <li>Attribute error: The following two factors cause this error.</li> </ul>
	Writing is not possible for constant attributes.
	<ol> <li>The I/O direction that is set in the tag data link settings does not agree with the I/O direction of the variable in the CPU Unit. There is an error in the setting of a Network Publish attribute for a CPU Unit variable.</li> <li>A connection will not be established for a tag for which this error occurs.</li> </ol>

#### Output Tag Set and Input Tag Set Tab Pages

You can monitor the status of each input/output tag set that is used for the EtherNet/IP connections. Click ▼ of each tag to display its detailed information.



Name	Description
Tag Set Name	Gives the connection status.
	If there is a connection error, "Not connected or error" is given.
Tag set size	Gives the size of the tag set in bytes.
Connected time	Gives the total connection duration in milliseconds.
Unconnected time	Gives the total disconnection duration in milliseconds.
Number of connections (in the	Gives the number of connections.
Output Tag Set Tab Page)	
Number of connected origina-	Gives the number of the connected originator devices.
tors (in the Output Tag Set	
Tab Page)	


Name	Description
Originator list (in the <b>Output Tag Set</b> Tab Page), Target list (in the <b>Input Tag Set</b> Tab  Page)	Gives the detailed information of the connected originators.
Originator name (in the  Output Tag Set Tab Page), or Target name (in the  Input Tag Set Tab Page)	Gives no information.
IP address (in the Output Tag Set Tab Page), or Re- mote IP address (in the Input Tag Set Tab Page)	Gives the IP addresses allocated for the originators.
Connected time (in the Output Tag Set Tab Page)	Gives the total duration of connection with the originator in milliseconds.
Unconnected time (in the Output Tag Set Tab Page)	Gives the total duration of disconnection with the originator in milliseconds.
Destination IP address (in the <b>Output Tag Set</b> Tab Page)	Gives the destination IP addresses. If the multi-cast connections are used, its own multi-cast address is displayed.
O->T RPI (packet interval)	Gives the RPI of connection from the originator to the target in milliseconds.
T->O Heartbeat transmis- sion cycle (ms)	Gives the heartbeat transmission period of the connections from the target to the originator in milliseconds.
O->T Timeout	Gives the timeout time for the connections from the originator to the target in milliseconds.
T->O Timeout	Gives the timeout time for the connections from the target to the originator in milliseconds.
O -> T API (actual packet interval)	Gives the RPI of connection from the originator to the target in milliseconds.
T->O Actual heartbeat transmission cycle (ms)	Gives the actual heartbeat transmission period of the connections from the target to the originator in milliseconds.
O->T Connection ID	Gives the connection identification for the connections from the originator to the target in hexadecimal.
T->O Connection ID	Gives the connection identification for the connections from the target to the originator in hexadecimal.

#### • Ethernet Information Tab Page

This tab page displays the communications status at the communications driver level of the Ethernet/IP port.

The error counter information can be used to confirm whether communications problems have occurred.

Under the Tag Data Link, you can confirm characteristics such as the bandwidth usage (PPS).



Display example for an NJ-series CPU Unit

#### A-3-6 Troubleshooting

In the case that there is a setting error or a communications error in the EtherNet/IP networks, the Sysmac Studio displays the error in the Troubleshooting Dialog Box.

Refer to the *NJ/NX-series Troubleshooting Manual (Cat. No. W503)* for how to identify errors and details on errors.

## Troubleshooting When Transferring and Monitoring the EtherNet/IP Connection Settings Fail


The first time you establish an online connection between the Controller and the computer that runs the Sysmac Studio with Windows Firewall on the computer enabled, a dialog box may be displayed to confirm the connection. If that occurs, select **Allow access**.

If you select other than **Allow access**, transferring and monitoring the EtherNet/IP connection settings may not be properly performed even if the online connection is successfully established between the Sysmac Studio and the Controller.


If the above problem occurs, take the following corrective method 1 or 2.

#### Problems

The connection setting data cannot be transferred.



Monitoring cannot be performed
 Monitor results in the EtherNet/IP Connection Monitor Tab Page remain as "---".




#### **Method 1: Disabling Windows Firewall Settings**


1 Open the Control Panel from the Windows Start Menu and then select Windows Firewall icon

The Windows Firewall Dialog Box is displayed.

- 2 Select Turn Windows Firewall On or Off.
  The Customize Settings Dialog box is displayed.
- 3 Clear the Block all incoming connections, including those in the list of allowed programs
  Check Box and click the **OK** Button.



- 4 Select the Advanced Tab in the Windows Firewall Dialog Box.
  The Windows Firewall with Advanced Security Dialog Box is displayed.
- Click Inbound Rules in the left pane and then double-click SysmacX86Server in the Inbound Rules list for Sysmac Studio version 1.31 or higher. For Sysmac Studio lower than version 1.31, double-click Sysmac Studio.
  If you double-click SysmacX86Server, the SysmacX86Server Properties Dialog Box appears. If you double-click Sysmac Studio, the Sysmac Studio Properties Dialog Box is dis-



- **6** For Sysmac Studio version 1.31 or higher, make the following settings in the **SyamacX86Server Properties** Dialog Box. If Sysmac Studio version is lower than 1.31, make the following settings in the **Syamac Studio Properties** Dialog Box.
  - If the Public Check Box under Profiles is not selected in the Advanced Tab Page, select it.
  - If the Enabled Check Box under General is not selected in the General Tab Page, select it.
  - Select Allow the connection under Action in the General Tab Page.

played.




#### **Precautions for Correct Use**

The main function of the firewall is to prevent illegal access from external sources (e.g., the Internet).

The purpose of changing the firewall settings through this procedure is to connect the Sysmac Studio to an NJ/NX-series Controller. If your computer is connected to an in-house network, make such changes only after confirming that they have no security impact on the network.

#### Method 2: Selecting the Use Option for the CIP Message Server

- **1** Connect the Sysmac Studio to the Controller.
- 2 Select Configurations and Setup CPU/Expansion Racks CPU Rack: X Bus Unit No.: NX-EIP201 () EtherNet/IP Port Settings CIP Settings.
- 3 Change the setting to select the Use Option for CIP Message Server.



# Method 3: Configuring Packet Filter Settings to Allow Packets Used by Sysmac Studio's EtherNet/IP Connection Settings

- **1** Connect the Sysmac Studio to the Controllers.
- 2 Select Configurations and Setup CPU/Expansion Racks CPU Rack: X Bus Unit No.: NX-EIP201 () EtherNet/IP Port Settings TCP/IP Settings.
- **3** Enter the settings for **Packet Filter** to allow packets used by Sysmac Studio's EtherNet/IP connection settings. Refer to *Packet Filter* on page 7-7 for detailed settings.

#### Method 4: Cycling the Power Supply to the Controller

Cycle the power supply to the NJ/NX-series Controller and transfer/monitor the EtherNet/IP connections settings again.

**Note** You may need to cycle the power supply when reflecting the changes in the IP address of the EtherNet/IP port or executing Transfer to the Controller.

### A-4 EDS File Management

This section describes the EDS file management on the Network Configurator.



#### **Precautions for Correct Use**


We recommend that you select **Run as administrator** to start the Network Configurator for operations with EDS files.

If you do not select **Run as administrator**, the following condition will result according to Windows user management for security purposes.

The following operations are not valid if you log in with another user account, and you need to restart the Network Configurator again: **Install**, **Create**, **Delete**, and **Create EDS Index File** under **EDS File**.

When you start the Network Configrator, select Run as administrator as below.

- 1. Select the Network Configurator from the Start Menu, and then right-click.
- 2. Select Run as administrator from the displayed pop-up menu.



#### A-4-1 Installing EDS Files

#### **EDS File - Install**

The Network Configurator can support new devices if the proper EDS files are installed. To install the EDS file, use the following procedure.

- 1 Select EDS File Install.
  The Install EDS File Dialog Box is displayed.
- 2 Select the EDS file to install, and click the **Open** Button.

Next, select the icon file (\*.ico). The EDS file is added to the Hardware List as a new device. If the hardware already exists, the new Hardware List will overwrite the previous one. If the hardware has different versions, each hardware version is added to the Hardware List.

#### A-4-2 Creating EDS Files

#### **EDS File - Create**

The EDS files are required for the Network Configurator to create a network configuration. To create an EDS file, use the following procedure.

- 1 Select EDS File Create.
- 2 Set the device information. You can obtain the device information from the device on the network if it is online.
- **3** The device is added to the Hardware List as a new device, just like when you install an EDS file.



#### **Additional Information**


You cannot set device parameters when you create an EDS file with the Network Configurator. Obtain a proper EDS file from the manufacturer of the device to make device parameter settings for the device.

#### A-4-3 Deleting EDS Files

#### **EDS File - Delete**

To delete an EDS file, use the following procedure.

- **1** Select the device from the Hardware List.
- 2 Select EDS File Delete.
  The following confirmation dialog box is displayed.



**3** Click the **Yes** Button.

The selected device is deleted from the Hardware List together with the EDS file.

#### A-4-4 Saving EDS Files

#### **EDS File - Save**

To save the EDS file, use the following procedure.

- 1 Select the target hardware device in the Hardware List, and then select EDS File Save.
- 2 A Save EDS File Dialog Box is displayed.
- **3** Input the folder and file names and click the **Save** Button. The EDS file is saved.

#### A-4-5 Searching EDS Files

#### **EDS File - Find**

To search the devices in the Hardware List for EDS files, use the following procedure.

Select EDS File - Find.
The following dialog box is displayed.



- 2 Input the character string to search for, and click the **Find Next** Button.
- **3** If a matching device is found, the cursor moves to the position of the device.
- **4** To quit the search operation, click the **Cancel** Button.



#### **Additional Information**


- The search is performed for the device on which the cursor stays and subsequent ones in the Hardware List.
- To search all the devices, select *Hardware* in the Hardware List before you perform the search.

#### A-4-6 Displaying EDS File Properties

#### **EDS File - Property**

To display the properties of the EDS file, use the following procedure.

- **1** Select the desired hardware (device) from the Hardware List.
- 2 Select EDS File Property.
  The following dialog box is displayed.



The time and date when the EDS file was created is displayed, along with the device information.

#### A-4-7 Creating EDS Index Files

#### **EDS File - Create EDS Index File**

When an EDS file is manually added or when a device is not correctly indicated in the Hardware List, use the following procedure to recreate the EDS index file.

(This applies to Network Configurator version 3.30 or higher.)

- 1 Select EDS File Create EDS Index File.
- **2** Restart the Network Configurator.

# A-5 Precautions for Using the Network Configurator on Windows XP, Windows Vista, or Windows 7 or Higher

Better firewall security for Windows XP (SP2 or higher), Windows Vista, and Windows 7 or higher has increased the restrictions for data communications. Before connecting the Network Configurator and an NJ/NX-series CPU Unit and starting communications through the following procedures, you may need to change the settings of the Windows firewall as described in this section.

- If you select Option Select Interface Ethernet I/F.
- If you select Option Select Interface NJ/NX Series Ethernet Direct I/F.
- If you select Option Select Interface NJ/NX Series USB Port.



#### **Precautions for Correct Use**

The main function of the firewall is to prevent illegal access from external sources (e.g., the Internet). The purpose of changing the firewall settings through this procedure is to connect the Network Configurator to an NJ/NX-series CPU Unit. If your computer is connected to an inhouse network, make such changes only after confirming that they have no security impact on the network

#### A-5-1 Changing Windows Firewall Settings

#### Windows XP

- 1 When you attempt to connect to the NJ/NX-series CPU Unit from the Network Configurator, the Windows Security Alert Dialog Box is displayed.
- Click the **Unblock** Button.

  This allows USB connection and EtherNet/IP connection to the Network Configurator, and you will be able to connect to the NJ/NX-series CPU Unit via the Network Configurator.

#### Windows Vista or Windows 7 or Higher


Use the following procedure to change the settings.

Always perform steps 1 to 6 if you cannot go online. The **User Account Control** Dialog Box may be displayed during this procedure. If it appears, click the **Continue** Button and continue with the procedure.


Select Control Panel from the Windows Start Menu, and select Classic View to change the view.




2 Open Administrative Tools, and select Windows Firewall with Advanced Security in the displayed dialog box.



3 Select Inbound Rules under Windows Firewall with Advanced Security on Local Computer on the left side of the Windows Firewall with Advanced Security Dialog Box.



4 Select New Rule under Inbound Rules in the Actions Area on the right side of the dialog box.




**5** Follow the steps below to make the settings in the **New Inbound Rule Wizard** Dialog Box. Select the specified option at each step, and click the **Next** Button to move to the next step.

Rule Type	Select Custom.
Program	Select All Programs.
Protocol and support	Select ICMPv4 as the protocol type.
	Protocol type: ICMPv4  Protocol number: 1
Scope	Select Any IP address for all.
Action	Select Allow the connection.
Profile	Select Domain, Private, and Public.
Name	Enter an arbitrary name (e.g., Omron_EIP).

6 Click the **Finish** Button. The rule that you defined (i.e., Omron\_EIP) is registered in the list of **Inbound Rules**.

Close the Windows Firewall with Advanced Security Dialog Box.



- When you attempt to connect to the NJ/NX-series CPU Unit from the Network Configurator, the Windows Security Alert Dialog Box is displayed.
- 8 Click the Allow access Button.



(On Windows 7) This allows USB connection and EtherNet/IP connection to the Network Configurator, and you will be able to connect to the NJ/NX-series CPU Unit via the Network Configurator.

# A-6 Tag Data Link Settings with Generic Devices

Use the Generic Device if you want to perform tag data links with a device that does not have an EDS file

Create a Generic Device with the Network Configurator to use a Generic Device.

The procedures to create a Generic Device and the procedures to create a tag or tag set are shown below.



#### **Additional Information**

The procedures after creating a tag or tag set are the same as for devices that have EDS files. Refer to *9-2 Setting Tag Data Links* on page 9-15.

#### A-6-1 Creating Generic Devices


Select Create Generic Device from the EDS File Menu. The Create Generic device EDS Dialog Box is displayed.




2 Set the information for the device and click the **Create** Button. A confirmation dialog to install an icon is displayed.



- **3** Set a device icon.
  - If you click the Yes Button:
     The Install Icon (EDS file name) Dialog Box is displayed.



- If you click the No Button:
   A default icon for the Network Configurator is set.
- **4** Select the icon file (\*.ico) to set as the EDS file and click the **Open** Button. The created Generic Device is added to the hardware list.




#### A-6-2 Creating a Tag or Tag Set for Generic Device

This section describes two types of methods for creating a tag or tag set: tag type and instance ID type. Each procedure is described below.

The type is what you select in Connection I/O Type when you create a Generic Device.


#### **Creation Procedure for Tag Type**

- **1** Add the Generic Device that you created to the network window.
- 2 Double-click the device icon.
  The Edit Device Parameters Dialog Box is displayed.



3 Select the slot number 00 in the Configuration from the Module Tab Page and then click the Edit Button.

The Edit Module Parameters Dialog Box is displayed.



4 Select Input Only (Tag type) or Input & Output (Tag type) from Type and click the New Button.

The Edit Variable Dialog Box is displayed.




- **5** Set the following parameters for the variable.
  - Name

Enter the name of the network variable. (Example: VarInputOnly)

- Size
  - Enter the size of the tag in bytes.
- I/O Type

If Type is Input & Output (Tag type), select Out or In.


Click the OK Button.
The Edit Module Parameters Dialog Box is displayed, and the added variable is displayed.



**7** Repeat steps 4 through 6 to register the required variables. Click the **OK** Button when the registration is complete.

#### **Creation Procedure for Instance ID Type**

- **1** Add the Generic Device that you created to the network window.
- 2 Double-click the device icon.
  The Edit Device Parameters Dialog Box is displayed.



**3** Click the **New** Button from the **I/O Configuration** Tab Page. The **Edit I/O Instance** Dialog Box is displayed.



- **4** Enter the following parameters.
  - · Instance No.

Enter the instance ID for the I/O instance.

Size


Enter the size of the tag in bytes.

• I/O Type
Select Out or In.



**5** Click the **OK** Button.

The **Edit Device Parameters** Dialog Box is displayed, and the added I/O instance is displayed in the **I/O Configuration** Tab Page.



**6** Repeat steps 3 through 5 to register the required I/O instances. Click the **OK** Button when the registration is complete.

# A-7 TCP/UDP Port Numbers Used for the NX-series EtherNet/IP Unit

The following table shows the applications that the NX-series EtherNet/IP Unit uses TCP/UDP ports, port numbers, port types, protocols used, default port states, usages, and how to change a port from open to close.


TCP/UDP ports (servers) other than those shown below are not used.

Application	UDP port num- ber	TCP port num- ber	Port type	Protocol used	Default port state	Usage	How to change from open to close
SSH/SFTP		22	System port	SSH/SFTP	Close	For maintenance	
DNS client	53		System port	DNS	Close	Used when using the DNS client.	
X Bus <sup>*1</sup>	67		System port	DHCP	Close	Used for communica- tions with the CPU	
	520		System port	RIP*2		Unit.	
	44819		User port	CIP			
		9910	User port	TCP (OMRON protocol)			
BOOTP client	68		System port	воотр	Close	Used when using the BOOTP client.	
HTTP server		80	System port	HTTP	Close	Used for communications with the Sysmac Studio.	
SNMP	161		System port	SNMP (SNMPv1,	Close	Used when using the SNMP agent.	
SNMP trap	162		System port	SNMPv2C)	Close	Used when using the SNMP trap.	
HTTPS server		443	System port	HTTPS	Open	Used for communications with the Sysmac Studio.	Use the Packet Filter. *3
EtherNet/IP tag data links	2222		User	CIP	Open	Used for the EtherNet/IP tag data links.	On the Sysmac Studio, select EtherNet/IP Port Settings - CIP Settings, and then select Do not use for CIP Message Server.
Sysmac Studio	9600		User port	OMRON protocol	Open	Used for communications with the Sysmac Studio.	Use the Packet Filter. *4

Application	UDP port num- ber	TCP port num- ber	Port type	Protocol used	Default port state	Usage	How to change from open to close
CIP messages	44818	44818	User port	CIP	Open	Used for the CIP messages.	On the Sysmac Studio, select EtherNet/IP Port Settings - CIP Settings, and then select Do not use for CIP Message Server.

<sup>1.</sup> The TCP/UDP port used for communications between the CPU Unit and the NX-series EtherNet/IP Unit via the X Bus. It cannot be used by a user.

- \*2. An abbreviation for Routing Information Protocol. RIP is a protocol used to exchange route information between communications devices such as routers in order to find the shortest distance from one point to another point in the network.
- \*3. Closing the port may prevent communications with the Sysmac Studio and the NA-series HMI. Refer to Troubleshooting when support software cannot go online in the NJ/NX-series Troubleshooting Manual (Cat. No. W503) on how to make corrections.
- \*4. Closing the port may prevent communications with the Sysmac Studio. Refer to *Troubleshooting When You Cannot Go Online from the Sysmac Studio* in the *NJ/NX-series Troubleshooting Manual (Cat. No. W503)* on how to make corrections.



# Index

### Index

A	CIP Communications2 Identity Error6-9, 6-22
	CIP Communications2 Normal Target Node Information
address	
adjusting device bandwidth usage12-10	CIP Communications2 Registered Target Node Information.
adjusting the communications load	
array variables for inputting and outputting service data and	CIP Communications2 Tag Data Link Communications Error
response data	6-9, 6-23
Assumed cause	CIP Communications2 Tag Data Link Communications Sta
Attached information14-15	tus
Auto Connection Configuration9-40	CIP Communications2 Tag Data Link Connection Failed
automatically setting connections9-39	6-9, 6-23
automatically starting tag data links9-61	CIP Communications2 Tag Data Link Setting Error. 6-9, 6-22
В	CIP Communications2 Tag Name Resolution Error
B	6-10, 6-24
	CIP Communications2 Target Node Error Information
BOOTP client1-11	6-14, 6-28
C	CIP Communications2 Target PLC Error Information
	6-13, 6-27
calculating the number of connections	CIP Communications2 Target PLC Operating Mode
changing devices	6-13, 6-27
changing the RPI	CIP message communications service specifications 10-2
changing Windows firewall settings	CIP message server
checking bandwidth usage for tag data links12-8	CIP Settings Display
checking connections	CIPClose
checking the current IP address8-8	CIPOpen
CIDR	CIPOpenWithDataSize10-4
CIP communications	CIPSend
CIP Communications Error6-8, 6-21	CIPUCMMSend
CIP communications instructions	clearing device parameters
CIP Communications1 All Tag Data Link Communications	client function of CIP message communications 10-3
Status	Communications Port Error
CIP Communications1 Error6-8, 6-21	Communications Port1 Error
CIP Communications1 Identity Error6-8, 6-21	Communications Port2 Error6-6, 6-17
CIP Communications1 Normal Target Node Information	community name
6-12, 6-26	Connection I/O Type
CIP Communications1 Registered Target Node Information	Connection Name
6-12, 6-25	connection settings
CIP Communications1 Tag Data Link Communications Error	editing all connections9-36 editing individual connections9-39
6-9, 6-23	Register Device List9-32
CIP Communications1 Tag Data Link Communications Sta-	connection status codes and troubleshooting
tus	Connection Tab Page14-5
CIP Communications1 Tag Data Link Connection Failed	Connection Type
6-9, 6-22	Controller Log Tab Page14-52
CIP Communications1 Tag Data Link Setting Error. 6-9, 6-22	Controller status9-10
CIP Communications1 Tag Name Resolution Error	Correction
6-10, 6-23	creating tags and tag sets9-19
CIP Communications1 Target Node Error Information	Creating tags and tag sets9-18
6-14, 6-28	D
CIP Communications1 Target PLC Error Information	
6-13, 6-27	default gateway7-3
CIP Communications1 Target PLC Operating Mode	destination address
6-12, 6-26	destination IP address
CIP Communications2 All Tag Data Link Communications	destination mask IP address
Status6-11, 6-25	detailed descriptions of MIB objects11-5
CIP Communications2 Error6-8, 6-21	•

Detection timing14-14	EIP_Comm2Status.TDLinkCfgErr (CIP Communications2
Device Connection Structure Tree9-41	Tag Data Link Setting Error) 6-9, 6-22
Device Monitor14-47	EIP_Comm2Status.TDLinkErr (CIP Communications2 Tag
device variables6-2	Data Link Communications Error)6-9, 6-23
displaying device status9-72	EIP_Comm2Status.TDLinkOpnErr (CIP Communications2
DNS	Tag Data Link Connection Failed)6-9, 6-23
DNS Setting Error6-7, 6-20	EIP_Comm2Status.TDLinkRunSta (CIP Communications2
domain names7-4	Tag Data Link Communications Status)6-11, 6-25
	EIP_ErrSta (CIP Communications Error)6-8, 6-21
E	Ethernet connectors
	Ethernet Information Tab Page14-54
EDS file management A-43	Ethernet Link Object10-35
EIP_Comm1Status.CipErr (CIP Communications1 Error)	Ethernet switch
6-8, 6-21	types5-3
EIP_Comm1Status.EstbTargetSta (CIP Communications1	Ethernet switches
Normal Target Node Information) 6-12, 6-26	connection methods5-11
EIP_Comm1Status.IdentityErr (CIP Communications1 Iden-	functions5-3
tity Error)6-8, 6-21	installation precautions5-11
EIP_Comm1Status.RegTargetSta (CIP Communications1	selection precautions5-4
Registered Target Node Information)6-12, 6-25	EtherNet/IP port settings7-1
EIP_Comm1Status.TagAdrErr (CIP Communications1 Tag	ETN_DNSCfgErr (DNS Setting Error)6-7, 6-20
Name Resolution Error)6-10, 6-23	ETN_ErrSta (Communications Port Error) 6-5, 6-16
EIP_Comm1Status.TargetNodeErr (CIP Communications1	ETN_IPRTblErr (IP Router Table Setting Error) 6-7, 6-20
Target Node Error Information)6-14, 6-28	ETN_Port1Status.BootpErr (Port1 BOOTP Server Error)
EIP_Comm1Status.TargetPLCErr (CIP Communications1	6-7, 6-20
Target PLC Error Information)6-13, 6-27	ETN_Port1Status.EtnCfgErr (Port1 Basic Ethernet Setting
EIP_Comm1Status.TargetPLCModeSta (CIP Communica-	Error)6-6, 6-18
tions1 Target PLC Operating Mode)6-12, 6-26	ETN_Port1Status.EtnOnlineSta (Port1 Online) 6-11, 6-24
EIP_Comm1Status.TDLinkAllRunSta (CIP Communica-	ETN_Port1Status.IPAdrCfgErr (Port1 IP Address Setting Er-
tions1 All Tag Data Link Communications Status)	ror)6-7, 6-19
	ETN_Port1Status.IPAdrDupErr (Port1 IP Address Duplica-
EIP_Comm1Status.TDLinkCfgErr (CIP Communications1	tion Error)6-7, 6-19
Tag Data Link Setting Error)	ETN_Port1Status.LanHwErr (Port1 Communications Con-
EIP_Comm1Status.TDLinkErr (CIP Communications1 Tag	troller Error)6-6, 6-18
Data Link Communications Error)6-9, 6-23	ETN_Port1Status.MacAdrErr (Port1 MAC Address Error)
EIP_Comm1Status.TDLinkOpnErr (CIP Communications1	6-6, 6-17
Tag Data Link Connection Failed)6-9, 6-22	ETN_Port1Status.PortErr (Communications Port1 Error)
EIP_Comm1Status.TDLinkRunSta (CIP Communications1	6-5, 6-17
Tag Data Link Communications Status)6-11, 6-24	ETN_Port2Status.BootpErr (Port2 BOOTP Server Error)
EIP_Comm2Status.CipErr (CIP Communications2 Error)6-8, 6-21	6-7, 6-20
EIP_Comm2Status.EstbTargetSta (CIP Communications2	ETN_Port2Status.EtnCfgErr (Port2 Basic Ethernet Setting
Normal Target Node Information) 6-12, 6-26	Error)
EIP_Comm2Status.IdentityErr (CIP Communications2 Iden-	ETN_Port2Status.EtnOnlineSta (Port2 Online) 6-11, 6-24
tity Error)6-9, 6-22	ETN_Port2Status.IPAdrCfgErr (Port2 IP Address Setting Error)6-7, 6-19
EIP_Comm2Status.RegTargetSta (CIP Communications2	ETN Port2Status.IPAdrDupErr (Port2 IP Address Duplica-
Registered Target Node Information)6-12, 6-26	= : ;
EIP_Comm2Status.TagAdrErr (CIP Communications2 Tag	tion Error)6-7, 6-19 ETN Port2Status.LanHwErr (Port2 Communications Con-
Name Resolution Error)6-10, 6-24	troller Error)6-6, 6-18
EIP_Comm2Status.TargetNodeErr (CIP Communications2	ETN_Port2Status.MacAdrErr (Port2 MAC Address Error)
Target Node Error Information)6-14, 6-28	ETN_PORZStatus.MacAdrerr (Portz MAC Address Error)
EIP_Comm2Status.TargetPLCErr (CIP Communications2	ETN_Port2Status.PortErr (Communications Port2 Error)
Target PLC Error Information)6-13, 6-27	ETN_PORT2Status.PORTEIT (CONTINUINCATIONS PORT2 ETTOI)6-6, 6-17
EIP_Comm2Status.TargetPLCModeSta (CIP Communica-	ETN_TcpAppCfgErr (TCP Application Setting Error)
tions2 Target PLC Operating Mode)	ETN_TCPAPPCIGET (TCP Application Setting Error)
EIP_Comm2Status.TDLinkAllRunSta (CIP Communica-	Event code
tions2 All Tag Data Link Communications Status)	Event name
- ,	

F		network type number	
function		network variablesimporting to Network Configurator	
functional comparison with other series	A-4	importing to Notwork Comigurator	0 20
G		0	
		Originator Variable	9-37
gateway address	7-5	output ON response time	12-25
General Status	10-21	output variable operation and timing	10-18
general status code	10-19	overview of the CIP message communication	ns service 10-2
global addresses	8-9	В	
н		P	
		Packet Filter	
Host Name		Packet Interval (RPI)	
host names	7-4, 7-12, 7-14	packet interval (RPI) accuracy	
1		PING Command	
<u> </u>		port Posis Ethernet Setting Error	
Identity Object	10-28	Port1 Basic Ethernet Setting Error Port1 BOOTP Server Error	
input ON response time		Port1 Communications Controller Error	
IP address allocation		Port1 P Address Duplication Error	,
IP address configuration		Port1 IP Address Setting Error	
IP address setting method		Port1 MAC Address Error	
IP addresses		Port1 Online	
IP Router Table Setting Error		Port2 Basic Ethernet Setting Error	
IP router table setting example		Port2 BOOTP Server Error	
IP routing		Port2 Communications Controller Error	•
3		Port2 IP Address Duplication Error	•
K		Port2 IP Address Setting Error	
		Port2 MAC Address Error	
Keep Alive	7-5	Port2 Online	
Keep Alive monitoring time	7-5	Prevention	,
_		priority DNS server	
L		private addresses	8-9
Level	44.44	procedure to use the SNMP agent	
Liven			
Linger option		R	
LINK settings			
LINK Settings DisplayLLDP		reading network configuration file	
location	·	receive data processing time	
Log category		Recognition 1 settings	
lot number		Recognition 2 settings	
Tot Humbor	20	recognition method	
M		recommended clamp core and attachment r	
		Recovery	
MAC addresses	26	registering devices	
maximum tag data link I/O response time	12-23	reponse code	
message service transmission delay	12-27	Requested Packet Interval (RPI) and b	
MIB groups	11-5	(PPS) Requested Packet Interval (RPI) settings	
MIB system diagram	11-4	route path	
multi-cast and unicast communications	9-9	RPI	
multicast filtering	5-3	N 1	9-37
N		S	
		sample programming	
Network Configurator		ladder programming for tag data links	9-73
connecting through Ethernet		saving network configuration file	
network transmission delay time	12-25	secondary DNS server	

send a recognition trap	7-11
send data processing time	
setting and downloading tag data link parameters	
setting IP addresses	
settings required for the SNMP agent	
SNMP agent1	-12, 11-2
SNMP messages	
SNMP service	
SNMP Settings Display	
SNMP specifications	
SNMP Trap Settings Display	
SNMP traps	
Source details	
specifying host names	
specifying method	
starting and stopping tag data linksstarting and stopping tag data links for individual de	
starting and stopping tag data links for individual de	
starting and stopping tag data links for the entire ne	
Starting and Stopping tag data links for the entire ne	
Status 1 Tab Page	
Status 2 Tab Page	
structure variables for input request paths	
subnet mask7-2	
subnet mask7-2	
	, 7-3, 8-3
T	12-9
tag data link bandwidth usage and RPI	12-9
tag data link bandwidth usage and RPItag data link communications methodtag data link I/O response timetag data link parameters	, 7-3, 8-3 12-9 12-2 12-23
tag data link bandwidth usage and RPItag data link communications methodtag data link I/O response time	, 7-3, 8-3 12-9 12-2 12-23
tag data link bandwidth usage and RPItag data link communications methodtag data link I/O response timetag data link parameters downloadingtag data links	, 7-3, 8-3 12-9 12-2 12-23 9-51
tag data link bandwidth usage and RPI	, 7-3, 8-3 12-9 12-2 12-23 9-51
tag data link bandwidth usage and RPI	, 7-3, 8-3 12-9 12-2 12-23 9-51 9-3 9-12
tag data link bandwidth usage and RPI	, 7-3, 8-3 12-9 12-2 12-23 9-51 9-3 9-12
tag data link bandwidth usage and RPI	, 7-3, 8-3 12-9 12-2 12-23 9-51 9-3 9-6 9-2
tag data link bandwidth usage and RPI	, 7-3, 8-3 12-9 12-23 9-51 9-3 9-6 9-12
tag data link bandwidth usage and RPI	12-912-239-519-129-69-15 PU Units
tag data link bandwidth usage and RPI	, 7-3, 8-312-912-239-519-129-69-15 PU Units9-78
tag data link bandwidth usage and RPI	, 7-3, 8-312-912-29-519-129-129-15 PU Units9-781-8
tag data link bandwidth usage and RPI	, 7-3, 8-312-912-29-519-129-15 PU Units9-789-3
tag data link bandwidth usage and RPI	, 7-3, 8-312-912-29-519-59-129-69-15 PU Units9-789-31-89-314-53
tag data link bandwidth usage and RPI	, 7-3, 8-312-99-519-519-15 PU Units9-781-89-31-89-31-89-3
tag data link bandwidth usage and RPI	, 7-3, 8-312-912-239-519-159-15 PU Units9-781-89-314-539-39-36
tag data link bandwidth usage and RPI	, 7-3, 8-312-99-519-519-15 PU Units9-781-89-39-39-39-39-3

connection methods.....5-13

installation precautionsother precautions for cable installation	
U	
unit version	26
uploading tag data link parameters	
uploading all	9-54
uploading from individual devices	9-56
Use of duplicated IP address	7-3
using CIP communications instructions	10-4
verifying device parameters	9-59
verifying tag data link parameters	
versions	
x	
X Bus Ethernet Function Module	14-6
X Bus EtherNet/IP Function Module	
X Bus Function Module	14-6
X Bus Unit Common Function Module	

twisted-pair cable

Index

#### **OMRON Corporation** Industrial Automation Company

Kyoto, JAPAN Contact : www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V.

Wegalaan 67-69, 2132 JD Hoofddorp The Netherlands Tel: (31) 2356-81-300 Fax: (31) 2356-81-388

OMRON ASIA PACIFIC PTE. LTD.

438B Alexandra Road, #08-01/02 Alexandra Technopark, Singapore 119968 Tel: (65) 6835-3011 Fax: (65) 6835-3011 OMRON ELECTRONICS LLC

2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900 Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD.

Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-6023-0333 Fax: (86) 21-5037-2388 Authorized Distributor:

©OMRON Corporation 2023 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

Cat. No. W627-E1-02 0623